

ENGINE CONTROL SYSTEM

SECTION EC

GI
MA
EM
LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

CONTENTS

TROUBLE DIAGNOSIS - INDEX	4	Malfunction Indicator Lamp (MIL)	35
Alphabetical & P No. Index for DTC	4	CONSULT-II	39
PRECAUTIONS	6	TROUBLE DIAGNOSIS - INTRODUCTION	46
Supplemental Restraint System (SRS) "AIR BAG"	6	Introduction	46
Precautions for On Board Diagnostic (OBD) System of Engine	6	Work Flow	48
Engine Fuel & Emission Control System	7	TROUBLE DIAGNOSIS - BASIC INSPECTION	50
Wiring Diagrams and Trouble Diagnosis	9	Basic Inspection	50
PREPARATION	10	TROUBLE DIAGNOSIS - GENERAL DESCRIPTION	67
Special Service Tools	10	Fail-safe Chart	67
Commercial Service Tools	10	Symptom Matrix Chart	68
ENGINE AND EMISSION CONTROL OVERALL SYSTEM	11	CONSULT-II Reference Value in Data Monitor Mode	72
Engine Control Component Parts Location	11	Major Sensor Reference Graph in Data Monitor Mode	74
Circuit Diagram	14	ECM Terminals and Reference Value	76
System Diagram	15	TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT	82
Vacuum Hose Drawing	16	Description	82
System Chart	17	Diagnostic Procedure	82
ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION	18	TROUBLE DIAGNOSIS FOR POWER SUPPLY	83
Multiport Fuel Injection (MFI) System	18	Main Power Supply and Ground Circuit	83
Electronic Ignition (EI) System	20	DTC 0101 CAMSHAFT POSITION SENSOR (CMPS)	90
Air Conditioning Cut Control	21	Component Description	90
Fuel Cut Control (at no load & high engine speed)	22	ECM Terminals and Reference Value	90
Evaporative Emission System	22	On Board Diagnosis Logic	91
Positive Crankcase Ventilation	25	DTC Confirmation Procedure	91
BASIC SERVICE PROCEDURE	27	Wiring Diagram	93
Fuel Pressure Release	27	Diagnostic Procedure	94
Fuel Pressure Check	27	Component Inspection	97
Fuel Pressure Regulator Check	28	DTC 0102 MASS AIR FLOW SENSOR (MAFS)	98
Injector	28	Component Description	98
Fast Idle Cam (FIC)	29	CONSULT-II Reference Value in Data Monitor Mode	98
How to Check Idle Speed and Ignition Timing	30	ECM Terminals and Reference Value	98
ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION	33	On Board Diagnosis Logic	98
Introduction	33	Fail-safe Mode	99
Diagnostic Trouble Code (DTC)	33	DTC Confirmation Procedure	99

CONTENTS (Cont'd)

Wiring Diagram	101	Diagnostic Procedure	145
Diagnostic Procedure	102	Component Inspection	146
Component Inspection	104	DTC 0504 A/T CONTROL	148
DTC 0103 ENGINE COOLANT TEMPERATURE		System Description	148
SENSOR (ECTS) (CIRCUIT)	105	ECM Terminals and Reference Value	148
Component Description	105	On Board Diagnosis Logic	148
CONSULT-II Reference Value in Data Monitor		DTC Confirmation Procedure	148
Mode	105	Overall Function Check	149
On Board Diagnosis Logic	105	Wiring Diagram	150
Fail-safe Mode	106	Diagnostic Procedure	151
DTC Confirmation Procedure	106	HEATED OXYGEN SENSOR 1 (FRONT)	152
Wiring Diagram	107	Component Description	152
Diagnostic Procedure	108	CONSULT-II Reference Value in Data Monitor	
Component Inspection	109	Mode	152
DTC 0201 IGNITION SIGNAL	110	ECM Terminals and Reference Value	152
Component Description	110	Wiring Diagram	153
CONSULT-II Reference Value in Data Monitor		Diagnostic Procedure	154
Mode	110	Component Inspection	156
ECM Terminals and Reference Value	110	HEATED OXYGEN SENSOR 1 HEATER (FRONT)	158
On Board Diagnosis Logic	111	Description	158
DTC Confirmation Procedure	111	ECM Terminals and Reference Value	158
Wiring Diagram	112	Wiring Diagram	159
Diagnostic Procedure	114	Diagnostic Procedure	160
Component Inspection	119	Component Inspection	161
DTC 0208 OVERHEAT (COOLING SYSTEM)	120	VEHICLE SPEED SENSOR (VSS)	162
System Description	120	Component Description	162
CONSULT-II Reference Value in Data Monitor		ECM Terminals and Reference Value	162
Mode	120	Wiring Diagram	163
ECM Terminals and Reference Value	120	Diagnostic Procedure	164
On Board Diagnosis Logic	121	IDLE AIR CONTROL VALVE (IACV) - AUXILIARY	
Overall Function Check	122	AIR CONTROL (AAC) VALVE	166
Wiring Diagram	123	Description	166
Diagnostic Procedure	124	CONSULT-II Reference Value in Data Monitor	
Main 12 Causes of Overheating	135	Mode	166
Component Inspection	135	ECM Terminals and Reference Value	167
DTC 0304 KNOCK SENSOR (KS)	137	Wiring Diagram	168
Component Description	137	Diagnostic Procedure	169
ECM Terminals and Reference Value	137	Component Inspection	172
On Board Diagnosis Logic	137	INTAKE VALVE TIMING CONTROL SOLENOID	
DTC Confirmation Procedure	137	VALVE	173
Wiring Diagram	138	Component Description	173
Diagnostic Procedure	139	Operation	173
Component Inspection	140	CONSULT-II Reference Value in Data Monitor	
DTC 0403 THROTTLE POSITION SENSOR	141	Mode	174
Component Description	141	ECM Terminals and Reference Value	174
CONSULT-II Reference Value in Data Monitor		Wiring Diagram	175
Mode	141	Diagnostic Procedure	176
ECM Terminals and Reference Value	142	Component Inspection	178
On Board Diagnosis Logic	142	WASTEGATE VALVE CONTROL SOLENOID	
Fail-safe Mode	142	VALVE	179
DTC Confirmation Procedure	142	Description	179
Wiring Diagram	144		

CONTENTS (Cont'd)

CONSULT-II Reference Value in Data Monitor Mode	179	Diagnostic Procedure	206	GI
ECM Terminals and Reference Value	180	Component Inspection	208	
Wiring Diagram	181	IACV-FICD SOLENOID VALVE	209	MA
Diagnostic Procedure	182	Component Description	209	EM
Component Inspection	185	ECM Terminals and Reference Value	209	EM
PARK/NEUTRAL POSITION (PNP) SWITCH	186	Wiring Diagram	210	
Component Description	186	Diagnostic Procedure	211	
CONSULT-II Reference Value in Data Monitor Mode	186	Component Inspection	212	
ECM Terminals and Reference Value	186	POWER STEERING OIL PRESSURE SWITCH	213	LC
Wiring Diagram	187	Component Description	213	
Diagnostic Procedure	188	CONSULT-II Reference Value in Data Monitor Mode	213	EC
INJECTOR	194	ECM Terminals and Reference Value	213	
Component Description	194	Wiring Diagram	214	FE
CONSULT-II Reference Value in Data Monitor Mode	194	Diagnostic Procedure	215	
ECM Terminals and Reference Value	194	Component Inspection	217	
Wiring Diagram	195	ELECTRICAL LOAD SIGNAL	218	CL
Diagnostic Procedure	196	CONSULT-II Reference Value in Data Monitor Mode	218	
Component Inspection	198	ECM Terminals and Reference Value	218	MT
START SIGNAL	199	Wiring Diagram	219	
CONSULT-II Reference Value in Data Monitor Mode	199	Diagnostic Procedure	220	AT
ECM Terminals and Reference Value	199	MI & DATA LINK CONNECTORS	224	
Wiring Diagram	200	Wiring Diagram	224	
Diagnostic Procedure	201	SERVICE DATA AND SPECIFICATIONS (SDS)	225	PD
FUEL PUMP	203	Fuel Pressure Regulator	225	
System Description	203	Idle Speed and Ignition Timing	225	AX
Component Description	203	Mass Air Flow Sensor	225	
CONSULT-II Reference Value in Data Monitor Mode	203	Engine Coolant Temperature Sensor	225	SU
ECM Terminals and Reference Value	204	Fuel Pump	225	
Wiring Diagram	205	IACV-AAC Valve	225	BR
		Injector	225	
		Throttle Position Sensor	225	ST
		Heated Oxygen Sensor 1 (Front) Heater	225	RS
				BT
				HA
				SC
				EL
				IDX

TROUBLE DIAGNOSIS — INDEX

Alphabetical & P No. Index for DTC

Alphabetical & P No. Index for DTC

NMEC0001

ALPHABETICAL INDEX FOR DTC

NMEC0001S01

X: Applicable —: Not applicable

Items (CONSULT-II screen terms)	DTC*1	MIL light up	Reference page
Unable to access ECM	—	X	EC-67
A/T COMM LINE	0504	—	EC-148
CAMSHAFT POSI SEN	0101	—	EC-90
COOLANT TEMP SEN	0103	X	EC-105
IGN SIGNAL-PRIMARY	0201	—	EC-110
KNOCK SENSOR	0304	—	EC-137
MASS AIR FLOW SEN	0102	X	EC-98
NATS MALFUNCTION	1401 - 1406, 1408	—	EL-134
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	0505	—	—
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	Flashing*2	—	EC-35
OVERHEAT	0208	X	EC-120
THROTTLE POSI SEN	0403	X	EC-141

NOTE:

*1: In Diagnostic Test Mode II (Self-diagnostic results).

*2: While engine is running.

TROUBLE DIAGNOSIS — INDEX

Alphabetical & P No. Index for DTC (Cont'd)

NUMERICAL INDEX FOR DTC

X: Applicable —: Not applicable ^{=NMEC0001S02}

DTC*1	Items (CONSULT-II screen terms)	MIL light up	Reference page
—	Unable to access ECM	X	EC-67
Flashing*2	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—	EC-35
0101	CAMSHAFT POSI SEN	—	EC-90
0102	MASS AIR FLOW SEN	X	EC-98
0103	COOLANT TEMP SEN	X	EC-105
0201	IGN SIGNAL-PRIMARY	—	EC-110
0208	OVERHEAT	X	EC-120
0304	KNOCK SENSOR	—	EC-137
0403	THROTTLE POSI SEN	X	EC-141
0504	A/T COMM LINE	—	EC-148
0505	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—	—
1401 - 1406, 1408	NATS MALFUNCTION	—	EL-134

NOTE:

*1: In Diagnostic Test Mode II (Self-diagnostic results).

*2: While engine is running.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG"

Supplemental Restraint System (SRS) "AIR BAG"

NMEC0653

The Supplemental Restraint System such as "AIR BAG" used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The SRS system composition which is available to NISSAN MODEL S15 is as follows:

The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified with yellow harness connector.

Precautions for On Board Diagnostic (OBD) System of Engine

NMEC0003





The ECM has an on board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.

CAUTION:

- Be sure to turn the ignition switch OFF and disconnect the negative battery terminal before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to light up due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Be sure to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MIL to light up due to the short circuit.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the ECM before returning the vehicle to the customer.

PRECAUTIONS

=NMEC0659



Engine Fuel & Emission Control System

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.
- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect negative battery terminal. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned off.

- Do not disassemble ECM.
- If a battery terminal is disconnected, the memory will return to the ECM value. The ECM will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.

- When connecting ECM harness connector, tighten securing bolt until the gap between orange indicators disappears.


 : 3.0 - 4.9 N·m (0.3 - 0.5 kg·m, 26 - 43 in·lb)

- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break). Make sure that there are not any bends or breaks on ECM pin terminals when connecting pin connectors.
- Securely connect ECM harness connectors. A Poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep ECM harness at least 10 cm (4 in) away from adjacent harness, to prevent an ECM system malfunctions due to receiving external noise, degraded operation of ICs, etc.
- Keep ECM parts and harness dry.


GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

PRECAUTIONS


Engine Fuel & Emission Control System (Cont'd)



- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble IAC valve-AAC valve.
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the camshaft position sensor and crankshaft position sensor.
- Before replacing ECM, perform refer to “ECM Terminals and Reference Value” inspection and make sure ECM functions properly, EC-76.




- After performing each TROUBLE DIAGNOSIS, perform “DTC Confirmation Procedure” or “Overall Function Check”.
The DTC should not be displayed in the “DTC Confirmation Procedure” if the repair is completed. The “Overall Function Check” should be a good result if the repair is completed.



- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.
- Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

PRECAUTIONS


Engine Fuel & Emission Control System (Cont'd)



- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque.



- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.



- When installing C.B. ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on installation location.
- 1) Keep the antenna as far as possible from the electronic control units.
 - 2) Keep the antenna feeder line more than 20 cm (8 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.
 - 3) Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
 - 4) Be sure to ground the radio to vehicle body.

Wiring Diagrams and Trouble Diagnosis

NMEC0660

When you read Wiring diagrams, refer to the following:

- GI-11, "HOW TO READ WIRING DIAGRAMS"
- EL-7, "POWER SUPPLY ROUTING" for power distribution circuit

When you perform trouble diagnosis, refer to the following:

- GI-31, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"
- GI-20, "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT"

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

PREPARATION

Special Service Tools




Special Service Tools

NMEC0007

Tool number Tool name	Description
KV10117100 Heated oxygen sensor wrench	 <p data-bbox="950 283 1469 336">Loosening or tightening heated oxygen sensor with 22 mm (0.87 in) hexagon nut</p> <p data-bbox="414 514 479 535">NT379</p>

Commercial Service Tools

NMEC0008


Tool name	Description
Fuel filler cap adapter	 <p data-bbox="950 672 1437 724">Checking fuel tank vacuum relief valve opening pressure</p> <p data-bbox="414 913 479 934">NT653</p>
Oxygen sensor thread cleaner	 <p data-bbox="950 955 1469 1039">Reconditioning the exhaust system threads before installing a new oxygen sensor. Use with anti-seize lubricant shown below.</p> <p data-bbox="950 1039 1437 1081">a: 18 mm dia. with pitch 1.5 mm for Zirconia Oxygen Sensor</p> <p data-bbox="950 1092 1437 1144">b: 12 mm dia. with pitch 1.25 mm for Titania Oxygen Sensor</p> <p data-bbox="414 1197 479 1218">NT778</p>
Anti-seize lubricant (Permatex™ 133AR or equivalent meeting MIL specification MIL-A-907)	 <p data-bbox="950 1239 1437 1291">Lubricating oxygen sensor thread cleaning tool when reconditioning exhaust system threads.</p> <p data-bbox="414 1480 479 1501">NT779</p>

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Engine Control Component Parts Location

Engine Control Component Parts Location

NMEC0009



GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC







EL

IDX

SEC317C

ENGINE AND EMISSION CONTROL OVERALL SYSTEM







Engine Control Component Parts Location (Cont'd)



SEC318C

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Engine Control Component Parts Location (Cont'd)



GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


SEC319C

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Circuit Diagram

Circuit Diagram


NMEC0010



TEC797

System Diagram

NMEC0011



GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

Vacuum Hose Drawing

Vacuum Hose Drawing

NMEC0012



NOTE: Do not use soapy water or any type of solvent while installing vacuum hoses or purge hoses.

SEC321C

Refer to "System Diagram", EC-15 for Vacuum Control System.

ENGINE AND EMISSION CONTROL OVERALL SYSTEM

System Chart

System Chart

NMEC0013

Input (Sensor)	ECM Function	Output (Actuator)	
<ul style="list-style-type: none"> ● Camshaft position sensor ● Mass air flow sensor ● Engine coolant temperature sensor ● Heated oxygen sensor 1 (front) ● Ignition switch ● Throttle position sensor ● Park/neutral position (PNP) switch ● Air conditioner switch ● Knock sensor ● Battery voltage ● Power steering oil pressure switch ● Vehicle speed sensor ● TCM (Transmission control module) ● Dual pressure switch ● Electrical load 	Fuel injection & mixture ratio control	Injectors	GI
	Electronic ignition system	Power transistor	MA
	Idle air control system	IACV-AAC valve and IACV-FICD solenoid valve	EM
	Fuel pump control	Fuel pump relay	
	Heated oxygen sensor monitor & on board diagnostic system	MIL (On the instrument panel)	LC
	Heated oxygen sensor 1 heater (front) control	Heated oxygen sensor 1 heater (front)	EC
	Wastegate valve control	Wastegate valve control solenoid valve	FE
	Intake valve timing control	Intake valve timing control solenoid valve	CL
	Air conditioning cut control	Air conditioner relay	
	Cooling fan control	Cooling fan relays	MT
			AT
			PD
			AX
			SU
			BR
			ST
			RS
			BT
			HA
			SC
			EL
			IDX

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Multiport Fuel Injection (MFI) System

Multiport Fuel Injection (MFI) System

DESCRIPTION

NMEC0014

Input/Output Signal Chart

NMEC0014S01

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed and piston position	Fuel injection & mixture ratio control	Injectors
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Heated oxygen sensor 1 (front)	Density of oxygen in exhaust gas		
Throttle position sensor	Throttle position Throttle valve idle position		
Park/neutral position (PNP) switch	Gear position		
Vehicle speed sensor	Vehicle speed		
Ignition switch	Start signal		
Air conditioner switch	Air conditioner operation		
Knock sensor	Engine knocking condition		
Battery	Battery voltage		
Power steering oil pressure switch	Power steering operation		

Basic Multiport Fuel Injection System

NMEC0014S02

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined by input signals (for engine speed and intake air) from both the camshaft position sensor and the mass air flow sensor.

Various Fuel Injection Increase/Decrease Compensation

NMEC0014S03

In addition, the amount of fuel injected is compensated to improve engine performance under various operating conditions as listed below.

<Fuel increase>


- During warm-up
- When starting the engine
- During acceleration
- Hot-engine operation
- When selector lever is changed from "N" to "D"
- High-load, high-speed operation

<Fuel decrease>

- During deceleration
- During high engine speed operation

Mixture Ratio Feedback Control (Closed loop control)

NMEC0014S04



The mixture ratio feedback system provides the best air-fuel mixture ratio for driveability and emission control. The warm-up three way catalyst can then better reduce CO, HC and NOx emissions. This system uses a heated oxygen sensor 1 (front) in the exhaust manifold to monitor if the engine operation is rich or lean. The ECM adjusts the injection pulse width according to the sensor voltage signal. For more information about the front heated oxygen sensor, refer to EC-152. This maintains the mixture ratio within the range of stoichiometric (ideal air-fuel mixture).

This stage is referred to as the closed loop control condition.

Open Loop Control

NMEC0014S05

The open loop system condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

- Deceleration and acceleration
- High-load, high-speed operation
- Malfunction of heated oxygen sensor 1 (front) or its circuit
- Insufficient activation of heated oxygen sensor 1 (front) at low engine coolant temperature
- High engine coolant temperature
- During warm-up
- After shifting from "N" to "D"
- When starting the engine

Mixture Ratio Self-learning Control

NMEC0014S06

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from the heated oxygen sensor 1 (front). This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. Both manufacturing differences (i.e., mass air flow sensor hot wire) and characteristic changes during operation (i.e., injector clogging) directly affect mixture ratio.

Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "injection pulse duration" to automatically compensate for the difference between the two ratios.

"Fuel trim" refers to the feedback compensation value compared against the basic injection duration. Fuel trim includes short term fuel trim and long term fuel trim.


"Short term fuel trim" is the short-term fuel compensation used to maintain the mixture ratio at its theoretical value. The signal from the heated oxygen sensor 1 (front) indicates whether the mixture ratio is RICH or LEAN compared to the theoretical value. The signal then triggers a reduction in fuel volume if the mixture ratio is rich, and an increase in fuel volume if it is lean.

"Long term fuel trim" is overall fuel compensation carried out long-term to compensate for continual deviation of the short term fuel trim from the central value. Such deviation will occur due to individual engine differences, wear over time and changes in the usage environment.

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Multiport Fuel Injection (MFI) System (Cont'd)

Fuel Injection Timing



Two types of systems are used.

Sequential Multiport Fuel Injection System

Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is running. NMEC0014S0701

Simultaneous Multiport Fuel Injection System

Fuel is injected simultaneously into all four cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM. NMEC0014S0702

The four injectors will then receive the signals two times for each engine cycle.

This system is used when the engine is being started and/or if the fail-safe system (CPU) is operating.

Fuel Shut-off

Fuel to each cylinder is cut off during deceleration or operation of the engine at excessively high speeds. NMEC0014S08

Electronic Ignition (EI) System

DESCRIPTION

Input/Output Signal Chart


NMEC0015

NMEC0015S01

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed and piston position	Ignition timing control	Power transistor
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Throttle position sensor	Throttle position Throttle valve idle position		
Vehicle speed sensor	Vehicle speed		
Ignition switch	Start signal		
Knock sensor	Engine knocking		
Park/neutral position (PNP) switch	Gear position		
Battery	Battery voltage		

System Description

NMEC0015S02



The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine. The ignition timing data is stored in the ECM. This data forms the map shown.

The ECM receives information such as the injection pulse width and camshaft position sensor signal. Computing this information, ignition signals are transmitted to the power transistor.

e.g., N: 1,800 rpm, Tp: 1.50 msec
A °BTDC

During the following conditions, the ignition timing is revised by the ECM according to the other data stored in the ECM.

- At starting
- During warm-up
- At idle
- At low battery voltage
- During acceleration

The knock sensor retard system is designed only for emergencies. The basic ignition timing is programmed within the anti-knocking zone, if recommended fuel is used under dry conditions. The retard system does not operate under normal driving conditions. If engine knocking occurs, the knock sensor monitors the condition. The signal is transmitted to the ECM. The ECM retards the ignition timing to eliminate the knocking condition.

Air Conditioning Cut Control

DESCRIPTION

Input/Output Signal Chart

NMEC0016

NMEC0016S01

Sensor	Input Signal to ECM	ECM function	Actuator
Air conditioner switch	Air conditioner "ON" signal	Air conditioner cut control	Air conditioner relay
Throttle position sensor	Throttle valve opening angle		
Camshaft position sensor	Engine speed		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Vehicle speed sensor	Vehicle speed		
Power steering oil pressure switch	Power steering operation		

System Description

NMEC0016S02

This system improves engine operation when the air conditioner is used.

Under the following conditions, the air conditioner is turned off.

- When the accelerator pedal is fully depressed.
- When cranking the engine.
- At high engine speeds.
- When the engine coolant temperature becomes excessively high.
- When operating power steering during low engine speed or low vehicle speed.
- When engine speed is excessively low.

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Fuel Cut Control (at no load & high engine speed)

Fuel Cut Control (at no load & high engine speed)

DESCRIPTION

Input/Output Signal Chart

NMEC0017

NMEC0017S01

Sensor	Input Signal to ECM	ECM function	Actuator
Vehicle speed sensor	Vehicle speed	Fuel cut control	Injectors
Park/neutral position (PNP) switch	Neutral position		
Throttle position sensor	Throttle position		
Engine coolant temperature sensor	Engine coolant temperature		
Camshaft position sensor	Engine speed		

If the engine speed is above 2,500 rpm with no load (for example, in neutral and engine speed over 2,500 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed. Fuel cut will operate until the engine speed reaches 2,000 rpm, then fuel cut is cancelled.


NOTE:

This function is different from deceleration control listed under "Multiport Fuel Injection (MFI) System", EC-18.

Evaporative Emission System

DESCRIPTION

NMEC0018




The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister. The fuel vapor from sealed fuel tank is led into the EVAP canister when the engine is off. The fuel vapor is then stored in the EVAP canister. The EVAP canister retains the fuel vapor until the EVAP canister is purged by air.

When the engine is running, the air is drawn through the bottom of the EVAP canister. The fuel vapor will then be led to the intake manifold.

When the engine runs at idle, the purge control valve is closed. Only a small amount of vapor flows into the intake manifold through the constant purge orifice.

As the engine speed increases and the throttle vacuum rises, the purge control valve opens. The vapor is sucked through both main purge and constant purge orifices.



INSPECTION

EVAP Canister

NMEC0019

NMEC0019S01

Check EVAP canister as follows:


1. Blow air through port A orally. Make sure that there is no leakage.
2. Apply vacuum to port A. Block port D. Blow air through port C orally. Check that air flows freely through port B.

GI

MA

EM

LC



Fuel Check Valve

NMEC0019S11


1. Blow air through connector on fuel tank side. A considerable resistance should be felt and a portion of air flow should be directed toward the EVAP canister side.
2. Blow air through connector on EVAP canister side. Air flow should be smoothly directed toward fuel tank side.
3. If fuel check valve is suspected of not properly functioning in steps 1 and 2 above, replace it.

EC

FE

CL

MT



Fuel Tank Vacuum Relief Valve (Built into fuel filler cap)

NMEC0019S03

1. Wipe clean valve housing.
2. Check valve opening pressure and vacuum.

Pressure:

15.3 - 20.0 kPa (0.156 - 0.204 kg/cm², 2.22 - 2.90 psi)

Vacuum:

-6.0 to -3.4 kPa (-0.061 to -0.035 kg/cm², -0.87 to -0.50 psi)

3. If out of specification, replace fuel filler cap as an assembly.

AT


PD

AX

SU

CAUTION:

Use only a genuine fuel filler cap as a replacement.



BR

ST

RS

BT

HA

SC

EL


IDX

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Evaporative Emission System (Cont'd)

EVAPORATIVE EMISSION LINE DRAWING

NMEC0020




NOTE: Do not use soapy water or any type of solvent while installing vacuum hose or purge hoses.

SEC322C

Positive Crankcase Ventilation DESCRIPTION

NMEC0021




SEF030Q

This system returns blow-by gas to the intake manifold. The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold. During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve. Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air. The ventilating air is then drawn from the air inlet tubes into the crankcase. In this process the air passes through the hose connecting air inlet tubes to rocker cover. Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve. The flow goes through the hose connection in the reverse direction. On vehicles with an excessively high blow-by, the valve does not meet the requirement. This is because some of the flow will go through the hose connection to the air inlet tubes under all conditions.

INSPECTION

PCV (Positive Crankcase Ventilation) Valve

With engine running at idle, remove PCV valve from rocker cover; if the valve is working properly, a hissing noise will be heard as air passes through it and a strong vacuum should be felt immediately when a finger is placed over valve inlet.




SEC137A

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION





Positive Crankcase Ventilation (Cont'd)



PCV Valve Ventilation Hose

NMEC0022S02

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.



Fuel Pressure Release

NMEC0023

Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.

WITH CONSULT-II

NMEC0023S01

1. Turn ignition switch "ON".
2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT-II.
3. Start engine.
4. After engine stalls, crank it two or three times to release all fuel pressure.
5. Turn ignition switch "OFF".

WITHOUT CONSULT-II

NMEC0023S02

1. Remove fuel pump fuse located in fuse box.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch "OFF".
5. Reinstall fuel pump fuse after servicing fuel system.

Fuel Pressure Check

NMEC0024

- When reconnecting fuel line, always use new clamps.
- Make sure that clamp screw does not contact adjacent parts.
- Use a torque driver to tighten clamps.
- Use Pressure Gauge to check fuel pressure.
- Do not perform fuel pressure check with system operating. Fuel pressure gauge may indicate false readings.

1. Release fuel pressure to zero.
2. Disconnect fuel hose from fuel filter.
3. Install pressure gauge between fuel hose and fuel filter.
4. Start engine and check for fuel leakage.
5. Read the indication of fuel pressure gauge.

At idling:

With vacuum hose connected

Approximately 235 kPa (2.4 kg/cm², 34 psi)


With vacuum hose disconnected

Approximately 294 kPa (3.0 kg/cm², 43 psi)

If results are unsatisfactory, perform Fuel Pressure Regulator Check.

BASIC SERVICE PROCEDURE

Fuel Pressure Regulator Check




Fuel Pressure Regulator Check

NMEC0025

1. Stop engine and disconnect fuel pressure regulator vacuum hose from intake manifold collector.
2. Plug intake manifold collector with a blind cap.
3. Connect variable vacuum source to fuel pressure regulator.
4. Start engine and read indication of fuel pressure gauge as vacuum is changed.

Fuel pressure should decrease as vacuum increases. If results are unsatisfactory, replace fuel pressure regulator.



Injector




REMOVAL AND INSTALLATION

NMEC0026

1. Remove injectors with fuel tube assembly. Refer to EM-36, "INTAKE MANIFOLD".
2. Push out any malfunctioning injector from fuel tube assembly.
 - **Do not extract injector by pinching connector.**
3. Replace or clean injector as necessary.
 - **Always replace O-rings and insulators with new ones.**
 - **Lubricate O-ring with a smear of engine oil.**
4. Install all parts removed in reverse order of removal.

CAUTION:

After properly connecting fuel tube assembly to injector and fuel hose, check connection for fuel leakage.



Fast Idle Cam (FIC) INSPECTION AND ADJUSTMENT

NMEC0656

NMEC0656S01

NMEC0656S0101





With CONSULT-II

1. Start engine.
2. See "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-II.
3. When engine coolant temperature is 75 to 85°C (167 to 185°F), go to next step.
4. Check that mark A (short line) on FI cam aligns with roller center.
If OK, inspection is complete.
If NG, go to next step.
5. Measure thermo-element stroke (L) and check it is within the specification in the figure.
If NG, replace thermo-element with a new one.
If OK, go to next step.
6. Loosen adjusting screw and align mark A (short line) on FI cam with roller center.
Tighten lock nut to the specification.
7. Cool down the engine until "COOLAN TEMP/S" indicates 20 to 30°C (68 to 86°F).
8. Check that mark B (long line) on FI cam aligns with roller center.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

BASIC SERVICE PROCEDURE

Fast Idle Cam (FIC) (Cont'd)



⊗ Without CONSULT-II

NMEC0656S0102

1. Start engine.
2. Check voltage between ECM terminal 18 (Engine coolant temperature sensor signal) and ground.
3. When the voltage is between 0.55 to 0.68V, go to next step.
4. Check that mark A (short line) on FI cam aligns with roller center.
If OK, inspection is complete.
If NG, go to next step.
5. Measure thermo-element stroke (L) and check it is within the specification in the figure.
If NG, replace thermo-element with a new one.
If OK, go to next step.
6. Loosen adjusting screw and align mark A (short line) on FI cam with roller center.
Tighten lock nut to the specification.
7. Cool down the engine until the voltage between ECM terminal 18 (engine coolant temperature sensor signal) and ground indicates 1.56 to 1.76V.
8. Check that mark B (long line) on FI cam aligns with roller center.

How to Check Idle Speed and Ignition Timing

NMEC0607

IDLE SPEED


NMEC0607S01

● Method A (Using CONSULT-II)

Check idle speed in "DATA MONITOR" mode with CONSULT-II.

BASIC SERVICE PROCEDURE

How to Check Idle Speed and Ignition Timing (Cont'd)



- **Method B (Using Tachometer)**


Clamp the loop wire (Red/White) using pulse type tachometer.

GI

MA

EM

LC



IGNITION TIMING

Any of following two methods may be used.

NMEC0607S02

EC


- **Method A**

- a) Attach timing light to loop wire as shown.
- b) Check ignition timing.

FE

CL

MT



- **Method B**

- a) Remove No. 1 ignition coil.
- b) Connect No. 1 ignition coil and No. 1 spark plug with suitable high-tension wire as shown, and attach timing light clamp to this wire.
- c) Check ignition timing.


AT

PD

AX

SU

BR



ST

RS

BT

HA


SC

EL

IDX

BASIC SERVICE PROCEDURE

How to Check Idle Speed and Ignition Timing (Cont'd)



Introduction

The ECM has an on board diagnostic system, which detects malfunctions related to engine sensors or actuators. Self-diagnosis items are listed in “TROUBLE DIAGNOSIS — INDEX”, EC-4. The malfunction indicator lamp (MIL) on the instrument panel lights up when the ECM enters fail-safe mode (Refer to EC-67.).

NMEC0657

GI

MA

Diagnostic Trouble Code (DTC)

HOW TO READ DTC

Malfunction items can be confirmed by the following methods.

NMEC0658

NMEC0658S01

EM

☐ With CONSULT-II

CONSULT-II displays the malfunctioning component or system. Examples: CAMSHAFT POSI SEN, MASS AIR FLOW SEN etc.

NMEC0658S0101

LC

⊗ Without CONSULT-II

The number of blinks of the malfunction indicator lamp in the Diagnostic Test Mode II (Self-Diagnostic Results) indicates the DTC. Examples: 0101, 1501 etc.

NMEC0658S0102

EC

- **Output of a DTC indicates a malfunction. However, Mode II does not indicate whether the malfunction is still occurring or has occurred in the past and has returned to normal. CONSULT-II can identify malfunction status as shown below. Therefore, using CONSULT-II (if available) is recommended.**

FE

CL

SELF DIAG RESULTS	
DTC RESULTS	TIME
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	

SEF560X

MT

AT

PD

AX

A sample of CONSULT-II display is shown at above. The malfunction is displayed in “SELF-DIAGNOSTIC RESULTS” mode of CONSULT-II. Time data indicates how many times the vehicle was driven after the last detection of a malfunction.

SU

If the malfunction is being detected currently, the time data will be “0”.

BR

HOW TO ERASE DTC

☐ With CONSULT-II

1. If the ignition switch stays “ON” after repair work, be sure to turn ignition switch “OFF” once. Wait at least 5 seconds and then turn it “ON” (engine stopped) again.
2. Touch “ENGINE”.
3. Touch “SELF-DIAG RESULTS”.
4. Touch “ERASE”. (The DTC in the ECM will be erased.)

NMEC0658S03

NMEC0658S0301

ST

RS

BT

HA

SC

EL

IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Diagnostic Trouble Code (DTC) (Cont'd)

How to erase DTC (With CONSULT-II)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" again.

SELECT SYSTEM
ENGINE

2. Turn CONSULT-II "ON" and touch "ENGINE".



SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
ECM PART NUMBER

3. Touch "SELF-DIAG RESULTS".



SELF DIAG RESULTS	
DTC RESULTS	TIME
COOLANT TEMP SEN	0

4. Touch "ERASE". (The DTC in the ECM will be erased.)

SEC329C

DTC in the ECM can be erased by selecting "ERASE" in the "SELF-DIAG RESULTS" mode with CONSULT-II.

No Tools

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" (engine stopped) again.
2. Change the diagnostic test mode from Mode II to Mode I by using the data link connector. (See EC-36.)

NMEC0658S0302

DTC in the ECM can be erased by changing the diagnostic test mode.

- If the battery is disconnected, DTC will be lost after approx. 24 hours.
- Erasing DTC using CONSULT-II is easier and quicker than switching the diagnostic test mode using the data link connector.
- Be careful not to erase the stored memory before starting trouble diagnoses.

NATS (NISSAN ANTI-THEFT SYSTEM)

NMEC0658S05

SELF DIAG RESULTS	
DTC RESULTS	TIME
NATS MALFUNCTION	0

SEF252Z

- If the security indicator lights up with the ignition switch in the "ON" position or "NATS MALFUNCTION" is displayed on "SELF-DIAG RESULTS" screen, perform self-diagnostic results mode with CONSULT-II using NATS program card. Refer to EL-134, "NATS (Nissan Anti-Theft System)".
- Confirm no self-diagnostic results of NATS is displayed before touching "ERASE" in "SELF-DIAG RESULTS" mode with CONSULT-II.
- When replacing ECM, initialization of NATS system and registration of all NATS ignition key IDs must be carried out with CONSULT-II using NATS program card. Therefore, be sure to receive all keys from vehicle owner. Regarding the procedures of NATS initialization and NATS ignition key ID registration, refer to CONSULT-II operation manual, NATS.


ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Malfunction Indicator Lamp (MIL)

Malfunction Indicator Lamp (MIL)

DESCRIPTION

NMEC0032



The MIL is located on the instrument panel.

1. The MIL will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
 - If the MIL does not light up, refer to EL-73, WARNING LAMPS or see EC-224.
2. When the engine is started, the MIL should go off.
 - If the MIL remains on, the on board diagnostic system has detected an engine system malfunction.

On Board Diagnostic System Function

NMEC0032S01

The on board diagnostic system has the following four functions.

Diagnostic Test Mode	KEY and ENG. Status	Function	Explanation of Function
Mode I	Ignition switch in ON position  Engine stopped 	BULB CHECK	This function checks the MIL bulb for damage (blown, open circuit, etc.). If the MIL does not come on, check MIL circuit. (See EC-224.)
	Engine running 	MALFUNCTION WARNING	This is a usual driving condition. When a malfunction is detected, the MIL will light up to inform the driver that a malfunction has been detected.
Mode II	Ignition switch in ON position  Engine stopped 	SELF-DIAGNOSTIC RESULTS	This function allows DTCs to be read.
	Engine running 	HEATED OXYGEN SENSOR 1 (FRONT) MONITOR	This function allows the fuel mixture condition (lean or rich), monitored by heated oxygen sensor 1 (front), to be read.

MIL Flashing without DTC

NMEC0032S0102

If the ECM is in Diagnostic Test Mode II, MIL may flash when engine is running. In this case, check ECM diagnostic test mode following "How to Switch Diagnostic Test Modes", EC-36.


How to switch the diagnostic test (function) modes, and details of the above functions are described later. (Refer to EC-37.)

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Malfunction Indicator Lamp (MIL) (Cont'd)

NMEC0032S07

How to Switch Diagnostic Test Modes



- Switching the modes is not possible when the engine is running.
- When ignition switch is turned off during diagnosis, power to ECM will drop after approx. 5 seconds. The diagnosis will automatically return to Diagnostic Test Mode I.

SEC330C

*1 EC-224

*2 EC-35

*3 EC-224

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Malfunction Indicator Lamp (MIL) (Cont'd)

Diagnostic Test Mode I — Bulb Check

NMEC0032S03

In this mode, the MIL on the instrument panel should stay ON. If it remains OFF, check the bulb. Refer to EL-73, "WARNING LAMPS" or see EC-224.

Diagnostic Test Mode I — Malfunction Warning


NMEC0032S04

MIL	Condition
ON	When malfunction is detected.
OFF	No malfunction.

Diagnostic Test Mode II — Self-diagnostic Results

NMEC0032S08

In this mode, the DTC is indicated by the number of blinks of the MIL. A DTC will be used as an example for how to read a code.



Long (0.6 second) blinking indicates the number of 1000th and 100th digits, and short (0.3 second) blinking indicates the number of tenth and single digits.

For example, the malfunction indicator lamp blinks four times for about 2.5 seconds (0.6 sec x 4 times) and then it blinks three times for about 1 second (0.3 sec x 3 times). This indicates the DTC "0403" and refers to the malfunction of the throttle position sensor.

In this way, all the detected malfunctions are classified by their diagnostic trouble code numbers. The DTC "0505" refer to no malfunction. (See TROUBLE DIAGNOSIS — INDEX, EC-4.)

How to Erase Diagnostic Test Mode II (Self-diagnostic results)

NMEC0032S0801

The DTC can be erased from the backup memory in the ECM when the diagnostic test mode is changed from Diagnostic Test Mode II to Diagnostic Test Mode I. (Refer to "How to Switch Diagnostic Test Modes", EC-36.)

- If the battery is disconnected, the DTC will be lost from the backup memory after approx. 24 hours.
- Be careful not to erase the stored memory before starting trouble diagnoses.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Malfunction Indicator Lamp (MIL) (Cont'd)

Diagnostic Test Mode II — Heated Oxygen Sensor 1 (Front) Monitor

=NMEC0032S09


In this mode, the MIL displays the condition of the fuel mixture (lean or rich) which is monitored by the heated oxygen sensor 1 (front).

MIL	Fuel mixture condition in the exhaust gas	Air fuel ratio feedback control condition
ON	Lean	Closed loop system
OFF	Rich	
*Remains ON or OFF	Any condition	Open loop system

*: Maintains conditions just before switching to open loop.

To check the heated oxygen sensor 1 (front) function, start engine in the Diagnostic Test Mode II and warm it up until engine coolant temperature indicator points to the middle of the gauge.

Next run engine at about 2,000 rpm for about 2 minutes under no-load conditions. Then make sure that the MIL comes ON more than 5 times within 10 seconds with engine running at 2,000 rpm under no-load.



CONSULT-II

CONSULT-II INSPECTION PROCEDURE

=NMEC0034

NMEC0034S01


1. Turn ignition switch OFF.
2. Connect "CONSULT-II" to data link connector, which is located under driver's side dash panel.

GI

MA

EM

LC




3. Turn ignition switch ON.
4. Touch "START".

EC

FE

CL

MT




5. Touch "ENGINE".

AT

PD

AX

SU



6. Perform each diagnostic test mode according to each service procedure.

BR

For further information, see the CONSULT-II Operation Manual.

ST

RS

BT

HA

SC

EL

IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

ENGINE CONTROL COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

NMEC0034S02

		Item	DIAGNOSTIC TEST MODE			
			WORK SUP-PORT	SELF-DIAG-NOSTIC RESULTS	DATA MONI-TOR	ACTIVE TEST
ENGINE CONTROL COMPONENT PARTS	INPUT	Camshaft position sensor		X	X	
		Mass air flow sensor		X	X	
		Engine coolant temperature sensor		X	X	X
		Heated oxygen sensor 1 (front)			X	
		Vehicle speed sensor			X	
		Throttle position sensor	X	X	X	
		Knock sensor		X		
		Ignition switch (start signal)			X	
		Air conditioner switch			X	
		Park/neutral position (PNP) switch			X	
		Power steering oil pressure switch			X	
		Battery voltage			X	
		Electrical load signal			X	
ENGINE CONTROL COMPONENT PARTS	OUTPUT	Injectors			X	X
		Power transistor (Ignition timing)	X	X (Ignition signal)	X	X
		IACV-AAC valve	X		X	X
		Air conditioner relay			X	
		Fuel pump relay	X		X	X
		Cooling fan relay		X	X	X
		Heated oxygen sensor 1 heater (front)			X	
		Intake valve timing control solenoid valve			X	X
		Wastegate valve control solenoid valve			X	X

X: Applicable

FUNCTION

NMEC0034S03

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT-II unit.
Self-diagnostic results	Self-diagnostic results can be read and erased quickly.
Data monitor	Input/Output data in the ECM can be read.
Active test	Diagnostic Test Mode in which CONSULT-II drives some actuators apart from the ECMs and also shifts some parameters in a specified range.
ECM part number	ECM part number can be read.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

WORK SUPPORT MODE

NMEC0034S04

WORK ITEM	CONDITION	USAGE
TP SW/TP SEN IDLE POSI ADJ	<ul style="list-style-type: none"> FOLLOW THE BASIC INSPECTION IN THE SERVICE MANUAL. 	When adjusting the idle throttle position.
IGNITION TIMING ADJ	<ul style="list-style-type: none"> IGNITION TIMING FEEDBACK CONTROL WILL BE HELD BY TOUCHING "START". AFTER DOING SO, ADJUST IGNITION TIMING WITH A TIMING LIGHT BY TURNING THE CAMSHAFT POSITION SENSOR. 	When adjusting initial ignition timing
IACV-AAC/V ADJ	SET ENGINE SPEED AT THE SPECIFIED VALUE UNDER THE FOLLOWING CONDITIONS. <ul style="list-style-type: none"> ENGINE WARMED UP NO-LOAD 	When adjusting idle speed
FUEL PRESSURE RELEASE	<ul style="list-style-type: none"> FUEL PUMP WILL STOP BY TOUCHING "START" DURING IDLING. CRANK A FEW TIMES AFTER ENGINE STALLS. 	When releasing fuel pressure from fuel line
SELF-LEARNING CONT	<ul style="list-style-type: none"> THE COEFFICIENT OF SELF-LEARNING CONTROL MIXTURE RATIO RETURNS TO THE ORIGINAL COEFFICIENT. 	When clearing the coefficient of self-learning control value

SELF-DIAGNOSTIC MODE DTC

NMEC0034S05

Regarding items of "DTC", refer to "TROUBLE DIAGNOSIS — INDEX" (See EC-4.)

DATA MONITOR MODE

NMEC0034S06

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
CMPS-RPM (REF) [rpm]	○	○	<ul style="list-style-type: none"> Indicates the engine speed computed from the REF signal (180° signal) of the camshaft position sensor. 	
MAS AIR/FL SE [V]	○	○	<ul style="list-style-type: none"> The signal voltage of the mass air flow sensor is displayed. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
A/F ALPHA [%]		○	<ul style="list-style-type: none"> The mean value of the air-fuel ratio feedback correction factor per cycle is indicated. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. This data also includes the data for the air-fuel ratio learning control.
COOLAN TEMP/S [°C] or [°F]	○	○	<ul style="list-style-type: none"> The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed. 	<ul style="list-style-type: none"> When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed.
O2S1 [V]	○	○	<ul style="list-style-type: none"> The signal voltage of the heated oxygen sensor 1 (front) is displayed. 	
M/R F/C MNT [RICH/LEAN]	○	○	<ul style="list-style-type: none"> Display of front heated oxygen sensor signal during air-fuel ratio feedback control: RICH ... means the mixture became "rich", and control is being affected toward a leaner mixture. LEAN ... means the mixture became "lean", and control is being affected toward a rich mixture. 	<ul style="list-style-type: none"> After turning ON the ignition switch, "RICH" is displayed until air-fuel mixture ratio feedback control begins. When the air-fuel ratio feedback is clamped, the value just before the clamping is displayed continuously.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
VHCL SPEED SE [km/h] or [mph]	○	○	<ul style="list-style-type: none"> The vehicle speed computed from the vehicle speed sensor signal is displayed. 	
BATTERY VOLT [V]	○	○	<ul style="list-style-type: none"> The power supply voltage of ECM is displayed. 	
THRTL POS SEN [V]	○	○	<ul style="list-style-type: none"> The throttle position sensor signal voltage is displayed. 	
START SIGNAL [ON/OFF]	○	○	<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the starter signal. 	<ul style="list-style-type: none"> After starting the engine, [OFF] is displayed regardless of the starter signal.
CLSD THL POS [ON/OFF]	○	○	<ul style="list-style-type: none"> Indicates idle position [ON/OFF] computed by ECM according to the throttle position sensor signal. 	
AIR COND SIG [ON/OFF]	○	○	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioner signal. 	
P/N POSI SW [ON/OFF]	○	○	<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the park/neutral position (PNP) switch signal. 	
PW/ST SIGNAL [ON/OFF]	○	○	<ul style="list-style-type: none"> [ON/OFF] condition of the power steering oil pressure switch determined by the power steering oil pressure signal is indicated. 	
LOAD SIGNAL [ON/OFF]	○	○	<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the electrical load signal and/or lighting switch. ON ... rear defogger is operating and/or lighting switch is on. OFF ... rear defogger is not operating and lighting switch is not on. 	
INJ PULSE [msec]		○	<ul style="list-style-type: none"> Indicates the actual fuel injection pulse width compensated by ECM according to the input signals. 	<ul style="list-style-type: none"> When the engine is stopped, a certain computed value is indicated.
IGN TIMING [BTDC]		○	<ul style="list-style-type: none"> Indicates the ignition timing computed by ECM according to the input signals. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
IACV-AAC/V [%]		○	<ul style="list-style-type: none"> Indicates the IACV-AAC valve control value computed by ECM according to the input signals. 	
W/G CONT S/V [%]		○	<ul style="list-style-type: none"> Indicates the wastegate valve control solenoid valve control value computed by the ECM according to the input signals. 	
AIR COND RLY [ON/OFF]		○	<ul style="list-style-type: none"> The air conditioner relay control condition (determined by ECM according to the input signal) is indicated. 	
FUEL PUMP RLY [ON/OFF]		○	<ul style="list-style-type: none"> Indicates the fuel pump relay control condition determined by ECM according to the input signals. 	

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
INT/V TIM SOL [ON/OFF]		○	<ul style="list-style-type: none"> The control condition of the intake valve timing control solenoid valve is indicated. ON ... Intake valve timing control is operating. OFF ... Intake valve timing control is not operating. 	
COOLING FAN [HIGH/LOW/OFF]		○	<ul style="list-style-type: none"> Indicates the control condition of the cooling fan (determined by ECM according to the input signal). HIGH ... High speed operation LOW ... Low speed operation OFF ... Stop 	
Voltage [V]			<ul style="list-style-type: none"> Voltage measured by the voltage probe. 	
Frequency [msec] or [Hz] or [%]			<ul style="list-style-type: none"> Pulse width, frequency or duty cycle measured by the pulse probe. 	<ul style="list-style-type: none"> Only “#” is displayed if item is unable to be measured. Figures with “#”s are temporary ones. They are the same figures as an actual piece of data which was just previously measured.

NOTE:

- Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

ACTIVE TEST MODE



NMEC0034S07

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
FUEL INJECTION	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the amount of fuel injection using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Harness and connector Fuel injectors Front heated oxygen sensor
IGNITION TIMING	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Timing light: Set Retard the ignition timing using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Adjust initial ignition timing
IACV-AAC/V OPENING	<ul style="list-style-type: none"> Engine: After warming up, idle the engine. Change the IACV-AAC valve opening percent using CONSULT-II. 	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> Harness and connector IACV-AAC valve
POWER BALANCE	<ul style="list-style-type: none"> Engine: After warming up, idle the engine. A/C switch “OFF” Shift lever “N” Cut off each injector signal one at a time using CONSULT-II. 	Engine runs rough or dies.	<ul style="list-style-type: none"> Harness and connector Compression Injectors Power transistor Spark plugs Ignition coils
COOLING FAN	<ul style="list-style-type: none"> Ignition switch: ON Turn the cooling fan “HIGH”, “LOW” and “OFF” using CONSULT-II. 	Cooling fan moves and stops.	<ul style="list-style-type: none"> Harness and connector Cooling fan motor Cooling fan relay
ENG COOLANT TEMP	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the engine coolant temperature using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Harness and connector Engine coolant temperature sensor Fuel injectors

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
FUEL PUMP RELAY	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Turn the fuel pump relay "ON" and "OFF" using CONSULT-II and listen to operating sound. 	Fuel pump relay makes the operating sound.	<ul style="list-style-type: none"> Harness and connector Fuel pump relay
VALVE TIMING SOL	<ul style="list-style-type: none"> Ignition switch: ON Turn solenoid valve "ON" and "OFF" with CONSULT-II and listen to operating sound. 	Solenoid valve makes an operating sound.	<ul style="list-style-type: none"> Harness and connector Intake valve timing control solenoid valve
TURBOCHARGE PRES	<ul style="list-style-type: none"> Ignition switch: ON Change the wastegate valve control solenoid valve opening percent using CONSULT-II. 	Wastegate valve control solenoid valve makes an operating sound.	<ul style="list-style-type: none"> Harness and connector Wastegate valve control solenoid valve



REAL TIME DIAGNOSIS IN DATA MONITOR MODE (RECORDING VEHICLE DATA)

NMEC0034S10

CONSULT-II has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.

1) "AUTO TRIG" (Automatic trigger):

- The malfunction will be identified on the CONSULT-II screen in real time.

In other words, DTC and malfunction item will be displayed if the malfunction is detected by ECM.

At the moment a malfunction is detected by ECM, "MONITOR" in "DATA MONITOR" screen is changed to "Recording Data ... xx%" as shown at left, and the data after the malfunction detection is recorded. Then when the percentage reached 100%, "REAL-TIME DIAG" screen is displayed. If "STOP" is touched on the screen during "Recording Data ... xx%", "REAL-TIME DIAG" screen is also displayed.

The recording time after the malfunction detection and the recording speed can be changed by "TRIGGER POINT" and "Recording Speed". Refer to CONSULT-II OPERATION MANUAL.

2) "MANU TRIG" (Manual trigger):

- DTC and malfunction item will not be displayed automatically on CONSULT-II screen even though a malfunction is detected by ECM.

DATA MONITOR can be performed continuously even though a malfunction is detected.

Use these triggers as follows:

1) "AUTO TRIG"


- While trying to detect the DTC by performing the "DTC Confirmation Procedure", be sure to select to "DATA MONITOR (AUTO TRIG)" mode. You can confirm the malfunction at the moment it is detected.
- While narrowing down the possible causes, CONSULT-II should be set in "DATA MONITOR (AUTO TRIG)" mode, especially in case the incident is intermittent.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

When you are inspecting the circuit by gently shaking (or twisting) the suspicious connectors, components and harness in the "DTC Confirmation Procedure", the moment a malfunction is found the DTC will be displayed. (Refer to GI-21, "Incident Simulation Tests".

- 2) "MANU TRIG"
 - If the malfunction is displayed as soon as "DATA MONITOR" is selected, reset CONSULT-II to "MANU TRIG". By selecting "MANU TRIG" you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.






SEF720X

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSIS — INTRODUCTION

Introduction



KEY POINTS

- WHAT** Vehicle & engine model
- WHEN** Date, Frequencies
- WHERE**..... Road conditions
- HOW** Operating conditions,
Weather conditions,
Symptoms

SEF907L

Introduction

NMEC0036

The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no problems such as vacuum leaks, fouled spark plugs, or other problems with the engine.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems. A road test with CONSULT-II or a circuit tester connected should be performed. Follow the "Work Flow" on EC-48.

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such problems, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example on next page should be used.

Start your diagnosis by looking for "conventional" problems first. This will help troubleshoot driveability problems on an electronically controlled engine vehicle.

DIAGNOSTIC WORKSHEET

NMEC0036S01

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make trouble-shooting faster and more accurate.

In general, each customer feels differently about a problem. It is important to fully understand the symptoms or conditions for a customer complaint.


Utilize a diagnostic worksheet like the one on the next page in order to organize all the information for troubleshooting.

TROUBLE DIAGNOSIS — INTRODUCTION

Work Flow

Work Flow

NMEC0037



SEC332C

*1 EC-67

*2 If time data of "SELF-DIAG RESULTS" is other than "0" or "[1t]", perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.

*3 If the incident cannot be verified, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.

*4 If the on board diagnostic system cannot be performed, check main power supply and ground circuit.

Refer to "TROUBLE DIAGNOSIS FOR POWER SUPPLY", EC-83.
*5 If malfunctioning part cannot be detected, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.

TROUBLE DIAGNOSIS — INTRODUCTION

Work Flow (Cont'd)

DESCRIPTION FOR WORK FLOW

NMEC0037S01

STEP	DESCRIPTION	
STEP I	Get detailed information about the conditions and the environment when the incident/symptom occurred using the "DIAGNOSTIC WORK SHEET", EC-47.	GI
STEP II	Before confirming the concern, check and write down (print out using CONSULT-II) then erase the DTC (Refer to EC-33.) The DTC can be used when duplicating the incident at STEP III & IV. If the incident cannot be verified, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82. Study the relationship between the cause, specified by DTC, and the symptom described by the customer. (The "Symptom Matrix Chart" will be useful. See EC-68.) Also check related service bulletins for information.	MA EM LC
STEP III	Try to confirm the symptom and under what conditions the incident occurs. The "DIAGNOSTIC WORK SHEET" is useful to verify the incident. Connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82. If the malfunction code is detected, skip STEP IV and perform STEP V.	EC
STEP IV	Try to detect the DTC by driving in (or performing) the "DTC Confirmation Procedure". Check and read the DTC by using CONSULT-II. During the DTC verification, be sure to connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82. In case the "DTC Confirmation Procedure" is not available, perform the "Overall Function Check" instead. The DTC cannot be displayed by this check, however, this simplified "check" is an effective alternative. The "NG" result of the "Overall Function Check" is the same as the DTC detection.	FE CL MT
STEP V	Take the appropriate action based on the results of STEP I through IV. If the malfunction code is indicated, proceed to TROUBLE DIAGNOSIS FOR DTC XXXX. If the normal code is indicated, proceed to the BASIC INSPECTION. (Refer to EC-50.) Then perform inspections according to the Symptom Matrix Chart. (Refer to EC-68.)	AT PD
STEP VI	Identify where to begin diagnosis based on the relationship study between symptom and possible causes. Inspect the system for mechanical binding, loose connectors or wiring damage using (tracing) "Harness Layouts". Gently shake the related connectors, components or wiring harness with CONSULT-II set in "DATA MONITOR (AUTO TRIG)" mode. Check the voltage of the related ECM terminals or monitor the output data from the related sensors with CONSULT-II. Refer to EC-72, 76. The "Diagnostic Procedure" in EC section contains a description based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure. For details, refer to GI-23, "Circuit Inspection". Repair or replace the malfunction parts. If malfunctioning part cannot be detected, perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.	AX SU BR
STEP VII	Once you have repaired the circuit or replaced a component, you need to run the engine in the same conditions and circumstances which resulted in the customer's initial complaint. Perform the "DTC Confirmation Procedure" and confirm the normal code [DTC No. 0505] is detected. If the incident is still detected in the final check, perform STEP VI by using a different method from the previous one. Before returning the vehicle to the customer, be sure to erase the unnecessary (already fixed) DTC in ECM. (Refer to EC-33.)	ST RS BT

HA

SC

EL

IDX

TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection


Basic Inspection

NMEC0038

Precaution:

Perform Basic Inspection without electrical or mechanical loads applied;

- Headlamp switch is OFF,
- Air conditioner switch is OFF,
- Rear window defogger switch is OFF,
- Steering wheel is in the straight-ahead position, etc.

1	INSPECTION START	
<p>1. Check service records for any recent repairs that may indicate a related problem, or a current need for scheduled maintenance.</p> <p>2. Open engine hood and check the following:</p> <ul style="list-style-type: none"> ● Harness connectors for improper connections ● Vacuum hoses for splits, kinks and improper connections ● Wiring for improper connections, pinches and cuts ● Air cleaner clogging ● Hoses and ducts for leaks 		
		
<p>3. Make sure that no DTC is displayed. Refer to "Diagnostic Trouble Code (DTC)", EC-33.</p>		
OK or NG		
OK (With CONSULT-II)	▶	GO TO 2.
OK (Without CONSULT-II)	▶	GO TO 6.
NG (With CONSULT-II)	▶	1. Repair or replace. 2. GO TO 2.
NG (Without CONSULT-II)	▶	1. Repair or replace. 2. GO TO 6.

SEF983U

TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

2 CHECK FI CAM FUNCTION


Ⓟ With CONSULT-II

1. Turn ignition switch "ON".
2. Select "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	NO DTC
COOLAN TEMP/S	XXX °C

SEF013Y

3. Start engine and warm it up.
4. When engine coolant temperature is 75 to 85°C (167 to 185°F), check that mark A (Short line) on FI cam aligns with roller center.



SEC333C

OK or NG

OK	▶	GO TO 3.
NG	▶	1. Check FI cam. Refer to "Fast Idle Cam (FIC)", EC-29. 2. GO TO 3.

TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

3 CHECK IGNITION TIMING

 With CONSULT-II


1. Start engine and warm it up to normal operating temperature.
2. Select "IGNITION TIMING ADJ" in "WORK SUPPORT" mode with CONSULT-II.

IGNITION TIMING ADJ

IGNITION TIMING FEEDBACK CONTROL WILL BE HELD BY TOUCHING START.
AFTER DOING SO, ADJUST IGNITION TIMING WITH A TIMING LIGHT BY TURNING THE CAMSHAFT POSITION SENSOR.

3. Touch "START".
4. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed.
5. Check ignition timing at idle using a timing light.

PEF546N



SEF284G

Ignition timing:

M/T 15°±2° BTDC

A/T 15°±2° BTDC (in "P" or "N" position)

OK or NG

OK



GO TO 4.

NG




1. Adjust ignition timing to the specified value by turning camshaft position sensor after loosening bolts which secure camshaft position sensor.
2. GO TO 4.

TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

4	CHECK BASE IDLE SPEED																							
<p>With CONSULT-II</p> <p>1. Select "IACV-AAC/V ADJ" in "WORK SUPPORT" mode and touch "START".</p>																								
<table border="1" style="margin: auto; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">IACV-AAC/V ADJ</td></tr> <tr><td colspan="2" style="text-align: center;">ADJ MONITOR</td></tr> <tr><td style="text-align: center;">CKPS-RPM</td><td style="text-align: center;">XXX rpm</td></tr> <tr><td colspan="2" style="text-align: center;">CONDITION SETTING</td></tr> <tr><td style="text-align: center;">IACV-ACC/V</td><td style="text-align: center;">FIXED</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td colspan="2" style="text-align: center;">MONITOR</td></tr> <tr><td style="text-align: center;">COOLAN TEMP/S</td><td style="text-align: center;">XXX° C</td></tr> <tr><td style="text-align: center;">CLSD THL POS</td><td style="text-align: center;">ON</td></tr> <tr><td> </td><td> </td></tr> </table>			IACV-AAC/V ADJ		ADJ MONITOR		CKPS-RPM	XXX rpm	CONDITION SETTING		IACV-ACC/V	FIXED					MONITOR		COOLAN TEMP/S	XXX° C	CLSD THL POS	ON		
IACV-AAC/V ADJ																								
ADJ MONITOR																								
CKPS-RPM	XXX rpm																							
CONDITION SETTING																								
IACV-ACC/V	FIXED																							
MONITOR																								
COOLAN TEMP/S	XXX° C																							
CLSD THL POS	ON																							
SEC334C																								
<p>2. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed.</p> <p>3. Read idle speed.</p> <p style="color: blue;">750±50 rpm (in "P" or "N" position)</p>																								
OK or NG																								
OK (A/T models)	▶	GO TO 10.																						
OK (M/T models)	▶	GO TO 18.																						
NG	▶	GO TO 5.																						

5	ADJUST BASE IDLE SPEED	
<p>With CONSULT-II</p> <p>Adjust idle speed by turning idle speed adjust screw.</p>		
		
SEC335C		
<p style="color: blue;">750±50 rpm (in "P" or "N" position)</p>		
A/T	▶	GO TO 10.
M/T	▶	GO TO 18.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

6 CHECK FI CAM FUNCTION


⊗ Without CONSULT-II

1. Start engine and warm it up.
2. Check voltage between ECM terminal 18 (Engine coolant temperature sensor signal) and ground.



SEC325C

3. When the voltage is between 0.55 to 0.68V, check that mark A (Short line) on FI cam aligns with roller center.



SEC333C

OK or NG

OK



GO TO 7.



NG



1. Check FI cam. Refer to "Fast Idle Cam (FIC)", EC-29.
2. GO TO 7.

TROUBLE DIAGNOSIS — BASIC INSPECTION


Basic Inspection (Cont'd)


7	CHECK IGNITION TIMING	<p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Turn ignition switch "OFF". 3. Disconnect throttle position sensor harness connector. <div style="text-align: center; margin: 10px 0;">  <p style="margin: 0;">Throttle position sensor harness connector</p> <p style="margin: 0;">Throttle position switch harness connector (A/T models only)</p> </div> <ol style="list-style-type: none"> 4. Start engine. 5. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed. 6. Check ignition timing at idle using a timing light. <div style="text-align: center; margin: 10px 0;">  <p style="margin: 0;">Timing light</p> </div> <p style="margin-top: 10px;">Ignition timing: M/T 15°±2° BTDC A/T 15°±2° BTDC (in "P" or "N" position)</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p>	<p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p style="background-color: black; color: white; padding: 2px;">EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>PD</p> <p>AX</p> <p>SU</p>						
		<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; border: none;">OK</td> <td style="width: 10%; border: none; text-align: center;">▶</td> <td style="border: none;">GO TO 8.</td> </tr> <tr> <td style="border: none;">NG</td> <td style="border: none; text-align: center;">▶</td> <td style="border: none;"> <ol style="list-style-type: none"> 1. Adjust ignition timing to the specified value by turning camshaft position sensor after loosening bolts which secure camshaft position sensor. 2. GO TO 8. </td> </tr> </table>	OK	▶	GO TO 8.	NG	▶	<ol style="list-style-type: none"> 1. Adjust ignition timing to the specified value by turning camshaft position sensor after loosening bolts which secure camshaft position sensor. 2. GO TO 8. 	<p>SEF284G</p> <p>BR</p> <p>ST</p>
OK	▶	GO TO 8.							
NG	▶	<ol style="list-style-type: none"> 1. Adjust ignition timing to the specified value by turning camshaft position sensor after loosening bolts which secure camshaft position sensor. 2. GO TO 8. 							

8	CHECK BASE IDLE SPEED	<p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed. 2. Check idle speed. <p style="margin-left: 20px;">750±50 rpm (in "P" or "N" position)</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p>	<p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> <p>EL</p> <p>IDX</p>									
		<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; border: none;">OK (A/T models)</td> <td style="width: 10%; border: none; text-align: center;">▶</td> <td style="border: none;">GO TO 14.</td> </tr> <tr> <td style="border: none;">OK (M/T models)</td> <td style="border: none; text-align: center;">▶</td> <td style="border: none;">GO TO 21.</td> </tr> <tr> <td style="border: none;">NG</td> <td style="border: none; text-align: center;">▶</td> <td style="border: none;">GO TO 9.</td> </tr> </table>	OK (A/T models)	▶	GO TO 14.	OK (M/T models)	▶	GO TO 21.	NG	▶	GO TO 9.	
OK (A/T models)	▶	GO TO 14.										
OK (M/T models)	▶	GO TO 21.										
NG	▶	GO TO 9.										

TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)


9	ADJUST BASE IDLE SPEED	<p> Without CONSULT-II Adjust idle speed by turning idle speed adjust screw.</p> <div style="text-align: center;">  <p>IACV-AAC valve and IACV-FICD solenoid valve unit</p> <p>High</p> <p>Low</p> <p>Idle speed adjust screw</p> <p>Front</p> </div> <p style="color: blue;">750±50 rpm (in "P" or "N" position)</p>	SEC335C
A/T		▶	GO TO 14.
M/T		▶	GO TO 21.

10	CHECK THROTTLE POSITION SWITCH CLOSED POSITION (FOR A/T MODELS)	<p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Touch "BACK". (Cancel "IACV-AAC/V ADJ" in "WORK SUPPORT" mode.) 2. Stop engine and turn ignition switch "ON". 3. Select "A/T" and then select "CLOSED THL/SW" in "DATA MONITOR" mode with CONSULT-II. 4. Read "CLOSED THL/SW" signal under the following conditions. Insert a 0.75 mm (0.0295 in) and 0.85 mm (0.0335 in) feeler gauge alternately between stopper and throttle drum as shown in the figure and check the signal. <div style="text-align: center;">  <p>Throttle position sensor harness connector</p> <p>Throttle position switch harness connector (A/T models only)</p> </div> <div style="text-align: center; margin: 20px 0;"> <table border="1" style="border-collapse: collapse;"> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <td>MONITOR</td> <td>NO DTC</td> </tr> <tr> <td>CLOSED THL/SW</td> <td>ON</td> </tr> </table> </div> <p style="text-align: center;">OK or NG</p>	DATA MONITOR		MONITOR	NO DTC	CLOSED THL/SW	ON	SEC336C
DATA MONITOR									
MONITOR	NO DTC								
CLOSED THL/SW	ON								
			SEF059Y						
"CLSD THL/P SW" signal should remain "ON" while inserting 0.75 mm (0.0295 in) feeler gauge.									
"CLSD THL/P SW" signal should remain "OFF" while inserting 0.85 mm (0.0335 in) feeler gauge.									
OK		▶	GO TO 24.						
NG		▶	GO TO 11.						


11 ADJUST THROTTLE POSITION SWITCH CLOSED POSITION-I (FOR A/T MODELS)

Ⓟ **With CONSULT-II**

1. Loosen throttle position sensor fixing bolts.
2. Insert 0.75 mm (0.0295 in) feeler gauge between stopper and throttle drum as shown in the figure.



3. Turn throttle position sensor body counterclockwise until "CLOSED THL/SW" signal switches to "OFF".



DATA MONITOR	
MONITOR	NO DTC
CLOSED THL/SW	OFF

SEC350C

SEC351C


SEF060Y


▶ GO TO 12.

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSIS — BASIC INSPECTION



Basic Inspection (Cont'd)

12	ADJUST THROTTLE POSITION SWITCH CLOSED POSITION-II (FOR A/T MODELS)
<p> With CONSULT-II</p> <p>1. Temporarily tighten sensor body fixing bolts as follows. Gradually move the sensor body clockwise and stop it when “CLOSED THL/SW” signal switches from “OFF” to “ON”, then temporarily tighten sensor body fixing bolts.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEC351C</p> <p>2. Make sure two or three times that the signal is “ON” when the throttle valve is closed and “OFF” when it is opened. 3. Remove 0.75 mm (0.0295 in) feeler gauge then insert 0.85 mm (0.0335 in) feeler gauge. 4. Make sure two or three times that the signal remains “OFF” when the throttle valve is closed. 5. Tighten throttle position sensor. 6. Check the “CLOSED THL/SW” signal again. The signal remains “OFF” while closing throttle valve.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 13.
NG	▶ GO TO 11.

13	RESET THROTTLE POSITION SENSOR IDLE POSITION MEMORY (FOR A/T MODELS)
<p> With CONSULT-II</p> <p>NOTE: Always warm up engine to normal operating temperature. If engine is cool, the throttle position sensor idle position memory will not be reset correctly.</p> <p>1. Start engine. 2. Warm up engine to normal operating temperature. 3. Select “ENGINE” and then select “CLSD THL POS” in “DATA MONITOR” mode. 4. Stop engine. (Turn ignition switch “OFF”.) 5. Turn ignition switch “ON” and wait at least 5 seconds.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF864V</p> <p>6. Turn ignition switch “OFF” and wait at least 5 seconds. 7. Repeat steps 5 and 6 until “CLSD THL POS” signal changes to “ON”.</p>	
▶	GO TO 24.

TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

14	CHECK THROTTLE POSITION SWITCH CLOSED POSITION (FOR A/T MODELS)	
<p>⊗ Without CONSULT-II</p> <p>1. Turn ignition switch "OFF".</p> <p>2. Check continuity between closed throttle position switch terminals 4 and 5 under the following conditions.</p>		
		
		
<p>“Continuity should exist” while inserting 0.75 mm (0.0295 in) feeler gauge.</p> <p>“Continuity should not exist” while inserting 0.85 mm (0.0335 in) feeler gauge.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 24.
NG	▶	GO TO 15.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

SEF711X

SEC350C


TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)


15 ADJUST THROTTLE POSITION SWITCH CLOSED POSITION-I (FOR A/T MODELS)

⊗ Without CONSULT-II

1. Loosen throttle position sensor fixing bolts.
2. Insert 0.75 mm (0.0295 in) feeler gauge between stopper and throttle drum as shown in the figure.




SEC350C



SEF711X

3. Turn throttle position sensor body counterclockwise until "CLOSED THL/SW" signal switches to "OFF".




SEC351C




GO TO 16.

TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

16	ADJUST THROTTLE POSITION SWITCH CLOSED POSITION-II (FOR A/T MODELS)
<p>⊗ Without CONSULT-II</p> <p>1. Temporarily tighten sensor body fixing bolts as follows. Gradually move the sensor body clockwise and stop it when the continuity comes to exist, then temporarily tighten sensor body fixing bolts.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEC351C</p> <p>2. Make sure two or three times that the continuity exists when the throttle valve is closed and continuity does not exist when it is opened.</p> <p>3. Remove 0.75 mm (0.0295 in) feeler gauge then insert 0.85 mm (0.0335 in) feeler gauge.</p> <p>4. Make sure two or three times that the continuity does not exist when the throttle valve is closed.</p> <p>5. Tighten throttle position sensor.</p> <p>6. Check the continuity again. Continuity does not exist while closing the throttle valve.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 17.
NG	▶ GO TO 15.

17	RESET THROTTLE POSITION SENSOR IDLE POSITION MEMORY (FOR A/T MODELS)
<p>⊗ Without CONSULT-II</p> <p>NOTE: Always warm up engine to normal operating temperature. If engine is cool, the throttle position sensor idle position memory will not be reset correctly.</p> <p>1. Start engine. 2. Warm up engine to normal operating temperature. 3. Stop engine. (Turn ignition switch "OFF".) 4. Turn ignition switch "ON" and wait at least 5 seconds.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SEF864V</p> <p>5. Turn ignition switch "OFF" and wait at least 5 seconds. 6. Repeat steps 4 and 5, 20 times.</p>	
▶	GO TO 24.


GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

18	CHECK THROTTLE POSITION SENSOR IDLE POSITION-I (FOR M/T MODELS)								
<p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Touch "BACK". (Cancel "IACV-AAC/V ADJ" in "WORK SUPPORT" mode.) 2. Select "THRTL POS SEN" and "CLSD THL POS" in "DATA MONITOR" mode with CONSULT-II. 									
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th>NO DTC</th> </tr> </thead> <tbody> <tr> <td>THRL POS SEN</td> <td>XXXV</td> </tr> <tr> <td>CLSD THL POS</td> <td>ON</td> </tr> </tbody> </table>		DATA MONITOR		MONITOR	NO DTC	THRL POS SEN	XXXV	CLSD THL POS	ON
DATA MONITOR									
MONITOR	NO DTC								
THRL POS SEN	XXXV								
CLSD THL POS	ON								
<p>3. Check that output voltage of "THRTL POS SEN" is 0.35 to 0.65V, and "CLSD THL POS" stays "ON". (Accelerator pedal fully released.)</p>									
OK or NG									
OK	▶ GO TO 24.								
NG	▶ GO TO 19.								

SEC353C

19	ADJUST THROTTLE POSITION SENSOR IDLE POSITION (FOR M/T MODELS)
<p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Loosen throttle position sensor fixing bolts. 2. Turn throttle position sensor body clockwise or counterclockwise until "THRTL POS SEN" voltage becomes 0.35 to 0.65V. 	
	
<p>3. Tighten throttle position sensor.</p>	
▶	GO TO 20.

SEC352C

TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)


20 RESET THROTTLE POSITION SENSOR IDLE POSITION MEMORY (FOR M/T MODELS)

Ⓟ With CONSULT-II

NOTE:

Always warm up engine to normal operating temperature. If engine is cool, the throttle position sensor idle position memory will not be reset correctly.

1. Start engine.
2. Warm up engine to normal operating temperature.
3. Select "CLSD THL POS" in "DATA MONITOR" mode with CONSULT-II.
4. Stop engine. (Turn ignition switch "OFF".)
5. Turn ignition switch "ON" and wait at least 5 seconds.



6. Turn ignition switch "ON" and wait at least 5 seconds.
7. Repeat steps 5 and 6 until "CLSD THL POS" signal changes to "ON".

DATA MONITOR	
MONITOR	NO DTC
CLSD THL POS	ON

OK or NG

▶ GO TO 24.


GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


SEF864V

SEF061Y

TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

21	CHECK THROTTLE POSITION SENSOR IDLE POSITION-I (FOR M/T MODELS)
<p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none">1. Turn ignition switch "OFF".2. Connect throttle position sensor harness connector.3. Turn ignition switch "ON" and accelerator pedal fully released.4. Check voltage between ECM terminal 20 and engine ground. <div style="text-align: center;"></div> <p>Voltage: 0.35 - 0.65V</p> <p style="text-align: right;">SEC354C</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 24.
NG	▶ GO TO 22.

22	ADJUST THROTTLE POSITION SENSOR IDLE POSITION (FOR M/T MODELS)
<p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none">1. Loosen throttle position sensor fixing bolts.2. Turn throttle position sensor body clockwise or counterclockwise until voltage between ECM terminal 20 and ground becomes 0.35 to 0.65V. <div style="text-align: center;"></div> <p>3. Tighten throttle position sensor.</p>	
	▶ GO TO 23.

TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

23	RESET THROTTLE POSITION SENSOR IDLE POSITION MEMORY (FOR M/T MODELS)
<p> Without CONSULT-II</p> <p>NOTE: Always warm up engine to normal operating temperature. If engine is cool, the throttle position sensor idle position memory will not be reset correctly.</p> <ol style="list-style-type: none"> 1. Start engine. 2. Warm up engine to normal operating temperature. 3. Stop engine. (Turn ignition switch "OFF".) 4. Turn ignition switch "ON" and wait at least 5 seconds. <div style="text-align: center; margin: 10px 0;"> </div> <ol style="list-style-type: none"> 5. Turn ignition switch "OFF" and wait at least 5 seconds. 6. Repeat steps 4 and 5, 20 times. 	
▶	GO TO 24.

24	CHECK TARGET IDLE SPEED
<p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start and rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed. 2. Select "CMPS-RPM (REF)" in "DATA MONITOR" mode with CONSULT-II. 3. Read idle speed. 800±50 rpm (in "P" or "N" position) 	
<p> Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start and rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed. 2. Check idle speed. 800±50 rpm (in "P" or "N" position) <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 30.
NG	▶ GO TO 25.

25	CHECK FOR INTAKE AIR LEAK
<ol style="list-style-type: none"> 1. Start engine and let it idle. 2. Listen for an air leak from PCV hose and after IACV-AAC valve. <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 27.
NG	▶ GO TO 26.

26	REPAIR MALFUNCTION
<ol style="list-style-type: none"> 1. Stop engine. 2. Repair or replace malfunctioning part. <p style="text-align: center;">OK or NG</p>	
With CONSULT-II	▶ GO TO 3.
Without CONSULT-II	▶ GO TO 7.

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSIS — BASIC INSPECTION

Basic Inspection (Cont'd)

27	CHECK IACV-AAC VALVE CIRCUIT AND FUNCTION
Check the IACV-AAC valve circuit and function. Refer to EC-166.	
OK or NG	
OK	▶ GO TO 29.
NG	▶ GO TO 28.

28	REPAIR MALFUNCTION
Repair or replace malfunction part following the "Diagnostic Procedure" corresponding the detected malfunction.	
With CONSULT-II	▶ GO TO 3.
Without CONSULT-II	▶ GO TO 7.

29	CHECK ECM FUNCTION
1. Substitute another known-good ECM to check ECM function. (ECM may be the cause of a problem, but this is rarely the case.) 2. Perform initialization of NATS system and registration of NATS ignition key IDs. Refer to "NATS (Nissan Anti-Theft System)", EC-34.	
With CONSULT-II	▶ GO TO 3.
Without CONSULT-II	▶ GO TO 7.

30	ERASE UNNECESSARY DTC
After this inspection, unnecessary DTC might be displayed. Erase the stored memory in ECM. Refer to "HOW TO ERASE DTC", EC-33.	
▶	INSPECTION END

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Fail-safe Chart

Fail-safe Chart

=NMEC0040

The ECM enters fail-safe mode, if any of the following malfunctions is detected due to the open or short circuit. When the ECM enters the fail-safe mode of ECM, the MIL lights up.

DTC No.	Detected items	Engine operating condition in fail-safe mode	
0102	Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.	
0103	Engine coolant temperature sensor circuit	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch "ON" or "START". CONSULT-II displays the engine coolant temperature decided by ECM.	
		Condition	Engine coolant temperature decided (CONSULT-II display)
		Just as ignition switch is turned ON or Start	20°C (68°F)
		More than approx. 6 minutes after ignition ON or Start	80°C (176°F)
		Except as shown above	20 - 80°C (68 - 176°F) (Depends on the time)
0403	Throttle position sensor circuit	Throttle position will be determined based on the injected fuel amount and the engine speed. Therefore, acceleration will be poor.	
		Condition	Driving condition
		When engine is idling	Normal
		When accelerating	Poor acceleration
Unable to access ECM	ECM	ECM fail-safe activating condition The computing function of the ECM was judged to be malfunctioning. When the fail-safe system activates (i.e., if the ECM detects a malfunction condition in the CPU of ECM), the MIL on the instrument panel lights to warn the driver. However it is not possible to access ECM and DTC cannot be confirmed.	
		Engine control with fail-safe When ECM fail-safe is operating, fuel injection, ignition timing, fuel pump operation, IACV-AAC valve operation and cooling fan operation are controlled under certain limitations.	
		ECM fail-safe operation	
		Engine speed	Engine speed will not rise more than 3,000 rpm
		Fuel injection	Simultaneous multiport fuel injection system
		Ignition timing	Ignition timing is fixed at the preset valve
		Fuel pump	Fuel pump relay is "ON" when engine is running and "OFF" when engine stalls
		IACV-AAC valve	Full open
		Cooling fans	Cooling fan relay "ON" (High speed condition) when engine is running, and "OFF" when engine stalls.
		Replace ECM, if ECM fail-safe condition is confirmed.	

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Matrix Chart

Symptom Matrix Chart SYSTEM — BASIC ENGINE CONTROL SYSTEM

NMEC0041
NMEC0041S01

		SYMPTOM													Reference page
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Fuel	Fuel pump circuit	1	1	2	3	2		2	2			3		2	EC-203
	Fuel pressure regulator system	3	3	4	4	4	4	4	4	4		4			EC-28
	Injector circuit	1	1	2	3	2		2	2			2			EC-194
	Evaporative emission system														EC-22
Air	Positive crankcase ventilation system	3	3	4	4	4	4	4	4	4		4	1		EC-25
	Incorrect idle speed adjustment						1	1	1	1		1			EC-50
	IACV-AAC valve circuit	1	1	2	3	3	2	2	2	2		2		2	EC-166
Ignition	Incorrect ignition timing adjustment	3	3	1	1	1		1	1			1			EC-50
	Ignition circuit	1	1	2	2	2		2	2			2			EC-110
Main power supply and ground circuit											2				EC-83
Air conditioner circuit		2	2	3	3	3	3	3	3	3		3		2	HA section

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Matrix Chart (Cont'd)

		SYMPTOM													Reference page
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Engine control	Camshaft position sensor circuit	2	2	3	3	3		3	3			3			EC-90
	Mass air flow sensor circuit	1			2										EC-98
	Heated oxygen sensor 1 (front) circuit														EC-152
	Engine coolant temperature sensor circuit	1	1	2	3	2		2	2		3	2			EC-105
	Throttle position sensor circuit						2				2				EC-141
	Incorrect throttle position sensor adjustment		3	1		1	1	1	1	1		1			EC-50
	Vehicle speed sensor circuit		2	3		3									EC-162
	Knock sensor circuit			2									3		EC-137
	ECM	2	2	3	3	3	3	3	3	3	3				EC-67
	Start signal circuit	2													EC-199
	Park/Neutral position switch circuit			3		3							3		EC-186
	Power steering oil pressure switch circuit		2					3	3						EC-213
Electrical load signal circuit														EC-218	

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Matrix Chart (Cont'd)

SYSTEM — ENGINE MECHANICAL & OTHER

NMEC0041S02

		SYMPTOM													Reference section
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEAT/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Fuel	Fuel tank	5	5												FE section
	Fuel piping			5	5	5		5	5		5				
	Vapor lock														
	Valve deposit														
	Poor fuel (Heavy weight gasoline, Low octane)	5		5	5	5		5	5		5				
Air	Air duct														—
	Air cleaner														
	Air leakage from air duct (Mass air flow sensor — throttle body)		5	5		5		5	5		5				
	Throttle body, Throttle wire	5			5		5			5				FE section	
	Air leakage from intake manifold/Collector/Gasket													—	
Cranking	Battery	1	1	1		1		1	1			1	1	1	EL section
	Alternator circuit														
	Starter circuit	3													
	Flywheel/Drive plate	6										EM section			
	PNP switch	4										AT section			

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Matrix Chart (Cont'd)

		SYMPTOM													Reference section
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Engine	Cylinder head	5	5	5	5	5		5	5			5			EM section
	Cylinder head gasket										4	5	3		
	Cylinder block														
	Piston												4		
	Piston ring														
	Connecting rod	6	6	6	6	6		6	6			6			
	Bearing														
	Crankshaft														
Valve mechanism	Timing chain														EM section
	Camshaft	5	5	5	5	5		5	5			5			
	Intake valve												3		
	Exhaust valve														
Exhaust	Exhaust manifold/Tube/Muffler/Gasket	5	5	5	5	5	5	5		5				FE section	
	Three way catalyst														
Lubrication	Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery	5	5	5	5	5		5	5			5		MA, EM, LC section	
	Oil level (Low)/Filthy oil													LC section	
Cooling	Radiator/Hose/Radiator filler cap														EC section
	Thermostat									5					
	Water pump														
	Water gallery	5	5	5	5	5		5	5		4	5			
	Cooling fan										5				
	Coolant level (low)/Contaminated coolant													MA section	

1 - 6: The numbers refer to the order of inspection.

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Matrix Chart (Cont'd)

	SYMPTOM													Reference section
	HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
NATS (Nissan Anti-Theft System)	1	1												EC-34 or EL section

1 - 6: The numbers refer to the order of inspection.

CONSULT-II Reference Value in Data Monitor Mode

NMEC0042

Remarks:

- Specification data are reference values.
- Specification data are output/input values which are detected or supplied by the ECM at the connector.
- * Specification data may not be directly related to their components signals/values/operations.
- i.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. This IGN TIMING monitors the data calculated by the ECM according to the signals input from the camshaft position sensor and other ignition timing related sensors.
- If the real-time diagnosis results are NG and the on board diagnostic system results are OK when diagnosing the mass air flow sensor, first check to see if the fuel pump control circuit is normal.

MONITOR ITEM	CONDITION	SPECIFICATION
CMPS-RPM (REF)	<ul style="list-style-type: none"> ● Tachometer: Connect ● Run engine and compare tachometer indication with the CONSULT-II value 	Almost the same speed as the CONSULT-II value.
MAS AIR/FL SE	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load 	Idle 0.8 - 1.5V
		3,000 rpm 1.4 - 2.0V
A/F ALPHA	<ul style="list-style-type: none"> ● Engine: After warming up 	Maintaining engine speed at 2,000 rpm 75 - 125%
COOLAN TEMP/S	<ul style="list-style-type: none"> ● Engine: After warming up 	More than 70°C (158°F)
O2S1	<ul style="list-style-type: none"> ● Engine: After warming up 	0 - 0.3V ↔ Approx. 0.6 - 0.9V
M/R F/C MNT		LEAN ↔ RICH Changes more than 5 times during 10 seconds.
VHCL SPEED SE	<ul style="list-style-type: none"> ● Turn drive wheels and compare speedometer indication with the CONSULT-II value 	Almost the same speed as the CONSULT-II value.
BATTERY VOLT	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 	11 - 14V

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

CONSULT-II Reference Value in Data Monitor Mode (Cont'd)

MONITOR ITEM	CONDITION	SPECIFICATION		
THRTL POS SEN	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine ● Ignition switch: ON (Engine stopped) 	Throttle valve: fully closed	0.35 - 0.65V	GI MA
	<ul style="list-style-type: none"> ● Engine: After warming up ● Ignition switch: ON (Engine stopped) 	Throttle valve: fully opened	Approx. 4.0V	EM
START SIGNAL	<ul style="list-style-type: none"> ● Ignition switch: ON → OFF → ON 		OFF → ON → OFF	LC
CLSD THL POS	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Throttle valve: Idle position	ON	EC
		Throttle valve: Slightly open	OFF	FE
AIR COND SIG	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Air conditioner switch: "OFF"	OFF	CL
		Air conditioner switch: "ON" (Compressor operates.)	ON	MT
P/N POSI SW	<ul style="list-style-type: none"> ● Ignition switch: ON 	Shift lever: "P" or "N" (A/T models) Neutral (M/T models)	ON	AT
		Except above	OFF	PD
PW/ST SIGNAL	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Steering wheel in neutral position (forward direction)	OFF	AX
		The steering wheel is turned	ON	SU
LOAD SIGNAL	<ul style="list-style-type: none"> ● Ignition switch: ON 	Rear window defogger switch "ON" and/or lighting switch "2ND"	ON	BR
		Rear window defogger switch and lighting switch "OFF"	OFF	ST
INJ PULSE	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load 	Idle	1.7 - 2.5 msec	RS
		2,000 rpm	1.5 - 2.3 msec	BT
IGN TIMING	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load 	Idle	15° BTDC	HA
		2,000 rpm	More than 25° BTDC	SC
IACV-AAC/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load 	Idle	20 - 40%	EL
		2,000 rpm	—	IDX
W/G CONT S/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load 	Idle	0%	
		Racing up to 4,000 rpm	20%	
AIR COND RLY	<ul style="list-style-type: none"> ● Air conditioner switch: OFF → ON 		OFF → ON	
FUEL PUMP RLY	<ul style="list-style-type: none"> ● Ignition switch is turned to ON (Operates for 1 second) ● Engine running and cranking 		ON	
	Except as shown above		OFF	
INT/V TIM SOL	<ul style="list-style-type: none"> ● Lift up the vehicle ● Engine: After warming up 	Idle	OFF	
		<ul style="list-style-type: none"> ● Shift lever to any position except "P" or "N" position ● Quickly depress accelerator pedal, then quickly release it 	OFF → ON → OFF	

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

CONSULT-II Reference Value in Data Monitor Mode (Cont'd)

MONITOR ITEM	CONDITION	SPECIFICATION
COOLING FAN	<ul style="list-style-type: none"> ● After warming up engine, idle the engine. ● Air conditioner switch: "OFF" 	Engine coolant temperature is 94°C (201°F) or less
		Engine coolant temperature is between 95°C (203°F) and 100°C (212°F)
		Engine coolant temperature is 100°C (212°F) or more

Major Sensor Reference Graph in Data Monitor Mode

NMEC0043


The following are the major sensor reference graphs in "DATA MONITOR" mode.

THRTL POS SEN, CLSD THL POS

NMEC0043S01

Below is the data for "THRTL POS SEN" and "CLSD THL POS" when depressing the accelerator pedal with the ignition switch "ON".

The signal of "THRTL POS SEN" should rise gradually without any intermittent drop or rise after "CLSD THL POS" is changed from "ON" to "OFF".




SEC355C

CMPS-RPM (REF), MAS AIR/FL SE, THRTL POS SEN, O2S1, INJ PULSE

NMEC0043S02

Below is the data for "CMPS-RPM (REF)", "MAS AIR/FL SE", "THRTL POS SEN", "O2S1" and "INJ PULSE" when revving engine quickly up to 4,800 rpm under no load after warming up engine sufficiently.


Each value is for reference, the exact value may vary.




SEC356C

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION


Major Sensor Reference Graph in Data Monitor Mode (Cont'd)



- "THRTL POS SEN" should increase while depressing the accelerator pedal and should decrease while releasing it.



- "O2S1" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "INJ PULSE" should increase when depressing the accelerator pedal and should decrease when the pedal is released.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC




EL

SEC357C

IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

ECM Terminals and Reference Value



ECM Terminals and Reference Value

NMEC0044


PREPARATION

NMEC0044S01

1. ECM is located behind the dash side lower finisher LH. For this inspection, remove dash side lower cover.
2. Remove ECM harness protector.
3. Perform all voltage measurements with the connector connected. Extend tester probe as shown to perform tests easily.
 - Open harness securing clip to make testing easier.
 - Use extreme care not to touch 2 pins at one time.
 - Data is for comparison and may not be exact.

ECM HARNESS CONNECTOR TERMINAL LAYOUT

NMEC0044S02



SEF877K

ECM INSPECTION TABLE

NMEC0044S03





Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION


ECM Terminals and Reference Value (Cont'd)

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1 3 5 25	R/W BR/R R/G R/L	Ignition signal No. 1 Ignition signal No. 2 Ignition signal No. 3 Ignition signal No. 4	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	0 - 0.2V★ 
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0.1 - 1.0V★ 
2	L/OR	Tachometer	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 1.0V★ 
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	Approximately 1.5V★ 
4	R/B	ECM relay (Self shut-off)	[Engine is running] [Ignition switch "OFF"] <ul style="list-style-type: none"> ● For a few seconds after turning ignition switch "OFF" 	0 - 1.5V
			[Ignition switch "OFF"] <ul style="list-style-type: none"> ● A few seconds passed after turning ignition switch "OFF" 	BATTERY VOLTAGE (11 - 14V)
6 13	B B	ECM ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Engine ground
7	BR/Y	Data link connector	[Ignition switch "ON"] <ul style="list-style-type: none"> ● CONSULT-II is connected and turn "ON". 	Approximately 0V
9	P/B	Cooling fan relay (Low)	[Engine is running] <ul style="list-style-type: none"> ● Cooling fan is operating. 	0 - 1.0V
			[Engine is running] <ul style="list-style-type: none"> ● Cooling fan is not operating. 	BATTERY VOLTAGE (11 - 14V)

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX






TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

ECM Terminals and Reference Value (Cont'd)

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
10	L/G	Cooling fan relay (High)	[Engine is running] ● Cooling fan is operating at high speed.	0 - 1.0V
			[Engine is running] ● Cooling fan is operating.	BATTERY VOLTAGE (11 - 14V)
11	G	Air conditioner relay	[Engine is running] ● Both A/C switch and blower fan switch are "ON" (Compressor is operating).	0 - 1.0V
			[Engine is running] ● A/C switch is "OFF".	BATTERY VOLTAGE (11 - 14V)
12	PU/W	A/T signal No. 3	[Engine is running] ● Idle speed	0 - 0.1V
15	SB	Data link connector	[Ignition switch "ON"] ● CONSULT-II is connected and turn "ON".	3 - 9V
16	L	Mass air flow sensor	[Engine is running] ● Warm-up condition ● Idle speed	0.8 - 1.5V
			[Engine is running] ● Warm-up condition ● Engine speed is 3,000 rpm.	1.4 - 2.0V
17	P	Mass air flow sensor ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
18	P/B	Engine coolant tem- perature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with engine coolant temperature.
19	W	Heated oxygen sensor 1 (front)	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)
				 <p style="text-align: right;">SEC363C</p>
20	R	Throttle position sensor	[Engine is running] ● Warm-up condition ● Accelerator pedal fully released	0.15 - 0.85V
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	3.5 - 4.7V
21	GY	Sensor's ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
23	G/R	Data link connector	[Ignition switch "ON"] ● CONSULT-II is connected and turn "ON".	Approximately 0V
24	OR	Malfunction indicator lamp	[Ignition switch "ON"]	0 - 1.0V
			[Engine is running] ● Idle speed	BATTERY VOLTAGE (11 - 14V)
27	W	Knock sensor	[Engine is running] ● Idle speed	Approximately 2.5V



TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

ECM Terminals and Reference Value (Cont'd)

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	
28	R/Y	Throttle position sensor signal output	[Engine is running] ● Warm-up condition ● Accelerator pedal fully released	Approximately 0.4V	GI
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	Approximately 3.0V	MA EM
30	B/Y	Camshaft position sensor (Position signal)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 2.5V 	LC
			[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	Approximately 2.4V 	EC FE CL MT AT
31	LG	Camshaft position sensor (Reference signal)	[Engine is running] ● Warm-up condition ● Idle speed	0.4 - 0.8V 	PD
			[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	Approximately 0.6V 	AX SU BR ST RS
32	W/PU	Vehicle speed sensor	[Engine is running] ● Lift up the vehicle ● Vehicle speed is 40 km/h (25 MPH).	2.0 - 3.0V 	BT HA SC
33	PU (With A/T) G/R (With M/T)	Electrical load signal (Headlamp and Rear defogger)	[Engine is running] ● Lighting switch is "2ND" and/or rear defogger switch is "ON".	BATTERY VOLTAGE (11 - 14V)	EL
			[Engine is running] ● Lighting switch and rear defogger switch are "OFF".	Approximately 0V	IDX




TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

ECM Terminals and Reference Value (Cont'd)

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
34	OR/L	Start signal	[Ignition switch "ON"]	Approximately 0V
			[Ignition switch "START"]	9 - 12V
35	R/G (With A/T) G/OR (With M/T)	PNP switch	[Ignition switch "ON"] ● Selector lever "P" or "N" position	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"] ● Except the above position	Approximately 0V
36	B/R	Ignition switch	[Ignition switch "OFF"]	Approximately 0V
			[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
37	LG/R	Sensor's power supply	[Ignition switch "ON"]	Approximately 5V
38 47	B/W B/W	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
39 48	B B	ECM ground	[Engine is running] ● Idle speed	Engine ground
41	L/B	Air conditioner switch	[Engine is running] ● Both A/C switch and blower fan switch are "ON" (Compressor is operating).	0 - 1.0V
			[Engine is running] ● A/C switch is "OFF".	BATTERY VOLTAGE (11 - 14V)
43	PU/W	Power steering oil pressure switch	[Engine is running] ● Steering wheel is fully turned.	Approximately 0V
			[Engine is running] ● Steering wheel is not turned.	Approximately 5V
44	L/W	A/T signal No. 2	[Engine is running] ● Idle speed	6 - 8V
45	L/OR	A/T signal No. 1	[Engine is running] ● Idle speed	6 - 8V
46 109	W W	Power supply for ECM (Back-up)	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)
101 103 110 112	W/G G/B L/R L/B	Injector No. 1 Injector No. 3 Injector No. 2 Injector No. 4	[Engine is running] ● Warm-up condition ● Idle speed	BATTERY VOLTAGE (11 - 14V)  SEC369C
			[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	BATTERY VOLTAGE (11 - 14V)  SEC371C

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

ECM Terminals and Reference Value (Cont'd)

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	GI
105	R/L	Intake valve timing control solenoid valve	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	BATTERY VOLTAGE (11 - 14V)	MA
			[Engine is running] <ul style="list-style-type: none"> ● Lift up the vehicle. ● Shift lever to any position except "P" or "N" position ● Engine speed 2,000 rpm 	0 - 1.0V	EM
106	B/P	Fuel pump relay	[Ignition switch "ON"] <ul style="list-style-type: none"> ● For 1 second after turning ignition switch "ON" 	0 - 1.0V	LC
			[Engine is running] <ul style="list-style-type: none"> ● More than 1 second after turning ignition switch "ON" 	BATTERY VOLTAGE (11 - 14V)	EC
107 108 116	B B B	ECM ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Engine ground	FE CL
111	B/R	Heated oxygen sensor 1 heater (front)	[Engine is running] <ul style="list-style-type: none"> ● Engine speed is below 4,400 rpm. 	Approximately 0V	MT
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 4,400 rpm. 	BATTERY VOLTAGE (11 - 14V)	AT
113	SB	IACV-AAC valve	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 10V  SEC372C	PD AX
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed ● Both A/C switch and blower fan switch are "ON" (Compressor is operating). ● Rear window defogger switch is "ON" 	Approximately 11V  SEC373C	SU BR ST
115	OR/B	Wastegate valve control solenoid valve	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	BATTERY VOLTAGE (11 - 14V)	RS
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm. 	BATTERY VOLTAGE (11 - 14V)  SEC374C	BT HA SC EL

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

IDX

TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT

Description

Description

NMEC0045

Intermittent incidents (I/I) may occur. In many cases, the problem resolves itself (the part or circuit function returns to normal without intervention). It is important to realize that the symptoms described in the customer's complaint often do not recur on DTC visits. Realize also that the most frequent cause of I/I occurrences is poor electrical connections. Because of this, the conditions under which the incident occurred may not be clear. Therefore, circuit checks made as part of the standard diagnostic procedure may not indicate the specific problem area.

COMMON I/I REPORT SITUATIONS

NMEC0045S01

STEP in Work Flow	Situation
II	The CONSULT-II is used. The SELF-DIAG RESULTS screen shows time data other than "0".
III	The symptom described by the customer does not recur.
IV	DTC does not appear during the DTC Confirmation Procedure.
VI	The Diagnostic Procedure for XXXX does not indicate the problem area.

Diagnostic Procedure

NMEC0046

1	INSPECTION START
Erase DTCs. Refer to "HOW TO ERASE DTC", EC-33.	
▶	GO TO 2.

2	CHECK GROUND TERMINALS
Check ground terminals for corroding or loose connection. Refer to GI-26, "GROUND INSPECTION".	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Repair or replace.

3	SEARCH FOR ELECTRICAL INCIDENT
Perform GI-21, "Incident Simulation Tests".	
OK or NG	
OK	▶ INSPECTION END
NG	▶ Repair or replace.


TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit


Main Power Supply and Ground Circuit WIRING DIAGRAM

NMEC0661


EC-MAIN-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



REFER TO THE FOLLOWING.
 (E101), (F4) -SUPER
 MULTIPLE JUNCTION (SMJ)
 (M7), (E104) -FUSE BLOCK-
 JUNCTION BOX (J/B)



TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit (Cont'd)

ECM TERMINALS AND REFERENCE VALUE

NMEC0662

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
4	R/B	ECM relay (Self shut-off)	[Engine is running] [Ignition switch "OFF"] ● For a few seconds after turning ignition switch "OFF"	0 - 1V
			[Ignition switch "OFF"] ● A few seconds passed after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
6 13	B B	ECM ground	[Engine is running] ● Idle speed	Engine ground
36	B/R	Ignition switch	[Ignition switch "OFF"]	0V
			[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
38 47	B/W B/W	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
39 48	B B	ECM ground	[Engine is running] ● Idle speed	Engine ground
46	W	Power supply for ECM (Back-up)	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)
107 108 116	B B B	ECM ground	[Engine is running] ● Idle speed	Engine ground
109	W	Current return	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)


DIAGNOSTIC PROCEDURE

NMEC0663

1	INSPECTION START	
Start engine. Is engine running?		
Yes or No		
Yes	▶	GO TO 8.
No	▶	GO TO 2.

TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit (Cont'd)



2	CHECK ECM POWER SUPPLY CIRCUIT-I		
		<p>1. Turn ignition switch "OFF" and then "ON". 2. Check voltage between ECM terminal 36 and ground with CONSULT-II or tester.</p>  <p style="text-align: right;">Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p>	<p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p style="background-color: black; color: white; text-align: center;">EC</p> <p>FE</p> <p>CL</p>
	OK	▶	GO TO 4.
	NG	▶	GO TO 3.

3	DETECT MALFUNCTIONING PART		
		<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M60, F4 ● Fuse block (J/B) connector M7, E104 ● 10A fuse ● Harness for open or short between ECM and ignition switch 	<p>MT</p> <p>AT</p> <p>PD</p>
		▶	Repair harness or connectors.

4	CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-I		
		<p>1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminals 6, 13, 39, 48, 107, 108, 116 and engine ground. Refer to WIRING DIAGRAM. Continuity should exist. 4. Also check harness for short to power.</p> <p style="text-align: center;">OK or NG</p>	<p>AX</p> <p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> <p>EL</p> <p>IDX</p>
	OK	▶	GO TO 5.
	NG	▶	Repair open circuit or short to power in harness or connectors.

TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit (Cont'd)

5	CHECK POWER SUPPLY-II
<p>1. Disconnect ECM relay.</p> <div style="text-align: center;"> <p>View with dash side lower finisher LH and ECM removed</p>  </div>	
<p>2. Check voltage between ECM relay terminals 1, 7 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p>Voltage: Battery voltage</p> </div> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 7.
NG	▶ GO TO 6.

SEC376C


SEC402C

6	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● 10A fuses ● Harness connectors E101, M10 ● Harness connectors M60, F4 ● Harness for open or short between ECM relay and battery 	
▶ Repair open circuit or short to ground or short to power in harness or connectors.	


7	CHECK OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT
<p>1. Check harness continuity between ECM terminal 4 and ECM relay terminal 2. Continuity should exist.</p> <p>2. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ Go to "DTC 0201 IGNITION SIGNAL", EC-110.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit (Cont'd)

8	CHECK ECM POWER SUPPLY CIRCUIT-II	<p>1. Stop engine. 2. Check voltage between ECM terminals 46, 109 and ground with CONSULT-II or tester.</p> <div style="text-align: center; margin: 10px 0;">  <p style="margin-left: 100px;">Voltage: Battery voltage</p> </div> <p style="text-align: right; margin-right: 20px;">SEC403C</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p>	GI MA EM LC EC	
	OK	▶	GO TO 10.	FE
	NG	▶	GO TO 9.	CL



9	DETECT MALFUNCTIONING PART	<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M60, F4 ● Harness for open or short between ECM and harness connector F4 	MT AT	
		▶	Repair harness or connectors.	PD

10	CHECK ECM POWER SUPPLY CIRCUIT-III	<p>1. Turn ignition switch "ON" and then "OFF". 2. Check voltage between ECM terminals 38, 47 and ground with CONSULT-II or tester.</p> <div style="text-align: center; margin: 10px 0;">  <p style="margin-left: 100px;">Voltage: After turning ignition switch "OFF", battery voltage will exist for a few seconds, then drop approximately 0V.</p> </div> <p style="text-align: right; margin-right: 20px;">SEC404C</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p>	AX SU BR ST RS	
	OK	▶	GO TO 15.	BT
	NG (Battery voltage does not exist.)	▶	GO TO 11.	HA
	NG (Battery voltage exists for more than a few seconds.)	▶	GO TO 13.	SC

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit (Cont'd)


11	CHECK ECM POWER SUPPLY CIRCUIT-IV						
<p>1. Disconnect ECM relay.</p> <div style="text-align: center;">  <p>View with dash side lower finisher LH and ECM removed</p> <p>ECM relay</p> </div> <p style="text-align: right;">SEC376C</p> <p>2. Check voltage between ECM relay terminal 5 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p>Voltage: Battery voltage</p> <p style="text-align: right;">SEC405C</p> </div> <p style="text-align: center;">OK or NG</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 13.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 12.</td> </tr> </table>		OK	▶	GO TO 13.	NG	▶	GO TO 12.
OK	▶	GO TO 13.					
NG	▶	GO TO 12.					

12	DETECT MALFUNCTIONING PART			
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness for open or short between ECM relay and harness connector F4 <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%;"></td> <td style="width: 10%; text-align: center;">▶</td> <td>Repair open circuit or short to ground or short to power in harness or connectors.</td> </tr> </table>			▶	Repair open circuit or short to ground or short to power in harness or connectors.
	▶	Repair open circuit or short to ground or short to power in harness or connectors.		

13	CHECK HARNESS CONTINUITY BETWEEN ECM RELAY AND ECM FOR OPEN AND SHORT						
<p>1. Check harness continuity between ECM terminals 38, 47 and ECM relay terminal 3. Refer to WIRING DIAGRAM. Continuity should exist.</p> <p>2. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%;">OK</td> <td style="width: 10%; text-align: center;">▶</td> <td>GO TO 14.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Repair open circuit or short to ground or short to power in harness or connectors.</td> </tr> </table>		OK	▶	GO TO 14.	NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.
OK	▶	GO TO 14.					
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.					

TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit (Cont'd)

14	CHECK ECM RELAY							
<ol style="list-style-type: none"> 1. Apply 12V direct current between ECM relay terminals 1 and 2. 2. Check continuity between relay terminals 3 and 5, 6 and 7. 								
								
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Continuity</th> </tr> </thead> <tbody> <tr> <td>12V direct current supply between terminals 1 and 2</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td>OFF</td> <td style="text-align: center;">No</td> </tr> </tbody> </table>			Condition	Continuity	12V direct current supply between terminals 1 and 2	Yes	OFF	No
Condition	Continuity							
12V direct current supply between terminals 1 and 2	Yes							
OFF	No							
SEF296X								
OK or NG								
OK	▶	GO TO 15.						
NG	▶	Replace ECM relay.						



15	CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-II	
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminals 6, 13, 39, 48, 107, 108, 116 and engine ground. Refer to WIRING DIAGRAM. Continuity should exist. 4. Also check harness for short to power. 		
OK or NG		
OK	▶	GO TO 16.
NG	▶	Repair open circuit or short to power in harness or connectors.

16	CHECK INTERMITTENT INCIDENT	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.		
▶		INSPECTION END

GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC 0101 CAMSHAFT POSITION SENSOR (CMPS)

Component Description



Component Description

NMEC0664

The camshaft position sensor is a basic component of the engine control system. It monitors engine speed and piston position. These input signals to the engine control system are used to control fuel injection, ignition timing and other functions.

The camshaft position sensor has a rotor plate and a wave-forming circuit. The rotor plate has 360 slits for a 1° (POS) signal and 4 slits for a 180° (REF) signal. The wave-forming circuit consists of Light Emitting Diodes (LED) and photo diodes.

The rotor plate is positioned between the LED and the photo diode. The LED transmits light to the photo diode. As the rotor plate turns, the slits cut the light to generate rough-shaped pulses. These pulses are converted into on-off signals by the wave-forming circuit and sent to the ECM.

The distributor is not repairable and must be replaced as an assembly except distributor cap and rotor head.

ECM Terminals and Reference Value

NMEC0665

Specification data are reference values and are measured between each terminal and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
31	LG	Camshaft position sensor (Reference signal)	<p>[Engine is running]</p> <ul style="list-style-type: none"> • Warm-up condition • Idle speed 	<p>0.4 - 0.8V</p> <p>SEC366C</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> • Engine speed is 2,000 rpm 	<p>Approximately 0.6V</p> <p>SEC367C</p>

DTC 0101 CAMSHAFT POSITION SENSOR (CMPS)

ECM Terminals and Reference Value (Cont'd)

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
30	B/Y	Camshaft position sensor (Position signal)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 2.5V  SEC364C
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	Approximately 2.4V  SEC365C

On Board Diagnosis Logic

NMEC0666

DTC No.	Malfunction is detected when ...		Check Items (Possible Cause)
0101	A)	Either 1° or 180° signal is not sent to ECM for the first few seconds during engine cranking.	<ul style="list-style-type: none"> ● Harness or connectors (The camshaft position sensor circuit is open or shorted.) ● Camshaft position sensor ● Starter motor (Refer to SC-12, "STARTING SYSTEM".) ● Starting system circuit (Refer to SC-12, "STARTING SYSTEM".) ● Dead (Weak) battery
	B)	Either 1° or 180° signal is not sent to ECM often enough while the engine speed is higher than the specified engine speed.	
	C)	The relation between 1° and 180° signal is not in the normal range during the specified engine speed.	

DTC Confirmation Procedure

NMEC0667

Perform "Procedure for malfunction A" first. If DTC cannot be confirmed, perform "Procedure for malfunction B and C".

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V.

2	DATA MONITOR	
	MONITOR	NO DTC
	CMPS-RPM (REF) XXX rpm	

SEC447C

PROCEDURE FOR MALFUNCTION A

NMEC0667S01

Ⓜ With CONSULT-II

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Crank engine for at least 2 seconds.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-94.

ⓧ Without CONSULT-II

- 1) Crank engine for at least 2 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".

DTC 0101 CAMSHAFT POSITION SENSOR (CMPS)

DTC Confirmation Procedure (Cont'd)

- 3) Perform "Diagnostic Test Mode II" (Self-diagnostic results) with ECM.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-94.

3	DATA MONITOR	
	MONITOR	NO DTC
	CMPS-RPM (REF) XXX rpm	

SEC447C

PROCEDURE FOR MALFUNCTION B AND C

NMEC0667S02

With CONSULT-II

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and run it for at least 2 seconds at idle speed.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-94.

Without CONSULT-II

- 1) Start engine and run it for at least 2 seconds at idle speed.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II" (Self-diagnostic results) with ECM.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-94.



DTC 0101 CAMSHAFT POSITION SENSOR (CMPS)

Wiring Diagram


Wiring Diagram

NMEC0668

EC-CMPS-01



REFER TO THE FOLLOWING.
(E101), (F4) -SUPER
MULTIPLE JUNCTION (SMJ)



TEC799


DTC 0101 CAMSHAFT POSITION SENSOR (CMPS)

Diagnostic Procedure

Diagnostic Procedure



NMEC0669

1	CHECK STARTING SYSTEM
Does the engine turn over? (Does the starter motor operate?)	
Yes or No	
Yes	▶ GO TO 2.
No	▶ Check starting system. (Refer to SC-12, "STARTING SYSTEM".)

2	RETIGHTEN GROUND SCREWS
1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws.	
 <p>The diagram is a technical line drawing of an engine compartment. It shows various components including hoses, wires, and metal parts. Two specific areas are highlighted with circles and labels: 'Engine ground.' and 'Intake manifold collector'. The 'Engine ground.' label points to a bolt on a metal surface. The 'Intake manifold collector' label points to a curved metal part. The drawing is oriented vertically on the page.</p>	
SEC377C	
▶	GO TO 3.

DTC 0101 CAMSHAFT POSITION SENSOR (CMPS)

Diagnostic Procedure (Cont'd)

3	CHECK POWER SUPPLY		
		<p>1. Disconnect camshaft position sensor (CMPS) harness connector.</p>  <p style="text-align: right;">SEC378C</p> <p>2. Turn ignition switch "ON".</p> <p>3. Check voltage between CMPS terminal 2 and ground with CONSULT-II or tester.</p>  <p style="text-align: right;">SEC406C</p> <p>Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p>	<p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p>EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>PD</p>
	OK	▶	GO TO 5.
	NG	▶	GO TO 4.

4	DETECT MALFUNCTIONING PART		
		<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness for open or short between CMPS and ECM relay ● Harness for open or short between CMPS and ECM <p style="text-align: right;">▶ Repair open circuit or short to ground or short to power in harness or connectors.</p>	<p>SU</p> <p>BR</p> <p>ST</p>

5	CHECK INPUT SIGNAL CIRCUIT		
		<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect ECM harness connector.</p> <p>3. Check harness continuity between CMPS terminal 3 and ECM terminal 30, CMPS terminal 4 and ECM terminal 31. Refer to Wiring Diagram.</p> <p style="color: blue;">Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	<p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> <p>EL</p> <p>IDX</p>
	OK	▶	GO TO 6.
	NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

DTC 0101 CAMSHAFT POSITION SENSOR (CMPS)

Diagnostic Procedure (Cont'd)

6		CHECK GROUND CIRCUIT
1. Turn ignition switch "OFF". 2. Check harness continuity between CMPS terminal 1 and engine ground. Refer to Wiring Diagram. Continuity should exist. 3. Also check harness for short to power.		
OK or NG		
OK	▶	GO TO 7.
NG	▶	Repair open circuit or short to power in harness or connectors.

7		CHECK CAMSHAFT POSITION SENSOR
Refer to "Component Inspection", EC-97.		
OK or NG		
OK	▶	GO TO 8.
NG	▶	Replace camshaft position sensor.


8		CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.		
	▶	INSPECTION END

DTC 0101 CAMSHAFT POSITION SENSOR (CMPS)

Component Inspection

=NMEC0670

NMEC0670S01



Component Inspection CAMSHAFT POSITION SENSOR

1. Start engine and warm it up to normal operating temperature.
2. Check voltage between ECM terminals 30, 31 and engine ground under the following conditions.

Terminal 31 and engine ground

Condition	Idle	2,000 rpm
Voltage	0.4 - 0.8V	Approximately 0.6V
Pulse signal	<p>SEC366C</p>	<p>SEC367C</p>

Terminal 30 and engine ground


Condition	Idle	2,000 rpm
Voltage	Approximately 2.5V	Approximately 2.4V
Pulse signal	<p>SEC364C</p>	<p>SEC365C</p>

If NG, replace camshaft position sensor.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC 0102 MASS AIR FLOW SENSOR (MAFS)

Component Description



Component Description

NMEC0671

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot wire that is supplied with electric current from the ECM. The temperature of the hot wire is controlled by the ECM a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The more air, the greater the heat loss.

Therefore, the ECM must supply more electric current to maintain the temperature of the hot wire as air flow increases. The ECM detects the air flow by means of this current change.

CONSULT-II Reference Value in Data Monitor Mode

NMEC0672

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MAS AIR/FL SE	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load 	Idle	0.8 - 1.5V
		3,000 rpm	1.4 - 2.0V

ECM Terminals and Reference Value

NMEC0673

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
16	L	Mass air flow sensor	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	0.8 - 1.5V
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 3,000 rpm 	1.4 - 2.0V
17	P	Mass air flow sensor ground	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V

On Board Diagnosis Logic

NMEC0674

DTC No.	Malfunction is detected when ...		Check Items (Possible Cause)
0102	A)	An excessively high voltage from the sensor is sent to ECM when engine is not running.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Mass air flow sensor
	B)	An excessively low voltage from the sensor is sent to ECM* when engine is running.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Intake air leaks ● Mass air flow sensor

*: When this malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Fail-safe Mode

NMEC0675

Detected items	Engine operating condition in fail-safe mode	
Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.	GI MA EM LC EC

DTC Confirmation Procedure


NMEC0676

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.



PROCEDURE FOR MALFUNCTION A


NMEC0676S01

☑ With CONSULT-II

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 5 seconds.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-102.

☒ Without CONSULT-II

- 1) Turn ignition switch "ON", and wait at least 5 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-102.



PROCEDURE FOR MALFUNCTION B

NMEC0676S02

☑ With CONSULT-II

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and wait at least 2 seconds.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-102.

☒ Without CONSULT-II

- 1) Start engine and wait at least 2 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".

DTC 0102 MASS AIR FLOW SENSOR (MAFS)

DTC Confirmation Procedure (Cont'd)

- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-102.



DTC 0102 MASS AIR FLOW SENSOR (MAFS)

Wiring Diagram


Wiring Diagram

NMEC0677

EC-MAFS-01



REFER TO THE FOLLOWING.
E101, F4 -SUPER
MULTIPLE JUNCTION (SMJ)



TEC800

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC 0102 MASS AIR FLOW SENSOR (MAFS)


Diagnostic Procedure

Diagnostic Procedure

NMEC0678



1	INSPECTION START
Which malfunction (A, or B) is duplicated?	
Malfunction A or B	
A	▶ GO TO 3.
B	▶ GO TO 2.

2	CHECK INTAKE SYSTEM
Check the following for connection.	
<ul style="list-style-type: none">● Air duct● Vacuum hoses● Intake air passage between air duct to collector	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Reconnect the parts.

3	RETIGHTEN GROUND SCREWS
1. Turn ignition switch "OFF". 2. Loosen and retighten engine ground screws.	
 <p>The diagram is a technical line drawing of an engine compartment. It shows the intake manifold collector and the engine ground screws. A hand is shown using a screwdriver to adjust one of the ground screws. Labels with arrows point to the 'Engine ground' and 'Intake manifold collector'.</p>	
SEC377C	
▶	GO TO 4.

DTC 0102 MASS AIR FLOW SENSOR (MAFS)

Diagnostic Procedure (Cont'd)

4	CHECK POWER SUPPLY		
		<p>1. Disconnect mass air flow sensor harness connector.</p>  <p style="text-align: right;">SEC378C</p> <p>2. Turn ignition switch "ON".</p> <p>3. Check voltage between terminal 3 and ground with CONSULT-II or tester.</p>  <p style="text-align: center;">OK or NG</p> <p style="text-align: right;">SEC408C</p>	<p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p>EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>PD</p>
	OK	▶	GO TO 6.
	NG	▶	GO TO 5.

5	DETECT MALFUNCTIONING PART		
		<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness for open or short between ECM relay and mass air flow sensor ● Harness for open or short between mass air flow sensor and ECM <p style="text-align: right;">Repair harness or connectors.</p>	<p>SU</p> <p>BR</p> <p>ST</p>

6	CHECK GROUND CIRCUIT		
		<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect ECM harness connector.</p> <p>3. Check harness continuity between mass air flow sensor terminal 2 and ECM terminal 17. Refer to wiring diagram. Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	<p>RS</p> <p>BT</p> <p>HA</p>
	OK	▶	GO TO 7.
	NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

SC

EL

IDX



DTC 0102 MASS AIR FLOW SENSOR (MAFS)

Diagnostic Procedure (Cont'd)

7	CHECK INPUT SIGNAL CIRCUIT
1. Check harness continuity between mass air flow sensor terminal 1 and ECM terminal 16. Refer to wiring diagram. Continuity should exist.	
2. Also check harness for short to ground and short to power.	
OK or NG	
OK	▶ GO TO 8.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

8	CHECK MASS AIR FLOW SENSOR
Refer to "Component Inspection", EC-104.	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Replace mass air flow sensor.

9	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.	
INSPECTION END	



Component Inspection MASS AIR FLOW SENSOR

NMEC0679

NMEC0679S01

1. Turn ignition switch "ON".
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 16 (Mass air flow sensor signal) and ground.



Conditions	Voltage V
Ignition switch "ON" (Engine stopped.)	Less than 1.2
Idle (Engine is warmed-up to normal operating temperature.)	0.8 - 1.5
3,000 rpm (Engine is warmed-up to normal operating temperature.)	1.4 - 2.0
Idle to about 4,000 rpm*	0.8 - 1.5 to Approx. 4.0

*: Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.

4. If the voltage is out of specification, disconnect mass air flow sensor harness connector and connect it again. Repeat above check.
5. If NG, remove mass air flow sensor from air duct. Check hot wire for damage or dust.

DTC 0103 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)

Component Description



Component Description

NMEC0680

The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.

<Reference data>

Engine coolant temperature °C (°F)	Voltage* mV	Resistance kΩ
-10 (14)	222	7.0 - 11.4
20 (68)	176	2.1 - 2.9
50 (122)	114	0.68 - 1.00
90 (194)	47	0.236 - 0.260
110 (230)	32	0.143 - 0.153
150 (302)	16	0.050 - 0.065

*: These data are reference values and are measured between ECM terminal 18 (Engine coolant temperature sensor) and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

CONSULT-II Reference Value in Data Monitor Mode

NMEC0681

MONITOR ITEM	CONDITION	SPECIFICATION
COOLAN TEMP/S	● Engine: After warming up	More than 70°C (158°F)

On Board Diagnosis Logic

NMEC0682

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
0103	● An excessively high or low voltage from the sensor is sent to ECM.*	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Engine coolant temperature sensor

*: When this malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.


DTC 0103 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)

Fail-safe Mode

Fail-safe Mode

NMEC0683

Detected items	Engine operating condition in fail-safe mode	
Engine coolant temperature sensor circuit	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch "ON" or "START". CONSULT-II displays the engine coolant temperature decided by ECM.	
	Condition	Engine coolant temperature decided (CONSULT-II display)
	Just as ignition switch is turned ON or Start	20°C (68°F)
	More than approx. 6 minutes after ignition ON or Start	80°C (176°F)
	Except as shown above	20 - 80°C (68 - 176°F) (Depends on the time)
When the fail-safe system for engine coolant temperature sensor is activated, the cooling fan operates while the engine is running.		



DTC Confirmation Procedure

NMEC0684

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

Ⓜ With CONSULT-II

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 5 seconds.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-108 .

ⓧ Without CONSULT-II

- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-108.


DTC 0103 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)

Wiring Diagram


Wiring Diagram

NMEC0685

EC-ECTS-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



REFER TO THE FOLLOWING.
 (F4) -SUPER MULTIPLE JUNCTION (SMJ)



TEC801

DTC 0103 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)

Diagnostic Procedure

Diagnostic Procedure

NMEC0686

1	CHECK POWER SUPPLY
<p>1. Turn ignition switch "OFF". 2. Disconnect engine coolant temperature sensor harness connector.</p> <div style="text-align: center;"> <p>View with intake air duct removed</p>  <p>Throttle body Engine coolant temperature sensor</p> </div> <p>3. Turn ignition switch "ON". 4. Check voltage between terminal 2 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p>Voltage: Approximately 5V</p> <p>OK or NG</p> </div>	
OK	▶ GO TO 3.
NG	▶ GO TO 2.

SEC379C

SEF690U

2	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F27, F111 ● Harness for open or short between ECM and engine coolant temperature sensor 	
▶	Repair harness or connectors.

3	CHECK GROUND CIRCUIT
<p>1. Turn ignition switch "OFF". 2. Check harness continuity between engine coolant temperature sensor terminal 1 and engine ground. Refer to wiring diagram. Continuity should exist. 3. Also check harness for short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 5.
NG	▶ GO TO 4.


DTC 0103 ENGINE COOLANT TEMPERATURE SENSOR (ECTS) (CIRCUIT)

Diagnostic Procedure (Cont'd)

4	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none"> ● Harness connectors F27, F111 ● Harness connectors F4, M60 ● Harness for open or short between ECM and engine coolant temperature sensor ● Harness for open or short between engine coolant temperature sensor and TCM (Transmission Control Module) 	
▶	Repair open circuit or short to power in harness or connectors.

5	CHECK ENGINE COOLANT TEMPERATURE SENSOR
Refer to "Component Inspection", EC-109.	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Replace engine coolant temperature sensor.

6	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.	
▶	INSPECTION END




Component Inspection

ENGINE COOLANT TEMPERATURE SENSOR

NMEC0687
NMEC0687S01

Check resistance as shown in the figure.
<Reference data>

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260




If NG, replace engine coolant temperature sensor.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC 0201 IGNITION SIGNAL

Component Description



Component Description

IGNITION COIL & POWER TRANSISTOR

NMEC0688

NMEC0688S01

The ignition signal from the ECM is sent to and amplified by the power transistor. The power transistor turns on and off the ignition coil primary circuit. This on-off operation induces the proper high voltage in the coil secondary circuit.

CONSULT-II Reference Value in Data Monitor Mode

NMEC0689

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
IGN TIMING	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	15°±2° BTDC
		2,000 rpm	More than 25° BTDC

ECM Terminals and Reference Value

NMEC0690

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1 3 5 25	R/W BR/R R/G R/L	Ignition signal (No. 1) Ignition signal (No. 2) Ignition signal (No. 3) Ignition signal (No. 4)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>0 - 0.2V</p> <p>SEC359C</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>0.1 - 1.0V</p> <p>SEC360C</p>

On Board Diagnosis Logic

NMEC0691

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
0201	<ul style="list-style-type: none"> ● The ignition signal in the primary circuit is not sent to ECM during engine cranking or running. 	<ul style="list-style-type: none"> ● Harness or connectors (The ignition primary circuit is open or shorted.) ● Power transistor unit built into ignition coil ● Condenser ● Camshaft position sensor ● Camshaft position sensor circuit

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



DTC Confirmation Procedure

NMEC0692

NOTE:

- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.
- **If DTC 0201 is displayed with DTC 0101, perform trouble diagnosis for DTC 0101 first. Refer to EC-90.**

Ⓟ WITH CONSULT-II

NMEC0692S01

- 1) Turn ignition switch “ON”.
- 2) Select “DATA MONITOR” mode with CONSULT-II.
- 3) Start engine. (If engine does not run, turn ignition switch to “START” for at least 5 seconds.)
- 4) If DTC is detected, go to “Diagnostic Procedure”, EC-114.

ⓧ WITHOUT CONSULT-II

NMEC0692S02

- 1) Turn ignition switch “ON”.
- 2) Start engine. (If engine does not run, turn ignition switch to “START” for at least 5 seconds.)
- 3) Turn ignition switch “OFF”, wait at least 5 seconds and then turn “ON”.
- 4) Perform “Diagnostic Test Mode II (Self-diagnostic results)” with ECM.
- 5) If DTC is detected, go to “Diagnostic Procedure”, EC-114.



DTC 0201 IGNITION SIGNAL

Wiring Diagram


Wiring Diagram

NMEC0693

EC-IGN/SG-01



REFER TO THE FOLLOWING.
 (E101), (F4) -SUPER
 MULTIPLE JUNCTION (SMJ)






TEC802

DTC 0201 IGNITION SIGNAL

Wiring Diagram (Cont'd)

EC-IGN/SG-02



GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TEC803

DTC 0201 IGNITION SIGNAL

Diagnostic Procedure

Diagnostic Procedure

NMEC0694



1	CHECK ENGINE START	
Turn ignition switch "OFF", and restart engine. Is engine running?		
Yes or No		
Yes (With CONSULT-II) ▶	GO TO 2.	
Yes (Without CONSULT-II) ▶	GO TO 12.	
No ▶	GO TO 3.	


2	SEARCH FOR MALFUNCTIONING CIRCUIT																											
<p> With CONSULT-II</p> <p>1. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II. 2. Search for circuit which does not produce a momentary engine speed drop.</p>																												
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th colspan="2">POWER BALANCE</th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <th>CMPS~RPM(REF)</th> <th>XXX rpm</th> </tr> <tr> <th>MAS AIR/FL SE</th> <th>XXX V</th> </tr> <tr> <th>IACV-AAC/V</th> <th>XXX %</th> </tr> <tr> <td> </td> <td> </td> </tr> </thead> <tbody> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>			ACTIVE TEST		POWER BALANCE		MONITOR		CMPS~RPM(REF)	XXX rpm	MAS AIR/FL SE	XXX V	IACV-AAC/V	XXX %														
ACTIVE TEST																												
POWER BALANCE																												
MONITOR																												
CMPS~RPM(REF)	XXX rpm																											
MAS AIR/FL SE	XXX V																											
IACV-AAC/V	XXX %																											
PEF389V																												
▶		GO TO 12.																										

3	CHECK IGNITION COIL POWER SUPPLY CIRCUIT-I	
<p>1. Turn ignition switch ON. 2. Check voltage between ECM terminals 38, 47 and ground with CONSULT-II or tester.</p>		
<p style="text-align: right;">Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p>		
SEC410C		
OK ▶	GO TO 4.	
NG ▶	Go to TROUBLE DIAGNOSIS FOR POWER SUPPLY, EC-83.	

DTC 0201 IGNITION SIGNAL

Diagnostic Procedure (Cont'd)


4	CHECK IGNITION COIL POWER SUPPLY CIRCUIT-II		
<ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect condenser harness connector. 		<p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p>EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p>	
		SEC380C	
<ol style="list-style-type: none"> 3. Turn ignition switch ON. 4. Check voltage between condenser terminal 1 and ground with CONSULT-II or tester. 			
 <p style="text-align: center;">Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p>		SEF367X	
OK	▶	GO TO 10.	PD
NG	▶	GO TO 5.	AX

5	CHECK IGNITION COIL POWER SUPPLY CIRCUIT-III		
<ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Disconnect ECM relay. 		<p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> <p>EL</p>	
<p>View with dash side lower finisher LH and ECM removed</p> 		SEC376C	
<ol style="list-style-type: none"> 3. Check harness continuity between ECM relay terminal 6 and condenser terminal 1. Refer to Wiring Diagram. Continuity should exist. 4. Also check harness for short to ground and short to power. 			
OK or NG			
OK	▶	GO TO 7.	IDX
NG	▶	GO TO 6.	

DTC 0201 IGNITION SIGNAL

Diagnostic Procedure (Cont'd)

6	DETECT MALFUNCTIONING PART
Check the harness for open or short between ECM relay and condenser.	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

7	CHECK IGNITION COIL POWER SUPPLY CIRCUIT-IV
Check voltage between ECM relay terminal 7 and ground with CONSULT-II or tester.	
	
SEC411C	
OK	▶ GO TO 9.
NG	▶ GO TO 8.

8	DETECT MALFUNCTIONING PART
Check the following.	
<ul style="list-style-type: none"> ● 10A fuse ● Harness connectors F4, M60 ● Harness connectors M10, E101 ● Harness for open and short between ECM relay and fuse 	
▶	Repair or replace harness or connectors.

9	CHECK ECM RELAY
Refer to "Component Inspection", EC-119.	
OK or NG	
OK	▶ GO TO 18.
NG	▶ Replace ECM relay.

10	CHECK CONDENSER GROUND CIRCUIT FOR OPEN AND SHORT
<ol style="list-style-type: none"> 1. Turn ignition switch OFF. 2. Check harness continuity between condenser terminal 2 and engine ground. Refer to Wiring Diagram. Continuity should exist. 3. Also check harness for short to power. 	
OK or NG	
OK	▶ GO TO 11.
NG	▶ Repair open circuit or short to power in harness or connectors.

DTC 0201 IGNITION SIGNAL

Diagnostic Procedure (Cont'd)

11	CHECK CONDENSER
Refer to "Component Inspection", EC-119.	
OK or NG	
OK	▶ GO TO 12.
NG	▶ Replace condenser.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS



BT

HA

SC

EL

IDX

12	CHECK IGNITION COIL POWER SUPPLY CIRCUIT-V
<ol style="list-style-type: none"> Turn ignition switch OFF. Reconnect harness connectors disconnected. Disconnect ignition coil harness connector. 	
 <p>Ignition coil No. 1</p>	
SEC393C	
<ol style="list-style-type: none"> Turn ignition switch ON. Check voltage between ignition coil terminal 1 and ground with CONSULT-II or tester. 	
 <p>Voltage: Battery voltage</p>	
OK or NG	
OK	▶ GO TO 14.
NG	▶ GO TO 13.

13	DETECT MALFUNCTIONING PART
Check the harness for open or short between ignition coil and ECM relay terminal 7.	
	▶ Repair or replace harness or connectors.

14	CHECK IGNITION COIL GROUND CIRCUIT FOR OPEN AND SHORT
<ol style="list-style-type: none"> Turn ignition switch OFF. Check harness continuity between ignition coil terminal 2 and engine ground. Refer to Wiring Diagram. Continuity should exist. Also check harness for short to power. 	
OK or NG	
OK	▶ GO TO 15.
NG	▶ Repair open circuit or short to power in harness or connectors.

DTC 0201 IGNITION SIGNAL


Diagnostic Procedure (Cont'd)

15	CHECK IGNITION COIL OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT
1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminals 1, 3, 5, 25 and ignition coil terminal 3. Refer to Wiring Diagram. Continuity should exist. 3. Also check harness for short to ground and short to power.	
OK or NG	
OK	▶ GO TO 17.
NG	▶ GO TO 16.

16	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none">● Harness connector F24, F101● Harness for open and short between ignition coil and ECM	
	▶ Repair or replace harness or connectors.

17	CHECK IGNITION COIL WITH POWER TRANSISTOR
Refer to "Component Inspection", EC-119.	
OK or NG	
OK	▶ GO TO 18.
NG	▶ Replace ignition coil with power transistor.

18	CHECK INTERMITTENT INCIDENT
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.	
	▶ INSPECTION END



Component Inspection

IGNITION COIL WITH POWER TRANSISTOR


=NMEC0695

NMEC0695S01

1. Disconnect ignition coil with power transistor harness connector.
2. Check ignition coil with power transistor for resistance as show in the figure.

Terminal No. (Polarity)	Resistance Ω [at 25°C (77°F)]
3 (+) - 2 (-)	Except 0 or ∞
1 (+) - 3 (-)	Except 0
1 (+) - 2 (-)	

If NG, replace ignition coil with power transistor assembly.




ECM RELAY

NMEC0695S02

1. Apply 12V direct current between ECM relay terminals 1 and 2.
2. Check continuity between ECM relay terminals 3 and 5, 6 and 7.

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
OFF	No

If NG, replace ECM relay.



CONDENSER

NMEC0695S03

1. Disconnect condenser harness connector.
2. Check condenser continuity between terminals 1 and 2.

Resistance: Above 100 M Ω at 20°C (68°F)

If NG, replace condenser.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC 0208 OVERHEAT (COOLING SYSTEM)

System Description

System Description

NMEC0696

COOLING FAN CONTROL


NMEC0696S01

Sensor	Input Signal to ECM	ECM function	Actuator
Vehicle speed sensor	Vehicle speed	Cooling fan control	Cooling fan relay(s)
Engine coolant temperature sensor	Engine coolant temperature		
Air conditioner switch	Air conditioner "ON" signal		
Ignition switch	Start signal		

The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature, and air conditioner ON signal. The control system has 3-step control [HIGH/LOW/OFF].

OPERATION

NMEC0696S02



CONSULT-II Reference Value in Data Monitor Mode

NMEC0697

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
AIR COND SIG	● Engine: After warming up, idle the engine	Air conditioner switch: OFF OFF
		Air conditioner switch: ON (Compressor operates) ON
COOLING FAN	● After warming up engine, idle the engine. ● Air conditioner switch: OFF	Engine coolant temperature is less than 95°C (203°F) OFF
		Engine coolant temperature is 95°C (203°F) and 100°C (212°F) LOW
		Engine coolant temperature is 100°C (212°F) or more HIGH

ECM Terminals and Reference Value

NMEC0698

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
9	P/B	Cooling fan relay (Low)	[Engine is running] ● Cooling fan is not operating	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] ● Cooling fan is operating	0 - 0.6V

DTC 0208 OVERHEAT (COOLING SYSTEM)

ECM Terminals and Reference Value (Cont'd)

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	
10	L/G	Cooling fan relay (High)	[Engine is running] <ul style="list-style-type: none"> Cooling fan is not operating Cooling fan is operating at low speed 	BATTERY VOLTAGE (11 - 14V)	GI MA
			[Engine is running] <ul style="list-style-type: none"> Cooling fan is operating at high speed 	0 - 0.6V	EM

On Board Diagnosis Logic

If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will rise. NMEC0699 LC

When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated. **EC**

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)	
0208	<ul style="list-style-type: none"> Cooling fan does not operate properly (Overheat). Cooling fan system does not operate properly (Overheat). Engine coolant was not added to the system using the proper filling method. 	<ul style="list-style-type: none"> Harness or connectors (The cooling fan circuit is open or shorted.) Cooling fan Radiator hose Radiator Radiator cap Water pump Thermostat <p>For more information, refer to "MAIN 12 CAUSES OF OVERHEATING", EC-135.</p>	FE CL MT AT PD

CAUTION:

When a malfunction is indicated, be sure to replace the coolant following the procedure in the LC-15, "Changing Engine Coolant". Also, replace the engine oil. AX

- 1) Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Be sure to use coolant with the proper mixture ratio. Refer to MA-9, "Engine Coolant Mixture Ratio". SU
- 2) After refilling coolant, run engine to ensure that no water-flow noise is emitted. BR

BR

ST

RS

BT

HA

SC


EL

IDX

DTC 0208 OVERHEAT (COOLING SYSTEM)

Overall Function Check



NMEC0700



4

ACTIVE TEST	
COOLING FAN	OFF
MONITOR	
COOLAN TEMP/S	XXX °C

SEF111X



Overall Function Check

Use this procedure to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

With CONSULT-II

- 1) Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to "Diagnostic Procedure", EC-124.
- 2) Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to "Diagnostic Procedure", EC-124.
- 3) Turn ignition switch "ON".
- 4) Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II.
- 5) If the results are NG, go to "Diagnostic Procedure", EC-124.

Without CONSULT-II

- 1) Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to "Diagnostic Procedure", EC-124.
- 2) Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to "Diagnostic Procedure", EC-124.
- 3) Start engine.
Be careful not to overheat engine.
- 4) Set temperature control lever to full cold position.
- 5) Turn air conditioner switch "ON".
- 6) Turn blower fan switch "ON".
- 7) Run engine at idle for a few minutes with air conditioner operating.
Be careful not to overheat engine.
- 8) Make sure that cooling fan operates at low speed.
If NG, go to "Diagnostic Procedure", EC-124.
If OK, go to the following step.
- 9) Turn ignition switch "OFF".
- 10) Turn air conditioner switch and blower fan switch "OFF".
- 11) Disconnect engine coolant temperature sensor harness connector.
- 12) Connect 150Ω resistor to engine coolant temperature sensor harness connector.
- 13) Restart engine and make sure that cooling fan operates at higher speed than low speed.
Be careful not to overheat engine.
- 14) If NG, go to "Diagnostic Procedure", EC-124.


DTC 0208 OVERHEAT (COOLING SYSTEM)

Wiring Diagram

Wiring Diagram

NMEC0701



EC-COOL/F-01



: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC

REFER TO EL-POWER.

REFER TO THE FOLLOWING.
 (E101), (F4) -SUPER MULTIPLE JUNCTION (SMJ)
 (E105) -FUSE BLOCK-JUNCTION BOX (J/B)



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TEC817

DTC 0208 OVERHEAT (COOLING SYSTEM)

Diagnostic Procedure

Diagnostic Procedure

NMEC0702

1	INSPECTION START	
Do you have CONSULT-II?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 4.

2	CHECK COOLING FAN LOW SPEED OPERATION																									
<p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch "ON". 2. Select "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II. 3. Touch "LOW". 																										
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th>COOLING FAN</th> <th>LOW</th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <th>COOLAN TEMP/S</th> <th>XXX °C</th> </tr> </thead> <tbody> <tr><td> </td><td> </td></tr> </tbody> </table>			ACTIVE TEST		COOLING FAN	LOW	MONITOR		COOLAN TEMP/S	XXX °C																
ACTIVE TEST																										
COOLING FAN	LOW																									
MONITOR																										
COOLAN TEMP/S	XXX °C																									
SEF784Z																										
4. Make sure that cooling fan operates at low speed.																										
OK or NG																										
OK	▶	GO TO 3.																								
NG	▶	Check cooling fan low speed control circuit. (Go to PROCEDURE A, EC-129.)																								

3	CHECK COOLING FAN HIGH SPEED OPERATION																									
<p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch "ON". 2. Select "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II. 3. Touch "HIGH". 																										
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th>COOLING FAN</th> <th>HIGH</th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <th>COOLAN TEMP/S</th> <th>XXX °C</th> </tr> </thead> <tbody> <tr><td> </td><td> </td></tr> </tbody> </table>			ACTIVE TEST		COOLING FAN	HIGH	MONITOR		COOLAN TEMP/S	XXX °C																
ACTIVE TEST																										
COOLING FAN	HIGH																									
MONITOR																										
COOLAN TEMP/S	XXX °C																									
SEF785Z																										
4. Make sure that cooling fan operates at higher speed than low speed.																										
OK or NG																										
OK	▶	GO TO 6.																								
NG	▶	Check cooling fan high speed control circuit. (Go to PROCEDURE B, EC-132.)																								


DTC 0208 OVERHEAT (COOLING SYSTEM)

Diagnostic Procedure (Cont'd)


4 CHECK COOLING FAN LOW SPEED OPERATION

⊗ Without CONSULT-II

1. Disconnect cooling fan relay-2.



2. Start engine and let it idle.
3. Set temperature lever at full cold position.
4. Turn air conditioner switch "ON".
5. Turn blower fan switch "ON".
6. Make sure that cooling fan operates at low speed.



OK or NG

SEC381C


SEC443C


OK	▶	GO TO 5.
NG	▶	Check cooling fan low speed control circuit. (Go to PROCEDURE A, EC-129.)

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC 0208 OVERHEAT (COOLING SYSTEM)


Diagnostic Procedure (Cont'd)

5	CHECK COOLING FAN HIGH SPEED OPERATION	
<p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Reconnect cooling fan relay-2. 3. Turn air conditioner switch and blower fan switch "OFF". 4. Disconnect engine coolant temperature sensor harness connector. 5. Connect 150Ω resistor to engine coolant temperature sensor harness connector. 6. Restart engine and make sure that cooling fan operates at higher speed than low speed. 		
 <p>The diagram illustrates the components for the cooling fan high speed operation test. It includes a cooling fan, an engine coolant temperature sensor harness connector, a 150Ω resistor, and a disconnect symbol. The resistor is shown connected to the sensor harness connector. The disconnect symbol is labeled 'DISCONNECT'.</p>		
SEC444C		
OK or NG		
OK	▶	GO TO 6.
NG	▶	Check cooling fan high speed control circuit. (Go to PROCEDURE B, EC-132.)


6	CHECK COOLING SYSTEM FOR LEAK	
<p>Apply pressure to the cooling system with a tester, and check if the pressure drops.</p> <p>Testing pressure: 157 kPa (1.57 bar, 1.6 kg/cm², 23 psi)</p> <p>CAUTION: Higher than the specified pressure may cause radiator damage.</p>		
 <p>The diagram shows a pressure tester with a gauge connected to a radiator hose adapter. The adapter is labeled 'Hose adapter' and 'EG17650301'. The pressure tester is connected to the radiator hose.</p>		
SLC754AB		
Pressure should not drop.		
OK or NG		
OK	▶	GO TO 7.
NG	▶	<p>Check the following for leak</p> <ul style="list-style-type: none"> ● Hose ● Radiator ● Water pump <p>Refer to LC-12, "Water Pump".</p>

DTC 0208 OVERHEAT (COOLING SYSTEM)

Diagnostic Procedure (Cont'd)

7	CHECK RADIATOR CAP	
Apply pressure to cap with a tester.		
		
SLC755AE		
<p>Radiator cap relief pressure: 59 - 98 kPa (0.59 - 0.98 bar, 0.6 - 1.0 kg/cm², 9 - 14 psi)</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 8.
NG	▶	Replace radiator cap.

GI
MA
EM
LC
EC

8	CHECK THERMOSTAT	
<p>1. Check valve seating condition at normal room temperatures. It should seat tightly.</p> <p>2. Check valve opening temperature and valve lift.</p>		
		
SLC343		
<p>Valve opening temperature: 76.5°C (170°F)</p> <p>Valve lift: More than 8 mm/90°C (0.31 in/194°F)</p> <p>3. Check if valve is closed at 5°C (9°F) below valve opening temperature. For details, refer to LC-13, "Thermostat".</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 9.
NG	▶	Replace thermostat

MT
AT
PD
AX
SU
BR
ST
RS

9	CHECK ENGINE COOLANT TEMPERATURE SENSOR	
Refer to "COMPONENT INSPECTION", EC-109.		
OK or NG		
OK	▶	GO TO 10.
NG	▶	Replace engine coolant temperature sensor.

HA
SC
EL
IDX

DTC 0208 OVERHEAT (COOLING SYSTEM)

Diagnostic Procedure (Cont'd)

10	CHECK MAIN 12 CAUSES
If the cause cannot be isolated, go to "MAIN 12 CAUSES OF OVERHEATING", EC-135.	
▶	INSPECTION END

DTC 0208 OVERHEAT (COOLING SYSTEM)


Diagnostic Procedure (Cont'd)

PROCEDURE A


=NMEC0702S01

1 CHECK POWER SUPPLY

1. Turn ignition switch "OFF".
2. Disconnect cooling fan relay-1.



3. Turn ignition switch "ON".
4. Check voltage between cooling fan relay-1 terminals 2, 5 and ground with CONSULT-II or tester.



Voltage: Battery voltage

OK or NG

OK	▶	GO TO 3.
NG	▶	GO TO 2.

2 DETECT MALFUNCTIONING PART

Check the following.


- 10A fuse
- 40A fusible link
- Harness for open or short between cooling fan relay-1 and fuse
- Harness for open or short between cooling fan relay-1 and battery

▶ Repair open circuit or short to ground or short to power in harness or connectors.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC 0208 OVERHEAT (COOLING SYSTEM)

Diagnostic Procedure (Cont'd)

3	CHECK COOLING FAN MOTOR CIRCUIT FOR OPEN AND SHORT-I	
<p>1. Turn ignition switch "OFF". 2. Disconnect cooling fan motor harness connector.</p>  <p style="text-align: right;">SEC382C</p>		
<p>3. Check harness continuity between cooling fan relay-1 terminal 3 and cooling fan motor terminal 1, cooling fan motor terminal 3 and body ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 4.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

4	CHECK OUTPUT SIGNAL CIRCUIT	
<p>1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 9 and cooling fan relay-1 terminal 1. Refer to Wiring Diagram. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 6.
NG	▶	GO TO 5.

5	DETECT MALFUNCTION PART	
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F4, M60 ● Harness connectors M10, E101 ● Harness for open or short between cooling fan relay-1 and ECM 		
		▶ Repair open circuit or short to ground or short to power in harness connectors.

6	CHECK COOLING FAN RELAY-1	
<p>Refer to "Component Inspection", EC-135.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 7.
NG	▶	Replace cooling fan relay-1.

DTC 0208 OVERHEAT (COOLING SYSTEM)

Diagnostic Procedure (Cont'd)

7	CHECK COOLING FAN MOTOR
Refer to "Component Inspection", EC-136.	
OK or NG	
OK	▶ GO TO 8.
NG	▶ Replace cooling fan motor.

GI

MA

EM

8	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.	
	▶ INSPECTION END

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC 0208 OVERHEAT (COOLING SYSTEM)


Diagnostic Procedure (Cont'd)

PROCEDURE B

=NMEC0702S02



1 CHECK COOLING FAN POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect cooling fan relay-2.



SEC381C

3. Turn ignition switch "ON".
4. Check voltage between cooling fan relays-2 terminals 2, 5 and ground with CONSULT-II or tester.



Voltage: Battery voltage

SEC412C

OK or NG

- | | | |
|----|---|----------|
| OK | ▶ | GO TO 3. |
| NG | ▶ | GO TO 2. |

2 DETECT MALFUNCTIONING PART


Check the following.

- 10A fuse
- 40A fusible link
- Harness for open or short between cooling fan relay-2 and fuse
- Harness for open or short between cooling fan relay-2 and fusible link

▶ Repair open circuit or short to ground or short to power in harness or connectors.

DTC 0208 OVERHEAT (COOLING SYSTEM)

Diagnostic Procedure (Cont'd)

3	CHECK COOLING FAN MOTOR CIRCUIT FOR OPEN AND SHORT
<p>1. Turn ignition switch "OFF". 2. Disconnect cooling fan motor harness connector.</p> <div style="text-align: center;">  <p style="text-align: center;">Cooling fan motor harness connector</p> <p style="text-align: center;">Battery</p> <p style="text-align: center;">Front</p> </div> <p style="text-align: right;">SEC382C</p> <p>3. Check harness continuity between cooling fan relay-2 terminal 3 and cooling fan motor terminal 4, cooling fan motor terminal 2 and body ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

4	CHECK COOLING FAN OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT
<p>1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 10 and cooling fan relay-2 terminal 1. Refer to Wiring Diagram. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

5	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F4, M60 ● Harness connectors M10, E101 ● Harness for open or short between cooling fan relay-2 and ECM 	
	▶ Repair open circuit or short to ground or short to power in harness or connectors.

6	CHECK COOLING FAN RELAY-2
<p>Refer to "Component Inspection", EC-135.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 7.
NG	▶ Replace cooling fan relay-2.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC 0208 OVERHEAT (COOLING SYSTEM)

Diagnostic Procedure (Cont'd)

7	CHECK COOLING FAN MOTOR
Refer to "Component Inspection", EC-136.	
OK or NG	
OK	▶ GO TO 8.
NG	▶ Replace cooling fan motors.

8	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.	
	▶ INSPECTION END

DTC 0208 OVERHEAT (COOLING SYSTEM)

Main 12 Causes of Overheating

Main 12 Causes of Overheating

=NMEC0703

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	<ul style="list-style-type: none"> Blocked radiator Blocked condenser Blocked radiator grille Blocked bumper 	<ul style="list-style-type: none"> Visual 	No blocking	—
	2	<ul style="list-style-type: none"> Coolant mixture 	<ul style="list-style-type: none"> Coolant tester 	50 - 50% coolant mixture	See MA-9, "Engine Coolant Mixture Ratio".
	3	<ul style="list-style-type: none"> Coolant level 	<ul style="list-style-type: none"> Visual 	Coolant up to MAX level in reservoir tank and radiator filler neck	See LC-15, "Changing Engine Coolant".
	4	<ul style="list-style-type: none"> Radiator cap 	<ul style="list-style-type: none"> Pressure tester 	59 - 98 kPa (0.59 - 0.98 bar, 0.6 - 1.0 kg/cm ² , 9 - 14 psi) (Limit)	See LC-10, "System Check".
ON*2	5	<ul style="list-style-type: none"> Coolant leaks 	<ul style="list-style-type: none"> Visual 	No leaks	See LC-10, "System Check".
ON*2	6	<ul style="list-style-type: none"> Thermostat 	<ul style="list-style-type: none"> Touch the upper and lower radiator hoses 	Both hoses should be hot	See LC-13, "Thermostat" and LC-14, "Radiator".
ON*1	7	<ul style="list-style-type: none"> Cooling fan 	<ul style="list-style-type: none"> CONSULT-II 	Operating	See "DTC P0208 OVERHEAT" (EC-120).
OFF	8	<ul style="list-style-type: none"> Combustion gas leak 	<ul style="list-style-type: none"> Color checker chemical tester 4 Gas analyzer 	Negative	—
ON*3	9	<ul style="list-style-type: none"> Coolant temperature gauge 	<ul style="list-style-type: none"> Visual 	Gauge less than 3/4 when driving	—
		<ul style="list-style-type: none"> Coolant overflow to reservoir tank 	<ul style="list-style-type: none"> Visual 	No overflow during driving and idling	See LC-15, "Changing Engine Coolant".
OFF*4	10	<ul style="list-style-type: none"> Coolant return from reservoir tank to radiator 	<ul style="list-style-type: none"> Visual 	Should be initial level in reservoir tank	See LC-16, "Refilling Engine Coolant".
OFF	11	<ul style="list-style-type: none"> Cylinder head 	<ul style="list-style-type: none"> Straight gauge feeler gauge 	0.1 mm (0.004 in) Maximum distortion (warping)	See EM-43, "Inspection", "CYLINDER HEAD".
	12	<ul style="list-style-type: none"> Cylinder block and pistons 	<ul style="list-style-type: none"> Visual 	No scuffing on cylinder walls or piston	See EM-70, "Inspection", "CYLINDER BLOCK".


*1: Turn the ignition switch ON.

*2: Engine running at 3,000 rpm for 10 minutes.

*3: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

*4: After 60 minutes of cool down time.

For more information, refer to LC-21, "OVERHEATING CAUSE ANALYSIS".



Component Inspection

COOLING FAN RELAYS-1 AND -2

NMEC0704

NMEC0704S01


Check continuity between terminals 3 and 5.

Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

If NG, replace relay.

DTC 0208 OVERHEAT (COOLING SYSTEM)

Component Inspection (Cont'd)



COOLING FAN MOTOR

NMEC0704S03

1. Disconnect cooling fan motor harness connectors.
2. Supply cooling fan motor terminals with battery voltage and check operation.


	Speed	Terminals	
		(+)	(-)
Cooling fan motor	Low	1	3
	High	1, 4	2, 3

Cooling fan motor should operate.

If NG, replace cooling fan motor.

DTC 0304 KNOCK SENSOR (KS)

Component Description



Component Description

NMEC0705

The knock sensor is attached to the cylinder block. It senses engine knocking using a piezoelectric element. A knocking vibration from the cylinder block is sensed as vibrational pressure. This pressure is converted into a voltage signal and sent to the ECM.

ECM Terminals and Reference Value

NMEC0706

Specification data are reference values and are measured between each terminal and ground.

CAUTION:


Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
27	W	Knock sensor	[Engine is running] ● Idle speed	Approximately 2.5V

On Board Diagnosis Logic

NMEC0707

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
0304	● An excessively low or high voltage from the knock sensor is sent to ECM.	● Harness or connectors (The knock sensor circuit is open or shorted.) ● Knock sensor



DTC Confirmation Procedure

NMEC0708

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

Ⓜ With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine and run it for at least 5 seconds at idle speed.
- 3) If DTC is detected, go to "Diagnostic Procedure", EC-139.

ⓧ Without CONSULT-II

- 1) Start engine and run it for at least 5 seconds at idle speed.
- 2) Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-139.



DTC 0304 KNOCK SENSOR (KS)

Wiring Diagram

Wiring Diagram

NMEC0709


EC-KS-01



TEC804

Diagnostic Procedure

NMEC0710

1	RETIGHTEN GROUND SCREWS		GI
		Loosen and retighten engine ground screws.	MA
			EM
		SEC377C	LC
▶		GO TO 2.	EC

2	CHECK INPUT SIGNAL CIRCUIT		FE
		<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector and knock sensor harness connector. 3. Check harness continuity between knock sensor terminal 2 and ECM terminal 27. Refer to wiring diagram. Continuity should exist. 4. Also check harness for short to ground and short to power. 	CL
		OK or NG	MT
OK ▶		GO TO 4.	AT
NG ▶		GO TO 3.	PD

3	DETECT MALFUNCTIONING PART		AX
		Check the following.	SU
		<ul style="list-style-type: none"> ● Harness connectors F28, F121 ● Harness for open or short between knock sensor and ECM 	BR
▶		Repair open circuit or short to ground or short to power in harness or connectors.	ST


4	CHECK KNOCK SENSOR		RS
		Refer to "Component Inspection", EC-140.	BT
		OK or NG	HA
OK ▶		GO TO 5.	SC
NG ▶		Replace knock sensor.	EL

5	CHECK SHIELD CIRCUIT		IDX
		<ol style="list-style-type: none"> 1. Reconnect harness connectors disconnected. 2. Disconnect harness connectors F28, F121. 3. Check harness continuity between F28 terminal 1 and engine ground. Refer to wiring diagram. Continuity should exist. 4. Also check harness for short to power. 5. Then reconnect harness connectors. 	HA
		OK or NG	SC
OK ▶		GO TO 6.	EL
NG ▶		Repair open circuit or short to power in harness or connectors.	IDX

DTC 0304 KNOCK SENSOR (KS)

Diagnostic Procedure (Cont'd)

6	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.	
▶	INSPECTION END



Component Inspection

KNOCK SENSOR

NMEC0711

- Use an ohmmeter which can measure more than 10 MΩ.

NMEC0711S01

1. Disconnect knock sensor harness connector.
2. Check resistance between terminal 2 and ground.

Resistance: 500 - 620 kΩ [at 25°C (77°F)]

CAUTION:

Discard any knock sensors that have been dropped or physically damaged. Use only new ones.

DTC 0403 THROTTLE POSITION SENSOR


Component Description

Component Description

NMEC0712

The throttle position sensor responds to the accelerator pedal movement. This sensor is a kind of potentiometer which transforms the throttle position into output voltage, and emits the voltage signal to the ECM. In addition, the sensor detects the opening and closing speed of the throttle valve and feeds the voltage signal to the ECM.

Idle position of the throttle valve is determined by the ECM receiving the signal from the throttle position sensor. This sensor controls engine operation such as fuel cut. On the other hand, the "Wide open and closed throttle position switch", which is built into the throttle position sensor unit (for A/T models only), is not used for engine control.



CONSULT-II Reference Value in Data Monitor Mode

NMEC0713

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
THRTL POS SEN	● Engine: Idle	Throttle valve: fully closed	0.15 - 0.85V
	● Ignition switch: ON (Engine stopped)	Throttle valve: fully opened	3.5 - 4.7V
CLSD THL POS	● Engine: Idle	Throttle valve: fully closed	ON
		Throttle valve: slightly opened	OFF

DTC 0403 THROTTLE POSITION SENSOR

ECM Terminals and Reference Value

ECM Terminals and Reference Value

=NMEC0714

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
20	R	Throttle position sensor	[Engine is running] ● Accelerator pedal fully released	0.15 - 0.85V
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	3.5 - 4.7V
21	GY	Sensors' ground	[Engine is running] ● Warm up condition ● Idle speed	Approximately 0V
37	LG/R	Sensors' power supply	[Ignition switch "ON"]	Approximately 5V

On Board Diagnosis Logic

NMEC0715

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
0403	An excessively low or high voltage from the sensor is sent to ECM* while driving.	<ul style="list-style-type: none"> ● Harness or connectors (The throttle position sensor circuit is open or shorted.) ● Throttle position sensor

*: When this malfunction is detected, the ECM enters fail-safe mode and the MIL lights up.

Fail-safe Mode

NMEC0716

Detected items	Engine operating condition in fail-safe mode	
Throttle position sensor circuit	Throttle position will be determined based on the injected fuel amount and the engine speed. Therefore, acceleration will be poor.	
	Condition	Driving condition
	When engine is idling	Normal
	When accelerating	Poor acceleration

DTC Confirmation Procedure

NMEC0717

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

CAUTION:

Always drive vehicle at a safe speed.

TESTING CONDITION:

- This test may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

DTC 0403 THROTTLE POSITION SENSOR

DTC Confirmation Procedure (Cont'd)

2

DATA MONITOR	
MONITOR	NO DTC
CMPS-RPM (REF)	XXX rpm
VHCL SPEED SE	XXX km/h
THRTL POS SEN	XXX V

SEC448C

Ⓔ With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine and maintain the following conditions for at least 5 consecutive seconds.

VHCL SPEED SE	More than 4 km/h (2 MPH)
Selector lever	Suitable position except "P" or "N" position

- 3) If DTC is detected, go to "Diagnostic Procedure", EC-145.

Ⓕ Without CONSULT-II

- 1) Start engine and maintain the following conditions for at least 5 consecutive seconds.

Vehicle speed	More than 4 km/h (2 MPH)
Selector lever	Suitable position except "P" or "N" position

- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON" and perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-145.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX





DTC 0403 THROTTLE POSITION SENSOR

Wiring Diagram

Wiring Diagram

NMEC0718

EC-TPS-01




REFER TO THE FOLLOWING.



(F4) -SUPER MULTIPLE JUNCTION (SMJ)

TEC805

Diagnostic Procedure

NMEC0719

1	RETIGHTEN GROUND SCREWS	<ol style="list-style-type: none"> Turn ignition switch "OFF". Loosen and retighten engine ground screws.  <p style="text-align: right;">SEC377C</p>	GI MA EM LC EC FE CL
▶		GO TO 2.	

2	CHECK POWER SUPPLY	<ol style="list-style-type: none"> Disconnect throttle position sensor harness connector.  <p style="text-align: right;">SEC336C</p> <ol style="list-style-type: none"> Turn ignition switch "ON". Check voltage between throttle position sensor terminal 3 and ground with CONSULT-II or tester.  <p style="text-align: center;">Voltage: Approximately 5V</p> <p style="text-align: center;">OK or NG</p> <p style="text-align: right;">SEF306X</p>	MT AT PD AX SU BR ST RS BT HA SC EL IDX
▶		GO TO 3.	
▶		Repair harness or connectors.	

DTC 0403 THROTTLE POSITION SENSOR

Diagnostic Procedure (Cont'd)

3	CHECK GROUND CIRCUIT
1. Turn ignition switch "OFF". 2. Check harness continuity between throttle position sensor terminal 1 and engine ground. Refer to wiring diagram. Continuity should exist. 3. Also check harness for short to power.	
OK or NG	
OK	▶ GO TO 5.
NG	▶ GO TO 4.

4	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none"> ● Harness connectors F4, M60 ● Harness for open or short between ECM and throttle position sensor ● Harness for open or short between TCM (Transmission Control Module) and throttle position sensor 	
	▶ Repair open circuit or short to power in harness or connectors.

5	CHECK INPUT SIGNAL CIRCUIT
1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 20 and throttle position sensor terminal 2. Refer to wiring diagram. Continuity should exist. 3. Also check harness for short to ground and short to power.	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

6	CHECK THROTTLE POSITION SENSOR
Refer to "Component Inspection", EC-146.	
OK or NG	
OK	▶ GO TO 7.
NG	▶ Replace throttle position sensor. To adjust it, perform "Basic Inspection", EC-50.

7	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.	
	▶ INSPECTION END

DATA MONITOR	
MONITOR	NO DTC
CMPS-RPM (REF)	XXX rpm
COOLAN TEMP/S	XXX °C
THRTL POS SEN	XXX V

SEC449C

Component Inspection THROTTLE POSITION SENSOR

NMEC0720

NMEC0720S01

Ⓜ With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Stop engine (ignition switch OFF).
- 3) Turn ignition switch ON.
- 4) Select "DATA MONITOR" mode with CONSULT-II.
- 5) Check voltage of "THRTL POS SEN" under the following conditions.

DTC 0403 THROTTLE POSITION SENSOR

Component Inspection (Cont'd)


NOTE:

Voltage measurement must be made with throttle position sensor installed in vehicle.

Throttle valve conditions	Voltage (V)
Completely closed	0.15 - 0.85 (a)
Partially open	Between (a) and (b)
Completely open	3.5 - 4.7 (b)

If NG, adjust closed throttle position switch. Refer to "Basic Inspection", EC-50.

- 6) If it is impossible to adjust closed throttle position switch in "Basic Inspection", replace throttle position sensor.



SEC414C

⊗ Without CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Stop engine (ignition switch OFF).
- 3) Turn ignition switch ON.
- 4) Check voltage between ECM terminal 20 (Throttle position sensor signal) and ground under the following conditions.

NOTE:

Voltage measurement must be made with throttle position sensor installed in vehicle.

Throttle valve conditions	Voltage (V)
Completely closed	0.15 - 0.85 (a)
Partially open	Between (a) and (b)
Completely open	3.5 - 4.7 (b)

If NG, adjust closed throttle position switch. Refer to "Basic Inspection", EC-50.

- 5) If it is impossible to adjust closed throttle position switch in "Basic Inspection", replace throttle position sensor.

DTC 0504 A/T CONTROL

System Description

System Description

These circuit lines are used to control the smooth shifting up and down of A/T during the hard acceleration/ deceleration. Pulse signals are exchanged between ECM and TCM (Transmission control module). NMEC0721

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and ground. NMEC0722


CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
12	PU/W	A/T signal No. 3	[Engine is running] ● Idle speed	0 - 0.1V
44	L/W	A/T signal No. 2	[Engine is running] ● Idle speed	6 - 8V
45	L/OR	A/T signal No. 1	[Engine is running] ● Idle speed	6 - 8V

On Board Diagnosis Logic

DTC No.	Malfunction is detected when ...	Check Items (Possible Cause)
0504	● ECM receives incorrect voltage from TCM (Transmission control module) continuously.	● Harness or connectors [The circuit between ECM and TCM (Transmission control module) is open or shorted.]



DTC Confirmation Procedure

NMEC0724

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V at idle.

Ⓜ With CONSULT-II

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine, and let it idle for at least 15 seconds.
- 4) If DTC is detected, go to "Diagnostic Procedure", EC-151.



Overall Function Check

NM/EC0818

Use this procedure to check the overall function of the A/T control circuit. During this check, a DTC might not be confirmed.

⊗ Without CONSULT-II

- 1) Start engine.
- 2) Check voltage between
ECM terminal 44 and ground.
ECM terminal 45 and ground.

Voltage: 6 - 8V

- 3) If NG, go to "Diagnostic Procedure", EC-151.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



DTC 0504 A/T CONTROL

Wiring Diagram

Wiring Diagram


NMEC0725

EC-AT/C-01



REFER TO THE FOLLOWING.

(F4) -SUPER MULTIPLE JUNCTION (SMJ)



TEC806

Diagnostic Procedure

NMEC0726

1	CHECK INPUT SIGNAL CIRCUIT	
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect ECM harness connector and TCM (Transmission control module) harness connector.</p> <p>3. Check harness continuity between ECM terminal 12 and TCM terminal 7, ECM terminal 44 and terminal TCM 6, ECM terminal 45 and TCM terminal 5.</p> <p>Refer to wiring diagram.</p> <p style="color: blue;">Continuity should exist.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 2.
NG	▶	Repair harness or connectors.

GI

MA

EM

LC

EC

2	CHECK INPUT SIGNAL CIRCUIT	
<p>1. Check harness continuity between ECM terminals 12, 44, 45 and ground.</p> <p>Refer to wiring diagram.</p> <p style="color: blue;">Continuity should not exist.</p> <p>2. Also check harness for short to power.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 3.
NG	▶	Repair short to ground or short to power in harness.

FE

CL

MT

3	CHECK INTERMITTENT INCIDENT	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.		
▶	INSPECTION END	

AT

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

HEATED OXYGEN SENSOR 1 (FRONT)


Component Description



Component Description

NMEC0727

The heated oxygen sensor 1 (front) is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 (front) has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 (front) signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

NMEC0728

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
O2S1	<ul style="list-style-type: none"> Engine: After warming up Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
M/R F/C MNT		LEAN ↔ RICH Changes more than 5 times during 10 seconds.

ECM Terminals and Reference Value

NMEC0729

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
19	W	Heated oxygen sensor 1 (front)	[Engine is running] <ul style="list-style-type: none"> After warming up to normal operating temperature and engine speed is 2,000 rpm 	0 - Approximately 1.0V <p>SEC363C</p>


HEATED OXYGEN SENSOR 1 (FRONT)

Wiring Diagram


Wiring Diagram

NMEC0730

EC-HO2S-01




GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



REFER TO THE FOLLOWING.

- (F4) -SUPER MULTIPLE JUNCTION (SMJ)
- (M7) -FUSE BLOCK-JUNCTION BOX (J/B)



TEC808

HEATED OXYGEN SENSOR 1 (FRONT)


Diagnostic Procedure

Diagnostic Procedure

NMEC0731



1	INSPECTION START	
Do you have CONSULT-II?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

2	CHECK OVERALL FUNCTION															
<p> With CONSULT-II</p> <ol style="list-style-type: none"> Start engine and warm it up to normal operating temperature. Select M/R F/C MNT in "DATA MONITOR" mode with CONSULT-II. Keep the engine speed at 2,000 rpm under no load, and make sure that the monitors fluctuate between LEAN and RICH more than five times in 10 seconds. 																
<table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th>NO DTC</th> </tr> </thead> <tbody> <tr> <td>CMPS-RPM (REF)</td> <td>XXX rpm</td> </tr> <tr> <td>MAS AIR/FL SE</td> <td>XXX V</td> </tr> <tr> <td>COOLAN TEMP/S</td> <td>XXX °C</td> </tr> <tr> <td>O2S1</td> <td>XXX V</td> </tr> <tr> <td>M/R F/C MNT</td> <td>LEAN</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR	NO DTC	CMPS-RPM (REF)	XXX rpm	MAS AIR/FL SE	XXX V	COOLAN TEMP/S	XXX °C	O2S1	XXX V	M/R F/C MNT	LEAN
DATA MONITOR																
MONITOR	NO DTC															
CMPS-RPM (REF)	XXX rpm															
MAS AIR/FL SE	XXX V															
COOLAN TEMP/S	XXX °C															
O2S1	XXX V															
M/R F/C MNT	LEAN															
<p>1 time: RICH → LEAN → RICH 2 times: RICH → LEAN → RICH → LEAN → RICH</p>																
SEC419C																
OK or NG																
OK	▶	INSPECTION END														
NG	▶	GO TO 4.														

3	CHECK OVERALL FUNCTION	
<p> Without CONSULT-II</p> <ol style="list-style-type: none"> Start engine and warm it up to normal operating temperature. Stop engine and wait at least 5 seconds. Set ECM in "Diagnostic test mode-II [Heated oxygen sensor 1 monitor (front)]". Refer to "How to Switch Diagnostic Test Modes", EC-36. Keep the engine speed at 2,000 rpm under no load, and make sure that the MIL comes ON more than five times in 10 seconds. 		
		
SAT652J		
OK or NG		
OK	▶	INSPECTION END
NG	▶	GO TO 4.

HEATED OXYGEN SENSOR 1 (FRONT)

Diagnostic Procedure (Cont'd)

4	RETIGHTEN GROUND SCREWS	<p>1. Turn ignition switch "OFF".</p> <p>2. Loosen and retighten engine ground screws.</p> <div style="text-align: center;">  <p>Labels: Engine ground, Intake manifold collector</p> </div> <p>3. Disconnect heated oxygen sensor 1 (HO2S1) (front) harness connector.</p> <div style="text-align: center;">  <p>Labels: Heated oxygen sensor 1 (front), Heated oxygen sensor 1 (front) harness connector, ABS actuator</p> </div>	<p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p style="background-color: black; color: white; padding: 5px;">EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>PD</p>
▶		GO TO 5.	<p>SEC377C</p> <p>SEC383C</p>

5	RETIGHTEN HEATED OXYGEN SENSOR 1 (FRONT)	<p>Loosen and retighten corresponding heated oxygen sensor 1 (front).</p> <p>Tightening torque: 40 - 60 N-m (4.1 - 6.1 kg-m, 30 - 44 ft-lb)</p>	<p>AX</p> <p>SU</p> <p>BR</p>
▶		GO TO 6.	

6	CHECK INPUT SIGNAL CIRCUIT	<p>1. Disconnect ECM harness connector.</p> <p>2. Check harness continuity between ECM terminal 19 and HO2S1 terminal 2. Refer to wiring diagram. Continuity should exist.</p> <p>3. Check harness continuity between ECM terminal 19 (or HO2S1 terminal 2) and ground. Continuity should not exist.</p> <p>4. Also check harness for short to power.</p> <p style="text-align: center;">OK or NG</p>	<p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p>
OK	▶	GO TO 7.	
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.	

IDX

HEATED OXYGEN SENSOR 1 (FRONT)

Diagnostic Procedure (Cont'd)

7	CHECK HEATED OXYGEN SENSOR 1 (FRONT)	
Refer to "Component Inspection", EC-156.		
OK or NG		
OK	▶	GO TO 8.
NG	▶	Replace heated oxygen sensor 1 (front).

8	CHECK INTERMITTENT INCIDENT	
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.		
▶		INSPECTION END

4	DATA MONITOR	
	MONITOR	NO DTC
	CMPS-RPM (REF)	XXX rpm
	MAS AIR/FL SE	XXX V
	COOLAN TEMP/S	XXX °C
	O2S1	XXX V
	M/R F/C MNT	LEAN
	SEC415C	

5	cycle 1 2 3 4 5
	M/R F/C MNT R-L-R-L-R-L-R-L-R-L-R
	R means M/R F/C MNT indicates RICH
	L means M/R F/C MNT indicates LEAN
SEC416C	

Component Inspection HEATED OXYGEN SENSOR 1 (FRONT)

NMEC0732

NMEC0732S01

Ⓜ With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Select "MANU TRIG" in "DATA MONITOR" mode, and select "O2S1" and "M/R F/C MNT".
- 3) Hold engine speed at 2,000 rpm under no load during the following steps.
- 4) Touch "RECORD" on CONSULT-II screen.
- 5) Check the following.
 - "M/R F/C MNT" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown below:
R = "M/R F/C MNT", "RICH"
L = "M/R F/C MNT", "LEAN"
 - "O2S1" voltage goes above 0.6V at least once.
 - "O2S1" voltage goes below 0.3V at least once.
 - "O2S1" voltage never exceeds 1.0V.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool and approved anti-seize lubricant.

HEATED OXYGEN SENSOR 1 HEATER (FRONT)

Description

Description

NMEC0733

SYSTEM DESCRIPTION

NMEC0733S01

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	Heated oxygen sensor 1 heater (front) control	Heated oxygen sensor 1 heater (front)

The ECM performs ON/OFF control of the heated oxygen sensor 1 heater (front) corresponding to the engine operating condition.

OPERATION

NMEC0733S02

Engine speed	Heated oxygen sensor 1 heater (front)
Above 4,000 rpm	OFF
Below 4,000 rpm	ON

ECM Terminals and Reference Value

NMEC0735

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
111	B/R	Heated oxygen sensor 1 heater (front)	[Engine is running] ● Engine speed is below 4,000 rpm.	Approximately 0V
			[Engine is running] ● Engine speed is above 4,000 rpm.	BATTERY VOLTAGE (11 - 14V)


HEATED OXYGEN SENSOR 1 HEATER (FRONT)

Wiring Diagram


Wiring Diagram

NMEC0736

EC-HO2SH-01




GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



REFER TO THE FOLLOWING.

- (F4) -SUPER MULTIPLE JUNCTION (SMJ)
- (M7) -FUSE BLOCK-JUNCTION BOX (J/B)




TEC809



HEATED OXYGEN SENSOR 1 HEATER (FRONT)

Diagnostic Procedure

Diagnostic Procedure

NMEC0737

1	CHECK OVERALL FUNCTION								
<ol style="list-style-type: none"> 1. Turn ignition switch "ON". 2. Set the tester probe between ECM terminal 111 [HO2S1 heater (front) signal] and ground. 3. Start engine and let it idle. 4. Check the voltage under the following conditions. 									
		<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Conditions</th> <th style="width: 50%;">Voltage</th> </tr> </thead> <tbody> <tr> <td>At idle</td> <td style="text-align: center;">0 - 1V</td> </tr> <tr> <td>Engine speed is above 4,000 rpm.</td> <td style="text-align: center;">Battery voltage</td> </tr> </tbody> </table>	Conditions	Voltage	At idle	0 - 1V	Engine speed is above 4,000 rpm.	Battery voltage	SEC420C
Conditions	Voltage								
At idle	0 - 1V								
Engine speed is above 4,000 rpm.	Battery voltage								
OK or NG									
OK	▶	INSPECTION END							
NG	▶	GO TO 2.							

2	CHECK POWER SUPPLY		
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Disconnect heated oxygen sensor 1 (front) harness connector. 			
		SEC383C	
<ol style="list-style-type: none"> 3. Turn ignition switch "ON". 4. Check voltage between HO2S1 terminal 1 and ground with CONSULT-II or tester. 			
		Voltage: Battery voltage	SEC399C
OK or NG			
OK	▶	GO TO 4.	
NG	▶	GO TO 3.	

HEATED OXYGEN SENSOR 1 HEATER (FRONT)


Diagnostic Procedure (Cont'd)

3	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none"> ● Harness connectors F4, M60 ● Fuse block (J/B) connector M7 ● 10A fuse ● Harness for open or short between heated oxygen sensor 1 (front) and fuse 	
▶	Repair harness or connectors.

4	CHECK GROUND CIRCUIT
1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between HO2S1 terminal 3 and ECM terminal 111. Refer to wiring diagram. Continuity should exist.	
4. Also check harness for short to ground and short to power.	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

5	CHECK HEATED OXYGEN SENSOR 1 HEATER (FRONT)
Refer to "Component Inspection", EC-161.	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Replace heated oxygen sensor 1 (front).

6	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.	
▶	INSPECTION END



Component Inspection

HEATED OXYGEN SENSOR 1 HEATER (FRONT)

NMEC0738
NMEC0738S01

Check resistance between terminals 3 and 1.

Resistance: 2.3 - 4.3 Ω at 25°C (77°F)

Check continuity between terminals 2 and 1, 3 and 2.

Continuity should not exist.


If NG, replace the heated oxygen sensor 1 (front).

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool and approved anti-seize lubricant.

VEHICLE SPEED SENSOR (VSS)

Component Description



Component Description

The vehicle speed sensor is installed in the transaxle. It contains a pulse generator which provides a vehicle speed signal to the speedometer. The speedometer then sends a signal to the ECM.

NMEC0739

ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and ground.

NMEC0740

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
32	W/PU	Vehicle speed sensor	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Lift up the vehicle ● Shift gear "ON" ● Vehicle speed is 40 km/h (25 MPH) 	<p>2.0 - 3.0V</p> <p>SEC368C</p>


VEHICLE SPEED SENSOR (VSS)

Wiring Diagram




Wiring Diagram

=NMEC0741

EC-VSS-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



REFER TO THE FOLLOWING.

- (F4) -SUPER MULTIPLE JUNCTION (SMJ)
- (M6), (M7) -FUSE BLOCK-JUNCTION BOX (J/B)

TEC807

VEHICLE SPEED SENSOR (VSS)

Diagnostic Procedure

Diagnostic Procedure

NMEC0742

1	INSPECTION START	
Do you have CONSULT-II?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

2	CHECK OVERALL FUNCTION													
<p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Lift up the vehicle. 3. Start engine and let it idle. 4. Select "VHCL SPEED SE" in "DATA MONITOR" mode with CONSULT-II. 5. Check "VHCL SPEED SE" indication when rotating wheels with suitable gear position. 														
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="text-align: left;">MONITOR</th> <th style="text-align: left;">NO DTC</th> </tr> </thead> <tbody> <tr> <td>CMPS-RPM (REF)</td> <td>XXX rpm</td> </tr> <tr> <td>COOLAN TEMP/S</td> <td>XXX °C</td> </tr> <tr> <td>PW/ST SIGNAL</td> <td>OFF</td> </tr> <tr> <td>VHCL SPEED SE</td> <td>XXX km/h</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR	NO DTC	CMPS-RPM (REF)	XXX rpm	COOLAN TEMP/S	XXX °C	PW/ST SIGNAL	OFF	VHCL SPEED SE	XXX km/h
DATA MONITOR														
MONITOR	NO DTC													
CMPS-RPM (REF)	XXX rpm													
COOLAN TEMP/S	XXX °C													
PW/ST SIGNAL	OFF													
VHCL SPEED SE	XXX km/h													
<p>“VHCL SPEED SE” indication should exceed 10 km/h (6 MPH).</p>														
SEC421C														
OK or NG														
OK	▶	INSPECTION END												
NG	▶	GO TO 4.												

3	CHECK OVERALL FUNCTION					
<p> Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Lift up the vehicle. 3. Start engine and let it idle. 4. Read the voltage signal between ECM terminal 32 and ground with an oscilloscope. 5. Verify that the oscilloscope screen shows a signal wave as shown below under the following conditions. 						
<div style="display: flex; align-items: center; justify-content: space-around;"> <div style="text-align: center;"> </div> <table border="1" style="border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Conditions</th> <th style="width: 50%;">Voltage</th> </tr> </thead> <tbody> <tr> <td style="vertical-align: top;">Vehicle speed is 40 km/h (25 MPH).</td> <td style="text-align: center;"> </td> </tr> </tbody> </table> </div>			Conditions	Voltage	Vehicle speed is 40 km/h (25 MPH).	
Conditions	Voltage					
Vehicle speed is 40 km/h (25 MPH).						
SEC422C						
OK or NG						
OK	▶	INSPECTION END				
NG	▶	GO TO 4.				

VEHICLE SPEED SENSOR (VSS)

Diagnostic Procedure (Cont'd)

4	CHECK VEHICLE SPEED SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT	
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect ECM harness connector and combination meter harness connector.</p> <p>3. Check harness continuity between ECM terminal 32 and combination meter terminal 31. Refer to Wiring Diagram.</p> <p style="color: blue;">Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 6.
NG	▶	GO TO 5.

GI
MA
EM
LC

5	DETECT MALFUNCTIONING PART	
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F4, M60 ● Harness for open or short between ECM and combination meter 		
▶		Repair open circuit or short to ground or short to power in harness or connectors.

EC
FE

6	CHECK SPEEDOMETER FUNCTION	
<p>Make sure that speedometer functions properly.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 8.
NG	▶	GO TO 7.

CL
MT
AT

7	CHECK SPEEDOMETER CIRCUIT FOR OPEN AND SHORT	
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F4, M60 ● Harness for open or short between combination meter and ABS control unit <p style="text-align: center;">OK or NG</p>		
OK	▶	Check combination meter and vehicle speed sensor. Refer to EL section.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

PD
AX
SU
BR

8	CHECK INTERMITTENT INCIDENT	
<p>Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.</p>		
▶		INSPECTION END

ST
RS

BT
HA

SC
EL

IDX

IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

Description


Description SYSTEM DESCRIPTION

NMEC0743

NMEC0743S01

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	Idle air control	IACV-AAC valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
Park/Neutral position switch	Park/Neutral position		
Air conditioner switch	Air conditioner operation		
Power steering oil pressure switch	Power steering load signal		
Battery	Battery voltage		
Vehicle speed sensor	Vehicle speed		

This system automatically controls engine idle speed to a specified level. Idle speed is controlled through fine adjustment of the amount of air which bypasses the throttle valve via IACV-AAC valve. The IACV-AAC valve repeats ON/OFF operation according to the signal sent from the ECM. The camshaft position sensor detects the actual engine speed and sends a signal to the ECM. The ECM then controls the ON/OFF time of the IACV-AAC valve so that engine speed coincides with the target value memorized in ECM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ECM is determined by taking into consideration various engine conditions, such as during warm up, deceleration, and engine load (air conditioner and power steering).



COMPONENT DESCRIPTION

NMEC0743S02

IACV-AAC Valve

NMEC0743S0201

The IACV-AAC valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of air that will flow through the valve. The more air that flows through the valve, the higher the idle speed.

CONSULT-II Reference Value in Data Monitor Mode

NMEC0744

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
IACV-AAC/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load 	Idle
		2,000 rpm
		20 - 40%
		—

IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

ECM Terminals and Reference Value

ECM Terminals and Reference Value

NMEC0745

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
113	SB	IACV-AAC valve	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>Approximately 10V</p> <p>SEC372C</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed ● Both A/C switch and blower fan switch are "ON" (Compressor is operating) ● Rear window defogger switch is "ON". 	<p>Approximately 11V</p> <p>SEC373C</p>

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

Wiring Diagram

Wiring Diagram

NMEC0746

EC-AAC/V-01



REFER TO THE FOLLOWING.

- F4 -SUPER MULTIPLE JUNCTION (SMJ)
- M7 -FUSE BLOCK-JUNCTION BOX (J/B)

101	102	103	104	106	107	108	1	2	3	4	5	6	7	15	16	17	18	19	20	21	22	31	32	33	34	35	36	37	38	39	
109	110	111	112	113	114	115	116	8	9	10	11	12	13	14	23	24	25	26	27	28	29	30	40	41	42	43	44	45	46	47	48



TEC815

Diagnostic Procedure

NMEC0747

1	INSPECTION START	
Do you have CONSULT-II?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

GI
MA
EM

2	CHECK OVERALL FUNCTION																							
<p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Perform "IACV-AAC/V OPENING" in ACTIVE TEST mode with CONSULT-II. 3. Check engine speed varies corresponding to IACV-AAC VALVE opening percent. 																								
<table border="1" style="margin: auto; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">IACV-AAC/V ADJ</td></tr> <tr><td colspan="2" style="text-align: center;">ADJ MONITOR</td></tr> <tr><td style="text-align: center;">CKPS-RPM</td><td style="text-align: center;">XXX rpm</td></tr> <tr><td colspan="2" style="text-align: center;">CONDITION SETTING</td></tr> <tr><td style="text-align: center;">IACV-ACC/V</td><td style="text-align: center;">FIXED</td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td colspan="2" style="text-align: center;">MONITOR</td></tr> <tr><td style="text-align: center;">COOLAN TEMP/S</td><td style="text-align: center;">XXX° C</td></tr> <tr><td style="text-align: center;">CLSD THL POS</td><td style="text-align: center;">ON</td></tr> <tr><td> </td><td> </td></tr> </table>			IACV-AAC/V ADJ		ADJ MONITOR		CKPS-RPM	XXX rpm	CONDITION SETTING		IACV-ACC/V	FIXED					MONITOR		COOLAN TEMP/S	XXX° C	CLSD THL POS	ON		
IACV-AAC/V ADJ																								
ADJ MONITOR																								
CKPS-RPM	XXX rpm																							
CONDITION SETTING																								
IACV-ACC/V	FIXED																							
MONITOR																								
COOLAN TEMP/S	XXX° C																							
CLSD THL POS	ON																							
SEC334C																								
OK or NG																								
OK	▶	INSPECTION END																						
NG	▶	GO TO 4.																						



LC
EC
FE
CL
MT
AT
PD
AX

3	CHECK OVERALL FUNCTION	
<p> Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine and warm it up to normal operating temperature. 2. Check idle speed. <div style="margin-left: 20px;"> M/T: 800±50 rpm A/T: 800±50 rpm (in "P" or "N" position) </div> If NG, adjust idle speed. Refer to "Basic Inspection", EC-50. 3. Stop engine and disconnect throttle position sensor harness connector. 4. Restart engine and let it idle after revving it to 2,000 to 3,000 rpm a few times. 5. Check idle speed again. <div style="margin-left: 20px;"> 750±50 rpm </div> 		
OK or NG		
OK	▶	INSPECTION END
NG	▶	GO TO 4.

SU
BR
ST
RS
BT
HA
SC
EL
IDX

IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

Diagnostic Procedure (Cont'd)

4	CHECK POWER SUPPLY	<ol style="list-style-type: none"> 1. Stop engine. 2. Disconnect IACV-AAC valve harness connector. <div style="text-align: center; margin: 10px 0;">  </div> <ol style="list-style-type: none"> 3. Turn ignition switch "ON". 4. Check voltage between terminal 2 and ground with CONSULT-II or tester. <div style="text-align: center; margin: 10px 0;">  </div> <p style="text-align: right; margin-right: 20px;">SEC384C</p> <p style="text-align: right; margin-right: 20px;">SEC441C</p> <p style="text-align: center; margin-top: 10px;">Voltage: Battery voltage</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p>
OK	▶	GO TO 3.
NG	▶	GO TO 2.

5	DETECT MALFUNCTIONING PART	<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M60, F4 ● Fuse block (J/B) connector M7 ● 10A fuse ● Harness for open or short between IACV-AAC valve and fuse
	▶	Repair harness or connectors.

6	CHECK OUTPUT SIGNAL CIRCUIT	<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 113 and IACV-AAC valve terminal 1. Refer to Wiring Diagram. Continuity should exist. 4. Also check harness for short to ground and short to power. <p style="text-align: center; margin-top: 10px;">OK or NG</p>
OK	▶	GO TO 7.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

Diagnostic Procedure (Cont'd)

7	CHECK IACV-AAC VALVE
Refer to "Component Inspection", EC-172.	
OK or NG	
OK	▶ GO TO 8.
NG	▶ Replace IACV-AAC valve.

GI

MA

EM

8	CHECK INTERMITTENT INCIDENT
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.	
	▶ INSPECTION END

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

IDLE AIR CONTROL VALVE (IACV) — AUXILIARY AIR CONTROL (AAC) VALVE

Component Inspection



Component Inspection

IACV-AAC VALVE

=NMEC0748

NMEC0748S01

1. Disconnect IACV-AAC valve harness connector.
2. Remove IACV-AAC valve.
- Check IACV-AAC valve resistance.

Resistance:

Approximately 10 Ω [at 20°C (68°F)]


- Check plunger for seizing or sticking.
- Check for broken spring.
3. Supply battery voltage between IACV-AAC valve connector terminals.

Plunger should move.

If NG, replace IACV-AAC valve.

INTAKE VALVE TIMING CONTROL SOLENOID VALVE

Component Description




Component Description

NMEC0749

The valve timing control system is utilized to control intake valve opening and closing timing. Engine coolant temperature signals, engine speed and throttle position are used to determine intake valve timing.

The intake camshaft sprocket position is regulated by oil pressure controlled by the intake valve timing control.

When ECM sends ON signal to intake valve timing control solenoid valve, oil pressure is transmitted to camshaft sprocket. Then, intake side camshaft is advanced.



SEC450C

Operation

NMEC0750

Engine operating condition			Intake valve timing control solenoid valve	Intake valve opening and closing time	Valve overlap
Engine speed	B/FUEL SCHDL	Neutral switch			
Below 1,050 rpm	Above 1.3 msec (M/T)	OFF	ON	Advance	Increased
	Above 1.5 msec (A/T)				
1,050 - 5,700 rpm	—				
Conditions other than those above			OFF	Normal	Normal

INTAKE VALVE TIMING CONTROL SOLENOID VALVE

CONSULT-II Reference Value in Data Monitor Mode

CONSULT-II Reference Value in Data Monitor Mode

NMEC0751

MONITOR ITEM	CONDITION		SPECIFICATION
INT/V TIM SOL	<ul style="list-style-type: none"> ● Engine: After warming up ● Lift up drive wheels and shift to suitable gear position other than "P" or "N" 	Idle	OFF
		Quickly depress the accelerator pedal, then quickly release it.	OFF → ON → OFF

ECM Terminals and Reference Value

NMEC0752

Specification data are reference values and are measured between each terminal and engine ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
105	R/L	Intake valve timing control solenoid valve	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	BATTERY VOLTAGE (11 - 14V)


INTAKE VALVE TIMING CONTROL SOLENOID VALVE

Wiring Diagram

Wiring Diagram


NMEC0753

EC-IVC-01




: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



REFER TO THE FOLLOWING.
 (F4) -SUPER MULTIPLE JUNCTION (SMJ)
 (M7) -FUSE BLOCK-JUNCTION BOX (J/B)



TEC814

INTAKE VALVE TIMING CONTROL SOLENOID VALVE

Diagnostic Procedure

Diagnostic Procedure

NMEC0754

1	INSPECTION START	
Do you have CONSULT-II?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

2	CHECK OVERALL FUNCTION																									
<p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch "ON". 2. Select "VALVE TIMING SOL" in "ACTIVE TEST" mode with CONSULT-II. 3. Touch "ON" CONSULT-II screen. 																										
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> <tr> <th>VALVE TIMING SOL</th> <th>OFF</th> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <th>CMPS-RPM (REF)</th> <th>XXX rpm</th> </tr> <tr> <th>IACV-AAC/V</th> <th>XXX %</th> </tr> <tr> <td> </td> <td> </td> </tr> </thead> <tbody> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>			ACTIVE TEST		VALVE TIMING SOL	OFF	MONITOR		CMPS-RPM (REF)	XXX rpm	IACV-AAC/V	XXX %														
ACTIVE TEST																										
VALVE TIMING SOL	OFF																									
MONITOR																										
CMPS-RPM (REF)	XXX rpm																									
IACV-AAC/V	XXX %																									
<p>4. Check for operating sound of the intake valve timing control solenoid valve. Clicking noise should be heard.</p>																										
OK or NG																										
OK	▶	INSPECTION END																								
NG	▶	GO TO 4.																								



SEC437C

3	CHECK OVERALL FUNCTION							
<p> Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Lift up vehicle, start engine and warm it up to normal operation temperature. 2. Shift to a suitable gear position other than "P" or "N" position. 3. Check voltage between ECM terminal 105 (Intake valve timing control solenoid valve signal) and ground under the following conditions. 								
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th>Conditions</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>Not rewing engine.</td> <td>Approximately 0V</td> </tr> <tr> <td>Quickly depress accelerator pedal, then quickly release it.</td> <td>Battery voltage (Momentary)</td> </tr> </tbody> </table>			Conditions	Voltage	Not rewing engine.	Approximately 0V	Quickly depress accelerator pedal, then quickly release it.	Battery voltage (Momentary)
Conditions	Voltage							
Not rewing engine.	Approximately 0V							
Quickly depress accelerator pedal, then quickly release it.	Battery voltage (Momentary)							
OK or NG								
OK	▶	INSPECTION END						
NG	▶	GO TO 4.						

SEC438C

INTAKE VALVE TIMING CONTROL SOLENOID VALVE

Diagnostic Procedure (Cont'd)

4	CHECK POWER SUPPLY			
		<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect intake valve timing control solenoid valve harness connector. 	GI MA EM LC	
		 <p>Oil filler cap Intake valve timing control solenoid valve</p>	EC	
		<ol style="list-style-type: none"> Turn ignition switch "ON". Check voltage between terminal 2 and ground with CONSULT-II or tester. 	SEC385C FE	
		 <p>DISCONNECT T.S. Voltage: Battery voltage</p>	CL MT AT	
		OK or NG	PD	
	OK	▶	GO TO 6.	AX
	NG	▶	GO TO 5.	SU

5	DETECT MALFUNCTIONING PART			
		<p>Check the following.</p> <ul style="list-style-type: none"> Harness connector F4, M60 10A fuse Harness for open or short between valve timing control solenoid valve and fuse 	BR	
		▶	Repair harness or connectors.	ST


6	CHECK OUTPUT SIGNAL CIRCUIT			
		<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect ECM harness connector. Check harness continuity between ECM terminal 105 and intake valve timing control solenoid valve harness connector terminal 1. Refer to wiring diagram. Continuity should exist. Also check harness for short to ground and short to power. 	RS BT HA	
		OK or NG	SC	
	OK	▶	GO TO 7.	EL
	NG	▶	Repair open circuit or short to ground to short to power or connectors.	IDX

INTAKE VALVE TIMING CONTROL SOLENOID VALVE

Diagnostic Procedure (Cont'd)

7	CHECK VALVE TIMING CONTROL SOLENOID VALVE
Refer to "Component Inspection", EC-178.	
OK or NG	
OK	▶ GO TO 8.
NG	▶ Replace valve timing control solenoid valve.

8	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.	
	▶ INSPECTION END



Component Inspection

INTAKE VALVE TIMING CONTROL SOLENOID VALVE

NMEC0755
NMEC0755S01

1. Check oil passage visually for any metal debris.
2. Supply intake valve timing control solenoid valve terminals with battery voltage.
3. Make sure that inside plunger protrudes.
If NG, replace intake valve timing control solenoid valve.

WASTEGATE VALVE CONTROL SOLENOID VALVE

Description

Description SYSTEM DESCRIPTION

NMEC0756

NMEC0756S01

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	Charged air pressure control	Wastegate valve control solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Throttle position sensor	Throttle position		
Park/Neutral position switch	Park/Neutral position		
Battery	Battery voltage		
Vehicle speed sensor	Vehicle speed		
Knock sensor	Engine knocking condition		

GI

MA

EM


LC

EC

FE

CL

MT




This system controls charged air pressure corresponding to the driving conditions through wastegate valve control solenoid valve. The wastegate valve control solenoid valve repeats ON/OFF operation according to the signal sent from the ECM. The ECM controls the ON/OFF time of the wastegate valve control solenoid valve according to the data memorized in the ECM. The optimum value stored in the ECM is determined by taking into consideration various engine conditions, such as engine speed, throttle valve opening angle, gear position, etc., and fuel octane rating. Knock sensor signal is used to determine the fuel octane rating.

AT

PD

AX

SU



COMPONENT DESCRIPTION

NMEC0756S02

Wastegate Valve Control Solenoid Valve

NMEC0756S0201

The wastegate valve control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the higher the charged air pressure is provided.

BR

ST

RS

BT

CONSULT-II Reference Value in Data Monitor Mode

NMEC0757

MONITOR ITEM	CONDITION	SPECIFICATION
W/G CONT S/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: N ● No-load 	Idle
		Revsing engine up to 4,000 rpm
		0%
		20%

SC

EL

IDX

WASTEGATE VALVE CONTROL SOLENOID VALVE

ECM Terminals and Reference Value

ECM Terminals and Reference Value

=NMEC0758

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
115	OR/B	Wastegate valve control solenoid valve	[Engine is running] <ul style="list-style-type: none">● Idle speed	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] <ul style="list-style-type: none">● Warm-up condition● Rev engine up to 4,000 rpm	Approximately 0V


WASTEGATE VALVE CONTROL SOLENOID VALVE

Wiring Diagram

Wiring Diagram


NMEC0759

EC-WG/V-01




: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



REFER TO THE FOLLOWING.

- (F4) -SUPER MULTIPLE JUNCTION (SMJ)
- (M7) -FUSE BLOCK-JUNCTION BOX (J/B)





TEC813

WASTEGATE VALVE CONTROL SOLENOID VALVE

Diagnostic Procedure

Diagnostic Procedure


NMEC0760


1	CHECK OVERALL FUNCTION								
<p>1. Turn ignition switch "OFF". 2. Disconnect air passage hose connected to wastegate valve control solenoid valve.</p>									
									
SEC394C									
<p>3. Start engine. 4. Make sure that charged air pressure exists under the following conditions.</p>									
<p>Air passage hose connected to wastegate valve actuator</p> 									
<table border="1" style="margin: auto;"> <thead> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Charged air pressure</th> </tr> </thead> <tbody> <tr> <td>At idle</td> <td>Should not exist.</td> </tr> <tr> <td>Engine speed is about 2,000 rpm.</td> <td>Should exist.</td> </tr> </tbody> </table>				Condition	Charged air pressure	At idle	Should not exist.	Engine speed is about 2,000 rpm.	Should exist.
Condition	Charged air pressure								
At idle	Should not exist.								
Engine speed is about 2,000 rpm.	Should exist.								
SEC395C									
OK or NG									
OK	▶	GO TO 2.							
NG (With CONSULT-II)	▶	GO TO 3.							
NG (Without CONSULT-II)	▶	GO TO 4.							

2	CHECK WASTEGATE VALVE ACTUATOR		
<p>1. Stop engine. 2. Check wastegate valve actuator. Refer to EM-62, "WASTEGATE VALVE ACTUATOR".</p>			
OK or NG			
OK	▶	INSPECTION END	
NG	▶	Replace wastegate valve actuator.	

WASTEGATE VALVE CONTROL SOLENOID VALVE

Diagnostic Procedure (Cont'd)


3	CHECK WASTEGATE VALVE CONTROL SOLENOID VALVE CIRCUIT																					
<p>With CONSULT-II</p> <ol style="list-style-type: none"> Turn ignition switch "ON". Select "TURBOCHARGE PRES" in ACTIVE TEST mode with CONSULT-II. Check wastegate valve control solenoid valve operating sound when touching "Qd" and "Qu" on the CONSULT-II screen. 																						
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">ACTIVE TEST</th> </tr> </thead> <tbody> <tr> <td>TURBOCHARGE PRES</td> <td>XXX %</td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <td>CMPS-RPM(REF)</td> <td>XXXrpm</td> </tr> <tr> <td>MAS AIR/FL SE</td> <td>XXXV</td> </tr> <tr> <td>INJ PULSE</td> <td>XXXmsec</td> </tr> <tr> <td>IGN TIMING</td> <td>XXXBTDC</td> </tr> <tr> <td>W/G CONT S/V</td> <td>XXX%</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>			ACTIVE TEST		TURBOCHARGE PRES	XXX %	MONITOR		CMPS-RPM(REF)	XXXrpm	MAS AIR/FL SE	XXXV	INJ PULSE	XXXmsec	IGN TIMING	XXXBTDC	W/G CONT S/V	XXX%				
ACTIVE TEST																						
TURBOCHARGE PRES	XXX %																					
MONITOR																						
CMPS-RPM(REF)	XXXrpm																					
MAS AIR/FL SE	XXXV																					
INJ PULSE	XXXmsec																					
IGN TIMING	XXXBTDC																					
W/G CONT S/V	XXX%																					
 <p style="text-align: right;">Wastegate valve control solenoid valve</p> <p style="text-align: right;">SEC396C</p>																						
<p>Clicking sound should be heard.</p> <p style="text-align: center;">OK or NG</p>																						
OK	▶	GO TO 5.																				
NG	▶	GO TO 6.																				


4	CHECK WASTEGATE VALVE CONTROL SOLENOID VALVE CIRCUIT	
<p>Without CONSULT-II</p> <ol style="list-style-type: none"> Start engine. Check wastegate valve control solenoid valve operating sound when revving engine up to 2,000 rpm and returning it to idle. 		
 <p style="text-align: right;">Wastegate valve control solenoid valve</p> <p style="text-align: right;">SEC397C</p>		
<p>Clicking sound should be heard.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 5.
NG	▶	GO TO 6.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

WASTEGATE VALVE CONTROL SOLENOID VALVE

Diagnostic Procedure (Cont'd)

5	CHECK AIR PASSAGE HOSES	<p>Check air passage hoses for clogging, cracks and improper connections. Refer to "Vacuum Hose Drawing", EC-16.</p> <div style="text-align: center;">  <p>Crack</p> <p>Clogging</p> <p>Improper connection</p> </div> <p style="text-align: right;">SEF816F</p> <p style="text-align: center;">OK or NG</p>	
OK	▶	GO TO 10.	
NG	▶	Repair or replace air passage hoses.	

6	CHECK POWER SUPPLY CIRCUIT	<p>1. Turn ignition switch "OFF". 2. Disconnect wastegate valve control solenoid valve harness connector. 3. Turn ignition switch "ON". 4. Check voltage between wastegate valve control solenoid valve terminal 1 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  <p style="text-align: right;">SEC451C</p> </div> <p style="color: blue;">Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p>	
OK	▶	GO TO 8.	
NG	▶	GO TO 7.	

7	DETECT MALFUNCTIONING PART	<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M60, F4 ● Fuse block (J/B) connector M7 ● Harness for open and short between wastegate valve control solenoid valve and fuse 	
	▶	Repair open circuit or short to ground or short to power in harness or connectors.	


WASTEGATE VALVE CONTROL SOLENOID VALVE

Diagnostic Procedure (Cont'd)

8	CHECK OUTPUT SIGNAL CIRCUIT	
1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between ECM terminal 115 and wastegate valve control solenoid valve terminal 2. Refer to Wiring Diagram. Continuity should exist.		
OK or NG		
OK	▶	GO TO 9.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

9	CHECK WASTEGATE VALVE CONTROL SOLENOID VALVE	
Refer to "Component Inspection", EC-185.		
OK or NG		
OK	▶	GO TO 10.
NG	▶	Replace wastegate valve control solenoid valve.

10	CHECK INTERMITTENT INCIDENT	
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.		
	▶	INSPECTION END



Component Inspection

WASTEGATE VALVE CONTROL SOLENOID VALVE

NMEC0761

NMEC0761S01

Check air passage continuity under the following conditions.


Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	No
No supply	Yes

If NG, replace wastegate valve control solenoid valve.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

PARK/NEUTRAL POSITION (PNP) SWITCH

Component Description



Component Description

When the gear position is "P" or "N", park/neutral position (PNP) switch is "ON".
ECM detects the park/neutral position when continuity with ground exists.

NMEC0762

CONSULT-II Reference Value in Data Monitor Mode

NMEC0763

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
P/N POSI SW	● Ignition switch: ON	ON
	Except above	OFF

ECM Terminals and Reference Value

NMEC0764

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
35	R/G (A/T) G/OR (M/T)	PNP switch	[Ignition switch "ON"] ● Gear position is "N" or "P" (A/T models) ● Gear position is in neutral position (M/T models)	Approximately 0V
			[Ignition switch "ON"] ● Except the above gear position	BATTERY VOLTAGE (11 - 14V)

PARK/NEUTRAL POSITION (PNP) SWITCH



Wiring Diagram

Wiring Diagram

NMEC0765

EC-PNP/SW-01

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



REFER TO THE FOLLOWING.
 (E101), (F4) -SUPER MULTIPLE JUNCTION (SMJ)
 (E105) -FUSE BLOCK-JUNCTION BOX (J/B)

PARK/NEUTRAL POSITION (PNP) SWITCH

Diagnostic Procedure


Diagnostic Procedure FOR M/T MODELS

NMEC0766

NMEC0766S01

1	INSPECTION START	
Do you have CONSULT-II?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

2	CHECK OVERALL FUNCTION							
<p> With CONSULT-II</p> <ol style="list-style-type: none"> Turn ignition switch "ON". Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT-II. Check the "P/N POSI SW" signal under the following conditions. 								
<table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th>NO DTC</th> </tr> </thead> <tbody> <tr> <td>P/N POSI SW</td> <td>ON</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR	NO DTC	P/N POSI SW	ON
DATA MONITOR								
MONITOR	NO DTC							
P/N POSI SW	ON							
<table border="1" style="margin: auto;"> <tbody> <tr> <td>Shift lever position</td> <td>P/N POSI SW</td> </tr> <tr> <td>Neutral position</td> <td>ON</td> </tr> <tr> <td>Except the above position</td> <td>OFF</td> </tr> </tbody> </table>			Shift lever position	P/N POSI SW	Neutral position	ON	Except the above position	OFF
Shift lever position	P/N POSI SW							
Neutral position	ON							
Except the above position	OFF							
SEF049Y								
OK or NG								
OK	▶	INSPECTION END						
NG	▶	GO TO 4.						

3	CHECK OVERALL FUNCTION							
<p> Without CONSULT-II</p> <ol style="list-style-type: none"> Turn ignition switch "ON". Check voltage between ECM terminal 35 and ground under the following conditions. 								
								
<table border="1" style="margin: auto;"> <tbody> <tr> <td>Shift lever position</td> <td>Voltage</td> </tr> <tr> <td>Neutral position</td> <td>Apporox. 0V</td> </tr> <tr> <td>Except the above position</td> <td>Battery voltage</td> </tr> </tbody> </table>			Shift lever position	Voltage	Neutral position	Apporox. 0V	Except the above position	Battery voltage
Shift lever position	Voltage							
Neutral position	Apporox. 0V							
Except the above position	Battery voltage							
SEC432C								
OK or NG								
OK	▶	INSPECTION END						
NG	▶	GO TO 4.						

PARK/NEUTRAL POSITION (PNP) SWITCH

Diagnostic Procedure (Cont'd)

4	CHECK PNP SWITCH GROUND CIRCUIT FOR OPEN AND SHORT	
<p>1. Turn ignition switch "OFF".</p> <p>2. Disconnect park/neutral position (PNP) switch harness connector.</p> <p>3. Check harness continuity between PNP switch terminal 2 and body ground. Refer to Wiring Diagram. Continuity should exist.</p> <p>4. Also check harness for short to power.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 6.
NG	▶	GO TO 5.

GI
MA
EM
LC

5	DETECT MALFUNCTIONING PART	
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors E26, E201 ● Harness for open or short between PNP switch and body ground 		
▶		Repair open circuit or short to power in harness or connectors.

EC
FE

6	CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT	
<p>1. Disconnect ECM harness connector.</p> <p>2. Check harness continuity between ECM terminal 35 and PNP switch terminal 1. Refer to Wiring Diagram. Continuity should exist.</p> <p>3. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 8.
NG	▶	GO TO 7.

CL
MT
AT
PD

7	DETECT MALFUNCTIONING PART	
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors M10, E101 ● Harness connectors E26, E201 ● Harness for open or short between ECM and PNP switch 		
▶		Repair open circuit or short to ground or short to power in harness or connectors.

AX
SU
BR

8	CHECK PARK/NEUTRAL POSITION (PNP) SWITCH	
<p>Refer to MT-8, "Position Switch Check".</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 9.
NG	▶	Replace park/neutral position (PNP) switch.

ST
RS
BT

9	CHECK INTERMITTENT INCIDENT	
<p>Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.</p>		
▶		INSPECTION END

HA
SC
EL
IDX

PARK/NEUTRAL POSITION (PNP) SWITCH


Diagnostic Procedure (Cont'd)

FOR A/T MODELS

=NMEC0766S02

1	INSPECTION START	
Do you have CONSULT-II?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

2	CHECK OVERALL FUNCTION							
<p> With CONSULT-II</p> <p>1. Turn ignition switch "ON". 2. Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT-II. 3. Check the "P/N POSI SW" signal under the following conditions.</p>								
<table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th>NO DTC</th> </tr> </thead> <tbody> <tr> <td>P/N POSI SW</td> <td>ON</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR	NO DTC	P/N POSI SW	ON
DATA MONITOR								
MONITOR	NO DTC							
P/N POSI SW	ON							
<table border="1" style="margin: auto;"> <thead> <tr> <th>Selector lever position</th> <th>P/N POSI SW</th> </tr> </thead> <tbody> <tr> <td>"N" and "P" position</td> <td>ON</td> </tr> <tr> <td>Except the above position</td> <td>OFF</td> </tr> </tbody> </table>			Selector lever position	P/N POSI SW	"N" and "P" position	ON	Except the above position	OFF
Selector lever position	P/N POSI SW							
"N" and "P" position	ON							
Except the above position	OFF							
SEF028Y								
OK or NG								
OK	▶	INSPECTION END						
NG	▶	GO TO 4.						


3	CHECK OVERALL FUNCTION							
<p> Without CONSULT-II</p> <p>1. Turn ignition switch "ON". 2. Check voltage between ECM terminal 35 and ground under the following conditions.</p>								
								
<table border="1" style="margin: auto;"> <thead> <tr> <th>Selector lever position</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>"P" and "N" position</td> <td>Apporox. 0V</td> </tr> <tr> <td>Except the above position</td> <td>Battery voltage</td> </tr> </tbody> </table>			Selector lever position	Voltage	"P" and "N" position	Apporox. 0V	Except the above position	Battery voltage
Selector lever position	Voltage							
"P" and "N" position	Apporox. 0V							
Except the above position	Battery voltage							
SEC433C								
OK or NG								
OK	▶	INSPECTION END						
NG	▶	GO TO 5.						

PARK/NEUTRAL POSITION (PNP) SWITCH

Diagnostic Procedure (Cont'd)


4	CHECK PARK/NEUTRAL POSITION (PNP) SWITCH CIRCUIT						
<p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Select "A/T", then "DATA MONITOR" with CONSULT-II. 2. Select "P/N POSI SW" signal, and check it under the following conditions. 							
<table border="1" style="margin: auto; border-collapse: collapse;"> <tr><th colspan="2">DATA MONITOR</th></tr> <tr><th>MONITORING</th><th>NO FAIL</th></tr> <tr><td>P/N POSI SW</td><td>ON</td></tr> </table>		DATA MONITOR		MONITORING	NO FAIL	P/N POSI SW	ON
DATA MONITOR							
MONITORING	NO FAIL						
P/N POSI SW	ON						
PEF963N							
<table border="1" style="margin: auto; border-collapse: collapse;"> <tr><th>Condition (Gear position)</th><th>P/N POSI SW</th></tr> <tr><td>"P" or "N" position</td><td>ON</td></tr> <tr><td>Other positions</td><td>OFF</td></tr> </table>		Condition (Gear position)	P/N POSI SW	"P" or "N" position	ON	Other positions	OFF
Condition (Gear position)	P/N POSI SW						
"P" or "N" position	ON						
Other positions	OFF						
MTBL0126							
OK or NG							
OK	▶	GO TO 10.					
NG	▶	GO TO 6.					

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

5	CHECK PARK/NEUTRAL POSITION (PNP) SWITCH CIRCUIT						
<p> Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Disconnect TCM (Transmission control module) harness connector. 3. Turn ignition switch "ON". 4. Check voltage between TCM terminal 36 and ground under the following conditions. 							
							
SEF073W							
<table border="1" style="margin: auto; border-collapse: collapse;"> <tr><th>Condition (Gear position)</th><th>Voltage</th></tr> <tr><td>"P" or "N" position</td><td>Battery voltage</td></tr> <tr><td>Other positions</td><td>0V</td></tr> </table>		Condition (Gear position)	Voltage	"P" or "N" position	Battery voltage	Other positions	0V
Condition (Gear position)	Voltage						
"P" or "N" position	Battery voltage						
Other positions	0V						
MTBL0647							
OK or NG							
OK	▶	GO TO 10.					
NG	▶	GO TO 6.					


PARK/NEUTRAL POSITION (PNP) SWITCH

Diagnostic Procedure (Cont'd)

6	CHECK POWER SUPPLY
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Disconnect park/neutral position (PNP) switch harness connector. 3. Turn ignition switch "ON". 4. Check voltage between terminal 3 and ground with CONSULT-II or tester. 	
	
<p>Voltage: Battery voltage</p> <p>OK or NG</p>	
OK	▶ GO TO 8.
NG	▶ GO TO 7.

SEC434C

7	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Fuse block (J/B) connector E105 ● 10 A fuse ● Harness for open or short between park/neutral position (PNP) switch and fuse 	
▶	Repair harness or connectors.

8	CHECK INPUT SIGNAL CIRCUIT-I
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Disconnect TCM (Transmission control module) harness connector. 3. Check harness continuity between TCM terminal 36 and switch terminals 4, 6. 	
	
<p>Continuity should exist.</p> <p>OK or NG</p>	
<p>4. Also check harness for short to ground and short to power.</p>	
OK	▶ GO TO 9.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

SEC435C

PARK/NEUTRAL POSITION (PNP) SWITCH

Diagnostic Procedure (Cont'd)

9	CHECK PARK/NEUTRAL POSITION (PNP) SWITCH	
Refer to "PARK/NEUTRAL POSITION SWITCH", AT-196.		
OK or NG		
OK	▶	GO TO 10.
NG	▶	Replace park/neutral position (PNP) switch.

GI

MA

EM

10	CHECK INPUT SIGNAL CIRCUIT-II	
<ol style="list-style-type: none"> 1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector and TCM (Transmission control module) harness connector. 3. Check harness continuity between ECM terminal 35 and TCM terminal 14. Refer to Wiring Diagram. Continuity should exist. 4. Also check harness for short to ground and short to power. 		
OK or NG		
OK	▶	GO TO 12.
NG	▶	GO TO 11.

LC

EC

FE

11	DETECT MALFUNCTIONING PART	
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F4, M60 ● Harness for open or short between ECM and TCM 		
OK or NG		
		▶ Repair open circuit or short to ground or short to power in harness or connectors.

CL

MT

AT

12	CHECK INTERMITTENT INCIDENT	
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.		
		▶ INSPECTION END

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

INJECTOR

Component Description



Component Description

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the injector circuit, the coil in the injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the injector into the intake manifold. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.

NMEC0767

CONSULT-II Reference Value in Data Monitor Mode

NMEC0768

MONITOR ITEM	CONDITION		SPECIFICATION
INJ PULSE	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: "N" ● No-load 	Idle	1.7 - 2.5 msec
		2,000 rpm	1.5 - 2.3 msec

ECM Terminals and Reference Value

NMEC0769

Specification data are reference values and are measured between each terminal and ground.

CAUTION:


Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	
101	W/B	Injector No. 1	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	BATTERY VOLTAGE (11 - 14V) SEC369C	
110	L/R	Injector No. 2		[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	BATTERY VOLTAGE (11 - 14V) SEC371C
103	G/B	Injector No. 3			
112	L/B	Injector No. 4			

Wiring Diagram


NMEC0770

EC-INJECT-01




: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



REFER TO THE FOLLOWING.

- (F4) -SUPER MULTIPLE JUNCTION (SMJ)
- (M7) -FUSE BLOCK-JUNCTION BOX (J/B)



INJECTOR

Diagnostic Procedure

NMEC0771

1 CHECK OVERALL FUNCTION

 **With CONSULT-II**

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.


ACTIVE TEST	
POWER BALANCE	
MONITOR	
CMPS~RPM(REF)	XXX rpm
MAS AIR/FL SE	XXX V
IACV-AAC/V	XXX %

PEF389V

3. Make sure that each circuit produces a momentary engine speed drop.

 **Without CONSULT-II**

1. Start engine.
2. Listen to each injector operating sound.



MEC703B

Clicking noise should be heard.



OK or NG

OK ► INSPECTION END

NG ► GO TO 2.

INJECTOR

Diagnostic Procedure (Cont'd)

2	CHECK POWER SUPPLY
<p>1. Stop engine. 2. Disconnect injector harness connector.</p> <div style="text-align: center;">  <p>Intake manifold collector Injector No. 1 harness connector</p> </div> <p>3. Turn ignition switch "ON". 4. Check voltage between terminal 2 and ground with CONSULT-II or tester.</p> <div style="text-align: center;">  </div> <p>Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ GO TO 3.

SEC392C

SEF078W

3	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● 10A fuse ● Harness connectors M60, F4 ● Harness connectors F27, F111 ● Harness for open or short between injector and fuse 	
▶	Repair harness or connectors.


4	CHECK OUTPUT SIGNAL CIRCUIT
<p>1. Turn ignition switch "OFF". 2. Disconnect ECM harness connector. 3. Check harness continuity between injector harness connector terminal 1 and ECM terminals 101, 103, 110, 112. Refer to wiring diagram. Continuity should exist.</p> <p>4. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

INJECTOR

Diagnostic Procedure (Cont'd)

5	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none">● Harness connectors F27, F111● Harness for open or short between ECM and injector.	
▶	Repair open circuit or short to ground or short to power in harness or connectors.
6	CHECK INJECTOR
Refer to "Component Inspection", EC-198.	
OK or NG	
OK	▶ GO TO 7.
NG	▶ Replace injector.
7	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.	
▶	INSPECTION END



Component Inspection INJECTOR

NMEC0772

NMEC0772S01

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.

Resistance: Approximately 11Ω [at 20°C (68°F)]

If NG, replace injector.

START SIGNAL

CONSULT-II Reference Value in Data Monitor Mode

CONSULT-II Reference Value in Data Monitor Mode

NMEC0773

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
START SIGNAL	● Ignition switch: ON → START → ON	OFF → ON → OFF

ECM Terminals and Reference Value

NMEC0774

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
34	OR/L	Start signal	[Ignition switch "ON"]	Approximately 0V
			[Ignition switch "START"]	9 - 12V

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


START SIGNAL

Wiring Diagram


Wiring Diagram

NMEC0775

EC-S/SIG-01




: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

- (F4) -SUPER MULTIPLE JUNCTION (SMJ)
- (M7), (E104) -FUSE BLOCK-JUNCTION BOX (J/B)



TEC810

START SIGNAL

Diagnostic Procedure

Diagnostic Procedure


=NMEC0776

1	INSPECTION START	
Do you have CONSULT-II?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

GI
MA
EM

2	CHECK OVERALL FUNCTION							
<p> With CONSULT-II</p> <p>1. Turn ignition switch "ON".</p> <p>2. Check "START SIGNAL" in "DATA MONITOR" mode with CONSULT-II under the following conditions.</p>								
<table border="1" style="margin: 0 auto;"> <tr><th colspan="2">DATA MONITOR</th></tr> <tr><th>MONITOR</th><th>NO DTC</th></tr> <tr><td>START SIGNAL</td><td>OFF</td></tr> </table>			DATA MONITOR		MONITOR	NO DTC	START SIGNAL	OFF
DATA MONITOR								
MONITOR	NO DTC							
START SIGNAL	OFF							
<table border="1" style="margin: 0 auto;"> <tr><th>Condition</th><th>"START SIGNAL"</th></tr> <tr><td>Ignition switch "ON"</td><td>OFF</td></tr> <tr><td>Ignition switch "START"</td><td>ON</td></tr> </table>			Condition	"START SIGNAL"	Ignition switch "ON"	OFF	Ignition switch "START"	ON
Condition	"START SIGNAL"							
Ignition switch "ON"	OFF							
Ignition switch "START"	ON							
SEF227Y								
OK or NG								
OK	▶	INSPECTION END						
NG	▶	GO TO 4.						

LC
EC
FE
CL
MT
AT

3	CHECK OVERALL FUNCTION							
<p> Without CONSULT-II</p> <p>1. Turn ignition switch to "START".</p> <p>2. Check voltage between ECM terminal 34 and ground under the following conditions.</p>								
								
<table border="1" style="margin: 0 auto;"> <tr><th>Condition</th><th>Voltage</th></tr> <tr><td>Ignition switch "START"</td><td>Battery Voltage</td></tr> <tr><td>Except above</td><td>Approximately 0V</td></tr> </table>			Condition	Voltage	Ignition switch "START"	Battery Voltage	Except above	Approximately 0V
Condition	Voltage							
Ignition switch "START"	Battery Voltage							
Except above	Approximately 0V							
SEC423C								
OK or NG								
OK	▶	INSPECTION END						
NG	▶	GO TO 4.						

AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

START SIGNAL

Diagnostic Procedure (Cont'd)

4	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none">● Harness connectors M60, F4● Fuse block (J/B) connectors M7, E104● 10A fuse● Harness for open or short between ECM and ignition switch	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.
5	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.	
	▶ INSPECTION END

FUEL PUMP

System Description


System Description

NMEC0777

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor	Engine speed	Fuel pump control	Fuel pump relay
Ignition switch	Ignition signal and start signal		

The ECM activates the fuel pump for several seconds after the ignition switch is turned on to improve engine startability. If the ECM receives a 180° signal from the camshaft position sensor, it knows that the engine is rotating, and causes the pump to perform. If the 180° signal is not received when the ignition switch is on, the engine stalls. The ECM stops pump operation and prevents battery discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 1 second
Engine running and cranking	Operates
When engine is stopped (Signal is not sent from camshaft position sensor.)	Stops in 1 second
Except as shown above	Stops



Component Description

A turbine type design fuel pump is used in the fuel tank.

NMEC0778

CONSULT-II Reference Value in Data Monitor Mode

NMEC0779

MONITOR ITEM	CONDITION	SPECIFICATION
FUEL PUMP RLY	<ul style="list-style-type: none"> Ignition switch is turned to ON (Operates for 1 second) Engine running and cranking When engine is stopped (stops in 1 second) 	ON
	<ul style="list-style-type: none"> Except as shown above 	OFF

FUEL PUMP

ECM Terminals and Reference Value

ECM Terminals and Reference Value

=NMEC0780

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
106	B/P	Fuel pump relay	[Ignition switch "ON"] ● For 1 second after turning ignition switch "ON" [Engine is running]	0 - 1V
			[Ignition switch "ON"] ● More than 1 second after turning ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)



FUEL PUMP

Diagnostic Procedure

Diagnostic Procedure

NMEC0782

1	CHECK OVERALL FUNCTION		
<p>1. Turn ignition switch "ON". 2. Pinch fuel feed hose with fingers.</p>			
			
SEC387C			
<p>Fuel pressure pulsation should be felt on the fuel feed hose for 1 second after ignition switch is turned "ON".</p> <p>OK or NG</p>			
OK	▶	INSPECTION END	
NG	▶	GO TO 2.	

2	CHECK POWER SUPPLY		
<p>1. Turn ignition switch "OFF". 2. Disconnect fuel pump relay.</p>			
<p>View with dash side lower finisher RH removed</p> 			
SEC388C			
<p>3. Turn ignition switch "ON". 4. Check voltage between terminals 2, 3 and ground with CONSULT-II or tester.</p>			
			
SEC424C			
<p>OK or NG</p>			
OK	▶	GO TO 4.	
NG	▶	GO TO 3.	


FUEL PUMP

Diagnostic Procedure (Cont'd)

3	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● 15A fuse ● Harness for open or short between fuse and fuel pump relay 	
▶	Repair harness or connectors.

GI

MA

4	CHECK POWER GROUND CIRCUIT
<p>1. Turn ignition switch "OFF". 2. Disconnect fuel pump harness connector.</p>	
<p>View with trunk room floor trim removed.</p> 	
<p>3. Check harness continuity between fuel pump terminal 2 and body ground, fuel pump terminal 1 and fuel pump relay terminal 5. Refer to wiring diagram. Continuity should exist.</p>	
<p>4. Also check harness for short to ground and short to power.</p>	
OK or NG	
OK	▶ GO TO 6.
NG	▶ GO TO 5.

EM

LC

EC

FE

CL

SEC389C

MT

AT

PD

AX

5	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors B24, T1 ● Harness for open or short between fuel pump and body ground ● Harness for open or short between fuel pump and fuel pump relay 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

SU

BR

ST

6	CHECK OUTPUT SIGNAL CIRCUIT
<p>1. Disconnect ECM harness connector. 2. Check harness continuity between ECM terminal 106 and fuel pump relay connector terminal 1. Refer to wiring diagram. Continuity should exist.</p>	
<p>3. Also check harness for short to ground and short to power.</p>	
OK or NG	
OK	▶ GO TO 8.
NG	▶ GO TO 7.

RS

BT

HA

SC


EL

IDX

FUEL PUMP

Diagnostic Procedure (Cont'd)

7	DETECT MALFUNCTIONING PART
Check the following. <ul style="list-style-type: none"> ● Harness connectors B1, M8 ● Harness connectors M60, F4 ● Harness for open or short between ECM and fuel pump relay 	
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.
8	CHECK FUEL PUMP RELAY
Refer to "Component Inspection", EC-208.	
OK or NG	
OK	▶ GO TO 9.
NG	▶ Replace fuel pump relay.
9	CHECK FUEL PUMP
Refer to "Component Inspection", EC-208.	
OK or NG	
OK	▶ GO TO 10.
NG	▶ Replace fuel pump.
10	CHECK INTERMITTENT INCIDENT
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.	
	▶ INSPECTION END



Component Inspection FUEL PUMP RELAY


NMEC0783

NMEC0783S01

Check continuity between terminals 3 and 5.

Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

If NG, replace relay.



FUEL PUMP

NMEC0783S02


1. Disconnect fuel pump harness connector.
2. Check resistance between terminals 1 and 2.

Resistance: 0.2 - 5.0Ω [at 25°C (77°F)]

If NG, replace fuel pump.

IACV-FICD SOLENOID VALVE

Component Description



Component Description

NMEC0784

When the air conditioner is on, the IACV-FICD solenoid valve supplies additional air to adjust to the increased load.

GI
MA
EM
LC

ECM Terminals and Reference Value

NMEC0785

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

EC
FE

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
11	G	Air conditioner relay	[Engine is running] ● Both A/C switch and blower fan switch are "ON"	0 - 1V
			[Engine is running] ● A/C switch is "OFF"	BATTERY VOLTAGE (11 - 14V)
41	L/B	Air conditioner switch	[Engine is running] ● Both A/C switch and blower fan switch are "ON" (Compressor operates)	Approximately 0V
			[Engine is running] ● Air conditioner switch is "OFF"	Approximately 5V

CL
MT
AT
PD
AX

SU
BR
ST
RS
BT
HA
SC
EL
IDX



IACV-FICD SOLENOID VALVE

Wiring Diagram

Wiring Diagram


NMEC0786

EC-FICD-01



REFER TO THE FOLLOWING.


(E101), (F4) -SUPER
MULTIPLE JUNCTION (SMJ)
(M6), (E105) -FUSE BLOCK-
JUNCTION BOX (J/B)




TEC816

Diagnostic Procedure

=NMEC0787

1	CHECK OVERALL FUNCTION	
<p>1. Start engine and warm it up to normal operating temperature. 2. Check idle speed. 800±50 rpm (in "N" position) If NG, adjust idle speed. 3. Turn air conditioner switch and blower fan switch "ON". 4. Recheck idle speed.</p>		
		
<p>800 rpm or more (in "P" or "N" position)</p> <p>SEF742U</p> <p>OK or NG</p>		
OK	▶	INSPECTION END
NG	▶	GO TO 2.

2	CHECK AIR CONDITIONER FUNCTION	
<p>Check if air conditioner compressor functions normally.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 3.
NG	▶	Refer to "TROUBLE DIAGNOSES", HA-19.



3	CHECK POWER SUPPLY	
<p>1. Turn air conditioner switch and blower fan switch "OFF". 2. Stop engine. 3. Disconnect IACV-FICD solenoid valve harness connector.</p>		
		
SEC384C		
<p>4. Disconnect A/C relay. 5. Check harness continuity between A/C relay terminal 3 and IACV-FICD solenoid valve terminal 2. Refer to Wiring Diagram. Continuity should exist. 6. Also check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 5.
NG	▶	GO TO 4.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

IACV-FICD SOLENOID VALVE

Diagnostic Procedure (Cont'd)

4	DETECT MALFUNCTIONING PART
Check the following.	
<ul style="list-style-type: none"> • Harness for open or short between IACV-FICD solenoid valve and harness connector F4 	
	▶ Repair harness or connectors.
5	CHECK GROUND CIRCUIT
1. Check harness continuity between IACV-FICD solenoid valve terminal 1 and engine ground. Refer to Wiring Diagram.	
Continuity should exist.	
2. Also check harness for short to power.	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Repair open circuit or short to power in harness or connectors.
6	CHECK IACV-FICD SOLENOID VALVE
Refer to "Component Inspection", EC-212.	
OK or NG	
OK	▶ GO TO 7.
NG	▶ Replace IACV-FICD solenoid valve.
7	CHECK INTERMITTENT INCIDENT
Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.	
	▶ INSPECTION END



Component Inspection IACV-FICD SOLENOID VALVE

NMEC0788


NMEC0788S01

Disconnect IACV-FICD solenoid valve harness connector.

- Check for clicking sound when applying 12V direct current to terminals.
- Check plunger for seizing or sticking.
- Check for broken spring.

POWER STEERING OIL PRESSURE SWITCH

Component Description



Component Description

NMEC0789

The power steering oil pressure switch is attached to the power steering high-pressure tube and detects a power steering load. When a power steering load is detected, it signals the ECM. The ECM adjusts the IACV-AAC valve to increase the idle speed and adjust for the increased load.

CONSULT-II Reference Value in Data Monitor Mode

NMEC0790

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
PW/ST SIGNAL	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	Steering wheel in neutral position (forward direction)	OFF
		The steering wheel is fully turned	ON

ECM Terminals and Reference Value

NMEC0791

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
43	PU/W	Power steering oil pressure switch	[Engine is running] <ul style="list-style-type: none"> Steering wheel is fully turned 	Approximately 0V
			[Engine is running] <ul style="list-style-type: none"> Steering wheel is not turned 	Approximately 5V

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX





POWER STEERING OIL PRESSURE SWITCH

Wiring Diagram

Wiring Diagram

NMEC0792

EC-PST/SW-01



TEC819

POWER STEERING OIL PRESSURE SWITCH

Diagnostic Procedure

Diagnostic Procedure


=NMEC0793

1	INSPECTION START	
Do you have CONSULT-II?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

GI
MA
EM

2	CHECK OVERALL FUNCTION							
<p> With CONSULT-II</p> <p>1. Start engine.</p> <p>2. Check "PW/ST SIGNAL" in "DATA MONITOR" mode with CONSULT-II under the following conditions.</p>								
<table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th>NO DTC</th> </tr> </thead> <tbody> <tr> <td>PW/ST SIGNAL</td> <td>OFF</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR	NO DTC	PW/ST SIGNAL	OFF
DATA MONITOR								
MONITOR	NO DTC							
PW/ST SIGNAL	OFF							
<table border="1" style="margin: auto;"> <thead> <tr> <th>Conditions</th> <th>PW/ST SIGNAL</th> </tr> </thead> <tbody> <tr> <td>Steering is in neutral position</td> <td>OFF</td> </tr> <tr> <td>Steering is turned</td> <td>ON</td> </tr> </tbody> </table>			Conditions	PW/ST SIGNAL	Steering is in neutral position	OFF	Steering is turned	ON
Conditions	PW/ST SIGNAL							
Steering is in neutral position	OFF							
Steering is turned	ON							
SEF311Y								
OK or NG								
OK	▶	INSPECTION END						
NG	▶	GO TO 4.						


LC
EC
FE
CL
MT
AT

3	CHECK OVERALL FUNCTION							
<p> Without CONSULT-II</p> <p>1. Start engine.</p> <p>2. Check voltage between ECM terminal 43 and ground under the following conditions.</p>								
								
<table border="1" style="margin: auto;"> <thead> <tr> <th>Condition</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>When steering wheel is turned quickly</td> <td>Approximately 0V</td> </tr> <tr> <td>Except above</td> <td>Approximately 5V</td> </tr> </tbody> </table>			Condition	Voltage	When steering wheel is turned quickly	Approximately 0V	Except above	Approximately 5V
Condition	Voltage							
When steering wheel is turned quickly	Approximately 0V							
Except above	Approximately 5V							
SEC425C								
OK or NG								
OK	▶	INSPECTION END						
NG	▶	GO TO 4.						

AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

POWER STEERING OIL PRESSURE SWITCH

Diagnostic Procedure (Cont'd)

4	CHECK GROUND CIRCUIT	
<ol style="list-style-type: none"> Turn ignition switch "OFF". Disconnect power steering oil pressure switch harness connector. 		
		
<ol style="list-style-type: none"> Check harness continuity between power steering oil pressure switch terminal 2 and engine ground. Refer to wiring diagram. Continuity should exist. Also check harness for short to power. 		
OK or NG		
OK	▶	GO TO 5.
NG	▶	Repair open circuit or short to power in harness or connectors.

SEC391C

5	CHECK INPUT SIGNAL CIRCUIT	
<ol style="list-style-type: none"> Disconnect ECM harness connector. Check harness continuity between ECM terminal 43 and power steering oil pressure switch terminal 1. Refer to wiring diagram. Continuity should exist. Also check harness for short to ground and short to power. 		
OK or NG		
OK	▶	GO TO 7.
NG	▶	GO TO 6.

6	DETECT MALFUNCTIONING PART	
Check the harness for open or short between ECM and power steering oil pressure switch.		
▶ Repair open circuit or short to ground or short to power in harness or connectors.		

7	CHECK POWER STEERING OIL PRESSURE SWITCH	
Refer to "Component Inspection", EC-217.		
OK or NG		
OK	▶	GO TO 8.
NG	▶	Replace power steering oil pressure switch.

8	CHECK INTERMITTENT INCIDENT	
Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.		
▶ INSPECTION END		

POWER STEERING OIL PRESSURE SWITCH

Component Inspection

Component Inspection

POWER STEERING OIL PRESSURE SWITCH

NMEC0794

NMEC0794S01

1. Disconnect power steering oil pressure switch harness connector then start engine. GI
2. Check continuity between terminals 1 and 2. Refer to wiring diagram. MA

Conditions	Continuity	EM
Steering wheel is being fully turned.	Yes	
Steering wheel is not being turned.	No	LC

If NG, replace power steering oil pressure switch.

EC

FE

CL

MT

AT

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

ELECTRICAL LOAD SIGNAL

CONSULT-II Reference Value in Data Monitor Mode

CONSULT-II Reference Value in Data Monitor Mode

NMEC0795

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
LOAD SIGNAL	<ul style="list-style-type: none"> ● Ignition switch: ON 	Rear window defogger is operating and/or lighting switch is "2ND" position.
		Rear window defogger is not operating and lighting switch is "OFF".

ECM Terminals and Reference Value

NMEC0796

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
33	PU (A/T) G/R (M/T)	Electric load signal (Load switch)	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Rear window defogger is operating and/or lighting switch is "2ND" position 	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Rear window defogger is not operating and lighting switch is "OFF" 	Approximately 0V


ELECTRICAL LOAD SIGNAL

Wiring Diagram


Wiring Diagram

NMEC0797


EC-LOAD-01



- : DETECTABLE LINE FOR DTC
- : NON-DETECTABLE LINE FOR DTC
- ⬡ : WITH A/T
- ⬢ : WITH M/T
- *1 PU : ⬡
- G/R : ⬢



REFER TO THE FOLLOWING.
 E101, F4 -SUPER
 MULTIPLE JUNCTION (SMJ)
 B4, B5 -FUSE BLOCK-
 JUNCTION BOX (J/B)



GI
 MA
 EM
 LC
EC
 FE
 CL
 MT
 AT
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TEC821

ELECTRICAL LOAD SIGNAL

Diagnostic Procedure

Diagnostic Procedure

NMEC0798


1	INSPECTION START	
Do you have CONSULT-II?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 4.

2	CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-I							
<p> With CONSULT-II</p> <p>1. Turn ignition switch "ON".</p> <p>2. Check "LOAD SIGNAL" in "DATA MONITOR" mode with CONSULT-II under the following conditions.</p>								
<table border="1" style="margin: 10px auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="text-align: center;">MONITOR</th> <th style="text-align: center;">NO DTC</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">LOAD SIGNAL</td> <td style="text-align: center;">ON</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR	NO DTC	LOAD SIGNAL	ON
DATA MONITOR								
MONITOR	NO DTC							
LOAD SIGNAL	ON							
<table border="1" style="margin: 10px auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">CONDITION</th> <th style="text-align: center;">LOAD SIGNAL</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Rear window defogger switch "ON"</td> <td style="text-align: center;">ON</td> </tr> <tr> <td style="text-align: center;">Rear window defogger switch "OFF"</td> <td style="text-align: center;">OFF</td> </tr> </tbody> </table>			CONDITION	LOAD SIGNAL	Rear window defogger switch "ON"	ON	Rear window defogger switch "OFF"	OFF
CONDITION	LOAD SIGNAL							
Rear window defogger switch "ON"	ON							
Rear window defogger switch "OFF"	OFF							
SEC426C								
OK or NG								
OK	▶	GO TO 3.						
NG	▶	GO TO 6.						

3	CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-II							
<p> With CONSULT-II</p> <p>1. Turn ignition switch "ON".</p> <p>2. Check "LOAD SIGNAL" in "DATA MONITOR" mode with CONSULT-II under the following conditions.</p>								
<table border="1" style="margin: 10px auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="text-align: center;">MONITOR</th> <th style="text-align: center;">NO DTC</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">LOAD SIGNAL</td> <td style="text-align: center;">ON</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR	NO DTC	LOAD SIGNAL	ON
DATA MONITOR								
MONITOR	NO DTC							
LOAD SIGNAL	ON							
<table border="1" style="margin: 10px auto; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">CONDITION</th> <th style="text-align: center;">LOAD SIGNAL</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Lighting switch "2ND" position</td> <td style="text-align: center;">ON</td> </tr> <tr> <td style="text-align: center;">Lighting switch "OFF"</td> <td style="text-align: center;">OFF</td> </tr> </tbody> </table>			CONDITION	LOAD SIGNAL	Lighting switch "2ND" position	ON	Lighting switch "OFF"	OFF
CONDITION	LOAD SIGNAL							
Lighting switch "2ND" position	ON							
Lighting switch "OFF"	OFF							
SEC427C								
OK or NG								
OK	▶	INSPECTION END						
NG	▶	GO TO 9.						

ELECTRICAL LOAD SIGNAL

Diagnostic Procedure (Cont'd)

4	CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-I							
<p> Without CONSULT-II</p> <p>1. Turn ignition switch "ON".</p> <p>2. Check voltage between ECM terminal 33 and ground under the following conditions.</p>								
								
		<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Voltage</th> </tr> </thead> <tbody> <tr> <td>Rear window defogger switch "ON"</td> <td>BATTERY VOLTAGE</td> </tr> <tr> <td>Rear window defogger switch "OFF"</td> <td>0V</td> </tr> </tbody> </table>	Condition	Voltage	Rear window defogger switch "ON"	BATTERY VOLTAGE	Rear window defogger switch "OFF"	0V
Condition	Voltage							
Rear window defogger switch "ON"	BATTERY VOLTAGE							
Rear window defogger switch "OFF"	0V							
SEC428C								
OK or NG								
OK	▶	GO TO 5.						
NG	▶	GO TO 6.						

GI

MA


EM

LC

EC

FE

CL

5	CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-II							
<p> Without CONSULT-II</p> <p>1. Turn ignition switch "ON".</p> <p>2. Check voltage between ECM terminal 33 and ground under the following conditions.</p>								
								
		<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="width: 50%;">Condition</th> <th style="width: 50%;">Voltage</th> </tr> </thead> <tbody> <tr> <td>Lighting switch "2ND" position</td> <td>BATTERY VOLTAGE</td> </tr> <tr> <td>Lighting switch "OFF"</td> <td>0V</td> </tr> </tbody> </table>	Condition	Voltage	Lighting switch "2ND" position	BATTERY VOLTAGE	Lighting switch "OFF"	0V
Condition	Voltage							
Lighting switch "2ND" position	BATTERY VOLTAGE							
Lighting switch "OFF"	0V							
SEC429C								
OK or NG								
OK	▶	INSPECTION END						
NG	▶	GO TO 9.						

MT

AT

PD

AX

SU

BR

ST

6	CHECK REAR WINDOW DEFOGGER FUNCTION	
<p>1. Start engine.</p> <p>2. Turn "ON" the rear window defogger switch.</p> <p>3. Check the rear windshield. Is the rear windshield heated up?</p>		
Yes or No		
Yes	▶	GO TO 7.
No	▶	Refer to EL-96, "Rear Window Defogger".

RS

BT

HA

SC

EL

IDX

ELECTRICAL LOAD SIGNAL

Diagnostic Procedure (Cont'd)

7	CHECK REAR WINDOW DEFOGGER INPUT SIGNAL CIRCUIT							
<ol style="list-style-type: none"> 1. Stop engine 2. Disconnect ECM harness connector. 3. Disconnect rear window defogger relay. 4. Check harness continuity between ECM terminal 33 and rear window defogger relay terminals 5, 7 under the following conditions. 								
<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>CONDITION 1</p> </div> <div style="text-align: center;"> <p>CONDITION 2</p> </div> </div>								
		<table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 15%;">CONDITION</th> <th style="width: 85%;">CONTINUITY</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">Should exist.</td> </tr> <tr> <td style="text-align: center;">2</td> <td style="text-align: center;">Should not exist.</td> </tr> </tbody> </table>	CONDITION	CONTINUITY	1	Should exist.	2	Should not exist.
CONDITION	CONTINUITY							
1	Should exist.							
2	Should not exist.							
SEC430C								
<ol style="list-style-type: none"> 5. Also check harness for short to ground and short to power. 								
OK or NG								
OK	▶	GO TO 12.						
NG	▶	GO TO 8.						

8	DETECT MALFUNCTIONING PART	
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F4, M60 ● Harness connectors B3, M9 ● Joint connector 1 ● Harness open and short between ECM and rear window defogger relay 		
		▶ Repair open circuit or short to ground or short to power in harness or connectors.

9	CHECK HEADLAMP FUNCTION	
<ol style="list-style-type: none"> 1. Start engine. 2. Turn the lighting switch "2ND". 3. Check that headlamps are illuminated. <p style="text-align: center;">Do the headlamps illuminate in both "High" and "Low" positions?</p> <p style="text-align: center;">Yes or No</p>		
Yes	▶	GO TO 10.
No	▶	Refer to EL-28, "HEADLAMP".

ELECTRICAL LOAD SIGNAL

Diagnostic Procedure (Cont'd)

10	CHECK HEADLAMP INPUT SIGNAL CIRCUIT						
<p>A/T models</p> <ol style="list-style-type: none"> 1. Stop engine. 2. Disconnect ECM harness connector. 3. Disconnect lighting switch harness connector. 4. Check harness continuity between ECM terminal 33 and lighting switch terminal 10 under the following conditions. 							
<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>CONDITION 1</p> </div> <div style="text-align: center;"> <p>CONDITION 2</p> </div> </div>							
<table border="1" style="border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">CONDITION</th> <th style="text-align: center;">CONTINUITY</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">Should exist.</td> </tr> <tr> <td style="text-align: center;">2</td> <td style="text-align: center;">Should not exist.</td> </tr> </tbody> </table>		CONDITION	CONTINUITY	1	Should exist.	2	Should not exist.
CONDITION	CONTINUITY						
1	Should exist.						
2	Should not exist.						
<p>5. Also check harness for short to ground and short to power.</p> <p style="text-align: right;">SEC431C</p>							
<p>M/T models</p> <ol style="list-style-type: none"> 1. Stop engine. 2. Disconnect ECM harness connector. 3. Disconnect lighting switch harness connector. 4. Check harness continuity between ECM terminal 33 and lighting switch terminal 10. Refer to Wiring Diagram. 5. Also check harness for short to ground and short to power. 							
OK or NG							
OK	▶ GO TO 12.						
NG	▶ GO TO 11.						

11	DETECT MALFUNCTIONING PART
<p>Check the following.</p> <ul style="list-style-type: none"> ● Harness connectors F4, M60 ● Harness connectors M10, E101 ● Joint connector-1 ● Harness for open and short between ECM and lighting switch 	
▶	Repair open circuit or short to ground or short to power in harness or connectors.

12	CHECK INTERMITTENT INCIDENT
<p>Perform "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-82.</p>	
▶	INSPECTION END

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX





MI & DATA LINK CONNECTORS

Wiring Diagram

Wiring Diagram

NMEC0800

EC-MIL/DL-01



REFER TO THE FOLLOWING.

- (F4) -SUPER MULTIPLE JUNCTION (SMJ)
- (M6), (M7) -FUSE BLOCK-JUNCTION BOX (J/B)

TEC822

SERVICE DATA AND SPECIFICATIONS (SDS)

Fuel Pressure Regulator

Fuel Pressure Regulator

NMEC0801

Fuel pressure at idling kPa (bar, kg/cm ² , psi)	Vacuum hose is connected	Approximately 245 (2.45, 2.5, 36)
	Vacuum hose is disconnected	Approximately 294 (2.94, 3.0, 43)

Idle Speed and Ignition Timing

NMEC0802

Target idle speed*1 rpm	No-load*3 (in "P" or "N" position)	800±50
Air conditioner: ON rpm	In "P" or "N" position	800±50
Ignition timing*2	In "P" or "N" position	15°±2° BTDC
Throttle position sensor idle position V		0.15 - 0.85

*1: Throttle position sensor harness connector connected

*2: Throttle position sensor harness connector disconnected

*3: Under the following conditions:

- Air conditioner switch: OFF
- Electrical load: OFF (Lights & rear window defogger)
- Steering wheel: Kept in straight-ahead position

Mass Air Flow Sensor

NMEC0804

Supply voltage V	Battery voltage (11 - 14)
Output voltage V	0.8 - 1.5

Engine Coolant Temperature Sensor

NMEC0805

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

Fuel Pump

NMEC0808

Resistance [at 25°C (77°F)] Ω	0.2 - 5.0
-------------------------------	-----------

IACV-AAC Valve

NMEC0809

Resistance [at 20°C (68°F)] Ω	Approximately 10
-------------------------------	------------------

Injector

NMEC0810

Resistance [at 20°C (68°F)] Ω	Approximately 11
-------------------------------	------------------

Throttle Position Sensor

NMEC0812

Throttle valve conditions	Voltage (at normal operating temperature, engine off, ignition switch ON, throttle opener disengaged)
Completely closed (a)	0.15 - 0.85V
Partially open	Between (a) and (b)
Completely open (b)	3.5 - 4.7V

Heated Oxygen Sensor 1 (Front) Heater

NMEC0813

Resistance [at 25°C (77°F)] Ω	2.3 - 4.3
-------------------------------	-----------

NOTES